FORCE1

8+

INSTRUCTION MANUAL


PLEASE READ CAREFULLY BEFORE OPERATION AND KEEP FOR FUTURE REFERENCE.

REMOTE CONTROL FUNCTION




PAIRING INSTRUCTIONS

Install batteries for the RC car and remote control before play.



1. Switch on the RC car then press the Power button on the remote control.
2. The power light indicator on the remote control will flash then turn off to signal successful pairing.
3. If the RC car does not respond, please switch off both the car and the remote control then re-operate the pairing instructions.


REMOTE CONTROL BATTERY INSTALLATION



Note: Install the batteries by polarity.

Use 2x1.5V "AA" Size Baterries (Not Included)


CAR BATTERY INSTALLATION



Use 1x3.7V 500mAh Lithium Battery (Included)

BATTERY CHARGING INSTRUCTION

Connect USB Cable to 3.7V Lithium Battery.



⚠ BATTERY SAFETY INSTRUCTIONS

1. Do not charge rechargeable batteries without adult supervision.
2. Do not mix old and new batteries or different types of batteries.
3. Only use the recommended types of batteries for the car and the remote control.
4. Remove batteries with low battery charge immediately.
5. Do not short circuit the power supply.
6. Do not disassemble batteries. Dispose old batteries properly.
7. Input voltage of the USB charging cable must be 5V DC and should use input 110-220V (50/60Hz), output 5V 0.5-1.5A. Do not use a fast charger to charge the car.
8. Remove the battery from the car when charging.
9. Regularly check the USB charging cable for damages. If any damage is found, discontinue use until completely repaired.
10. Please use only the included USB charging cable to charge the RC car battery.
11. Install batteries by correct polarity.
12. Charge time: 120 minutes; Play time: 35 minutes.

Visit us at https://force1rc.com

BASIC OPERATION CONTROLS



















When the car is running at normal speed, press the Speed button for the car to speed up.





When the car is speeding up, press the Speed button again to return to normal speed.



Inquiries? Email us at: support@force1rc.com