

# Headstock Housing 1




# Headstock Housing 2




# Headstock Housing Parts List

| REF | PART # | DESCRIPTION |
|---|---|---|
| 1 | PSB1046PF0001 | SHIFT LEVER END CAP |
| 2 | PSB1046PF0002 | SHIFT LEVER |
| 3 | PCAP38M | CAP SCREW M5-.8 X 25 |
| 4 | PSB1046PF0004 | SHAFT COLLAR |
| 5 | PK47M | KEY 4 X 4 X 15 |
| 6 | PSB1046PF0006 | SHIFT LEVER SHAFT |
| 7 | PK48M | KEY 4 X 4 X 20 |
| 8 | PSB1046PF0008 | DETENT PIN |
| 9 | PSB1046PF0009 | COMPRESSION SPRING |
| 10 | PSB1046PF0010 | SHIFT KNUCKLE |
| 11 | PR07M | EXT RETAINING RING 18MM |
| 12 | PSB1046PF0012 | SHIFT TAB |
| 13 | PS107M | PHLP HD SCR M6-1 X 20 |
| 14 | PSB1046PF0014 | LEVER BEVELED WASHER |
| 15 | PSB1046PF0015 | SPEED SELECTION LEVER |
| 16 | PR15M | EXT RETAINING RING 30MM |
| 17 | PSB1046PF0017 | RANGE SELECTION LEVER |
| 18 | PK19M | KEY 5 X 5 X 14 |
| 19 | PSB1046PF0019 | SPEED SLECTOR SHAFT |
| 20 | PK19M | KEY 5 X 5 X 14 |
| 21 | PCAP40M | CAP SCREW M8-1.25 X 35 |
| 22 | PSB1046PF0022 | LEVER HOUSING |
| 23 | PK82M | KEY 7 X 7 X 18 |
| 24 | PSB1046PF0024 | RANGE SELECTOR SHAFT |
| 25 | PSB1046PF0025 | SELECTOR SLEEVE |
| 26 | PR12M | EXT RETAINING RING 35MM |
| 27 | PSB1046PF0027 | SELECTOR DISC |
| 28 | PSB1046PF0028 | SIGHT GLASS |
| 29 | PSB1046PF0029 | STEP PIN |
| 30 | PSB1046PF0030 | UPPER PIVOT ROD |
| 31 | PSB1046PF0031 | UPPER SHIFT YOKE |
| 32 | PEC03M | E-CLIP 10MM |
| 33 | PSB1046PF0033 | SHIFT FORK |
| 34 | PSB1046PF0034 | SHIFT ARM PIVOT BOLT |
| 35 | PSB1046PF0035 | SHIFT ARM |
| 36 | PSB1046PF0036 | SHIFT FORK |
| 37 | PSB1046PF0037 | LOWER SHIFT YOKE |
| 38 | PSB1046PF0038 | LOWER PIVOT ROD |
| 39 | PCAP07M | CAP SCREW M6-1 X 30 |
| 40 | PSB1046PF0040 | DETENT BRACKET |
| 41 | PSB1046PF0041 | SHIFT LIMIT PIN |
| 42 | PSB1046PF0042 | OIL TUBE |
| 43 | PSB1046PF0043 | SHIFT YOKE FRAME |
| 44 | PSB1046PF0044 | OIL FITTING |
| 45 | PSB1046PF0045 | PIVOT ARM BOLT HEX NUT |
| 46 | PSB1046PF0046 | PIVOT ROD LOCK COLLARS |
| 47 | PCAP14M | CAP SCREW M8-1.25 X 20 |
| 48 | PSB1046PF0048 | SHIFT FORK |
| 49 | PSB1046PF0049 | OUTBOARD SIDE SHIFT LEVER |
| 50 | PSB1046PF0050 | HEADSTOCK TOP COVER |
| 51 | PSB1046PF0051 | HEADSTOCK CASTING (SB1046PF-48PF |
| 51 | PSB1056F0051 | HEADSTOCK CASTING (SB1056F-58F) |
| 52 | PSB1046PF0052 | COMPRESSION SPRING |
| 53 | PFH05M | FLAT HD SCR M5-.8 X 12 |
| 54 | PW03M | FLAT WASHER 6MM |
| 55 | PK07M | KEY 6 X 6 X 20 |
| 56 | PRP76M | ROLL PIN 4 X 16 |
| 57 | PSB1046PF0057 | FLANGE BUSHING |
| 58 | PSB1046PF0058 | LEVER |
| 59 | PSB1046PF0059 | PIVOT PIN |
| 60 | PSB1046PF0060 | LEVER ROLLER |
| 61 | PCAP50M | CAP SCREW M5-.8 X 10 |
| 62 | PSB1046PF0062 | INNER LEVER SLEEVE |
| 63 | PSB1046PF0063 | LEVER SHAFT |
| 64 | PSB1046PF0064 | SHIFT FORK |
| 65 | PR01M | EXT RETAINING RING 10MM |
| 66 | PSB1046PF0066 | SHIFT TAB |
| 67 | PK42M | KEY 6 X 6 X 30 |
| 68 | PSB1046PF0068 | RETAINING FLAT WASHER 6MM |
| 69 | PCAP01M | CAP SCREW M6-1 X 16 |
| 70 | PSB1046PF0070 | EXTENSION SPRING |
| 71 | PCAP02M | CAP SCREW M6-1 X 20 |
| 72 | PSB1046PF0072 | BUSHING |
| 73 | PSB1046PF0073 | DETENT PLATE |
| 74 | PSB1046PF0074 | SPRING HANGER |
| 75 | PSB1046PF0075 | SPRING PLATE |
| 76 | PN01M | HEX NUT M6-1 |
| 77 | PSB1046PF0077 | HEADSTOCK REAR COVER |

# Headstock Gears 1



# Headstock Gears 2



# Headstock Gears Parts List

| REF | PART # | DESCRIPTION |
|---|---|---|
| 101 | PSB1046PF0101 | CAMLOCK STUD |
| 102 | PSB1046PF0102 | SPINDLE BOLT |
| 103 | PSB1046PF0103 | SPINDLE |
| 104 | PSB1046PF0104 | COMPRESSION SPRING |
| 105 | PSB1046PF0105 | CAMLOCK |
| 106 | PSB1046PF0106 | KEY 15 X 10 X 78 |
| 107 | PCAP29M | CAP SCREW M6-1 X 40 |
| 108 | PSB1046PF0108 | FRONT BEARING COVER |
| 109 | PSB1046PF0109 | INBOARD SPINDLE GASKET |
| 110 | P32026 | TAPERED BEARING 32026 |
| 111 | PSB1046PF0111 | GEAR 75T |
| 112 | PSB1046PF0112 | GEAR 56T |
| 113 | PSB1046PF0113 | SPINDLE SPACER |
| 114 | P6022-OPEN | BALL BEARING 6022 OPEN |
| 115 | PR90M | EXT RETANING RING 110MM |
| 116 | PK114M | KEY 10 X 8 X 35 |
| 117 | PSB1046PF0117 | GEAR 48T |
| 118 | P32021 | TAPER BEARING 32021 |
| 119 | PSB1046PF0119 | SPANNER NUT |
| 120 | PSB1046PF0120 | OUTBOARD SPINDLE GASKET |
| 121 | PSB1046PF0121 | REAR BEARING COVER |
| 122 | PCAP14M | CAP SCREW M8-1.25 X 20 |
| 123 | PSB1046PF0123 | PLUG |
| 124 | PORG065 | O-RING 64.4 X 3.1 G65 |
| 125 | PSB1046PF0125 | PLUG |
| 126 | PORG055 | O-RING 54.4 X 3.1 G55 |
| 127 | P6305-OPEN | BALL BEARING 6305 OPEN |
| 128 | PR38M | INT RETAINING RING 62MM |
| 129 | PSB1046PF0129 | COMBO GEAR 21T/40T |
| 130 | PSB1046PF0130 | SPLINED SHAFT |
| 131 | PSB1046PF0131 | COLLAR |
| 132 | P6007-OPEN | BALL BEARING 6007 OPEN |
| 133 | PSB1046PF0133 | COMBO GEAR 26T/38T |
| 134 | PSB1046PF0134 | COMBO GEAR 30T/34T |
| 135 | PR32M | EXT RETAINING RING 48MM |
| 136 | PSB1046PF0136 | GEAR 32T |
| 137 | PSB1046PF0137 | GEAR SHAFT 16T |
| 138 | PSB1046PF0138 | SPLINED SHAFT COVER |
| 139 | PCAP02M | CAP SCREW M6-1 X 20 |
| 140 | PRP02M | ROLL PIN 3 X 16 |
| 141 | PSB1046PF0141 | SHAFT COVER PLATE |
| 142 | PSB1046PF0142 | SPACER |
| 143 | PORP030 | O-RING 29.7 X 3.5 P30 |
| 144 | PSB1046PF0144 | OIL SEAL 507212 |
| 145 | PR64M | INT RETAINING RING 72MM |
| 146 | P6207-RS | BALL BEARING 6207-RS |
| 147 | PSB1046PF0147 | SPLINED GEAR SHAFT 16T |
| 148 | PK136M | KEY 8 X 8 X 30 |
| 149 | PR68M | EXT RETAINING RING 40MM |
| 150 | PSB1046PF0150 | GEAR 35T |


| REF | PART # | DESCRIPTION |
|---|---|---|
| 151 | P6008-OPEN | BALL BEARING 6008 OPEN |
| 152 | PSB1046PF0152 | COMBO GEAR 25T/40T |
| 153 | PSB1046PF0153 | BRAKE DRUM SHAFT |
| 154 | PSB1046PF0154 | BRAKE SHOE |
| 155 | PSB1046PF0155 | COMPRESSION SPRING |
| 156 | PSB1046PF0156 | BRAKE DRUM |
| 157 | PW01M | FLAT WASHER 8MM |
| 158 | PCAP31M | CAP SCREW M8-1.25 X 25 |
| 159 | PSB1046PF0159 | CENTRIFUGAL BRAKE CYLINDER |
| 160 | PSB1046PF0160 | BRAKE SHOE BUSHING |
| 161 | PS11M | PHLP HD SCR M6-1 X 16 |
| 162 | PSB1046PF0162 | RETAINER PIN |
| 163 | PSB1046PF0163 | BRAKE ASSEMBLY FLAT WASHER |
| 164 | PSB1046PF0164 | BRAKE ASSEMBLY COLLAR |
| 165 | PSB1046PF0165 | NEEDLE ROLLER BEARING NK22/20 |
| 166 | PR43M | EXT RETAINING RING 50MM |
| 167 | PSB1046PF0167 | SHAFT |
| 168 | PSB1046PF0168 | KEY 10 X 7 X 18 |
| 169 | PSB1046PF0169 | KEY 10 X 7 X 30 |
| 170 | PSB1046PF0170 | CLUTCH/GEAR ASSEMBLY 31T |
| 171 | PSB1046PF0171 | OUTBOARD COPPER COLLAR |
| 172 | PSB1046PF0172 | CLUTCH ASSEMBLY |
| 173 | PSB1046PF0173 | INBOARD COPPER COLLAR |
| 174 | P6906-OPEN | BALL BEARING 6906-OPEN |
| 175 | PSB1046PF0175 | CLUTCH/GEAR ASSY 27T |
| 176 | PSB1046PF0176 | CLUTCH ASSEMBLY SHAFT |
| 177 | PSB1046PF0177 | WOODRUFF KEY 25 X 7 |
| 178 | P6206-OPEN | BALL BEARING 6206 OPEN |
| 179 | PORG075 | O-RING 74.4 X 3.1 G75 |
| 180 | PSB1046PF0180 | BEARING SEAT |
| 181 | PSB1046PF0181 | OIL SEAL 406212 |
| 182 | PSB1046PF0182 | PULLEY SPACER |
| 183 | PSB1046PF0183 | SPINDLE PULLEY |
| 184 | PSB1046PF0184 | PULLEY FLAT WASHER |
| 185 | PCAP13M | CAP SCREW M8-1.25 X 30 |
| 186 | PORP016 | O-RING 15.8 X 2.4 P16 |
| 187 | PCAP26M | CAP SCREW M6-1 X 12 |
| 188 | PSB1046PF0188 | SHAFT RETAINING FLAT WASHER |
| 189 | PSB1046PF0189 | CHANGE GEAR SHAFT |
| 190 | PSB1046PF0190 | CHANGE GEAR SHAFT |
| 191 | PSB1046PF0191 | OIL SEAL 385508 |
| 192 | PSB1046PF0192 | SHAFT HOUSING |
| 193 | PSB1046PF0193 | SPINED SHAFT |
| 194 | PSB1046PF0194 | SPLINED SHAFT SPACER |
| 195 | PSB1046PF0195 | NEEDLE BEARING 32 X 30 |
| 196 | PR15M | EXT RETAINING RING 30MM |
| 197 | PSB1046PF0197 | GEAR 24T |
| 198 | PSB1046PF0198 | OIL DRAIN PLUG 1/2" NPT |
| 199 | PSB1046PF0199 | ELBOW 3/4 X 1/2" NPT |
| 200 | PSB1046PF0200 | COUPLER 3/4" NPT |

# Headstock Gears Parts List


| REF | PART # | DESCRIPTION |
|---|---|---|
| 201 | PSB1046PF0201 | CHANGE GEAR SHAFT |
| 202 | PSB1046PF0202 | GEAR 24T |
| 203 | PR37M | EXT RETAINING RING 32MM |
| 204 | PSB1046PF0204 | CHANGE GEAR SHAFT |
| 205 | PSB1046PF0205 | COMBO GEAR 24T/48T |
| 206 | PSB1046PF0206 | CHANGE GEAR SHAFT |
| 207 | PSB1046PF0207 | COMBO GEAR 48T/24T |
| 208 | PCAP01M | CAP SCREW M6-1 X 16 |
| 209 | PSB1046PF0209 | CHANGE GEAR SHAFT |
| 210 | PORG035 | O-RING 3.1 X 34.4 G35 |
| 211 | PSB1046PF0211 | NEEDLE ROLLER BEARING NAX3030 |
| 212 | PSB1046PF0212 | GEAR 28T |
| 213 | PSB1046PF0213 | CHANGE SPACER |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 214 | PSB1046PF0214 | SHAFT COVER PLATE |
| 215 | PSB1046PF0215 | FLANGED BEARING |
| 216 | PSB1046PF0216 | SPLINED SHAFT |
| 217 | PSB1046PF0217 | GEAR 27T |
| 218 | PSB1046PF0218 | SPACER |
| 219 | PSB1046PF0219 | GEAR 23T |
| 220 | PSB1046PF0220 | SPACER |
| 221 | PSB1046PF0221 | GEAR 27T |
| 222 | PSB1046PF0222 | GEAR 19T |
| 223 | PSB1046PF0223 | SPACER |
| 224 | PSB1046PF0224 | GEAR 31T |
| 225 | P6207-OPEN | BALL BEARING 6207-OPEN |
| 226 | PSB1046PF0226 | BEARING RETAINER |

# Gearbox 1


G1
G2
G3
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
426
427
428

# Gearbox 2


417
416
377
415
418
423
424
417
416
377
425
415
423
422
414
373
413
408
420
421
419
412
373
421
419
413
412
420
413
412
407
411
409
410
406
373
405
429
404
406
373
405
429
404
406
373
405
429
404
403
401
402
401
400
399
398
397
431
396
395
376
390
378
377
380
384
391
382
385
389
394
393
392
388
387
386
383
381
375
432
374
430

# Gearbox Parts List


| REF | PART # | DESCRIPTION |
|---|---|---|
| 301 | PSB1046PF0301 | SPLINED SHAFT |
| 302 | PK109M | KEY 7 X 7 X 35 |
| 303 | PSB1046PF0303 | SHAFT SPACER |
| 304 | PSB1046PF0304 | OIL SEAL 253708 |
| 305 | PSB1046PF0305 | NEEDLE BEARING |
| 306 | PCAP01M | CAP SCREW M6-1 X 16 |
| 307 | PSB1046PF0307 | SPLINED SHAFT SEAT |
| 308 | PSB1046PF0308 | SPACER |
| 309 | PR11M | EXT RETAINING RING 25MM |
| 310 | PSB1046PF0310 | GEAR 19T/19T |
| 311 | PSB1046PF0311 | SPLINED SHAFT |
| 312 | PSB1046PF0312 | SHAFT COVER |
| 313 | PSB1046PF0313 | COVER GASKET |
| 314 | P6005-OPEN | BALL BEARING 6005 OPEN |
| 315 | PSB1046PF0315 | SPACER |
| 316 | PSB1046PF0316 | GEAR 20T/30T |
| 317 | PSB1046PF0317 | SPACER |
| 318 | PR15M | EXT RETAINING RING 30MM |
| 319 | PSB1046PF0319 | SPLINED SHAFT |
| 320 | PSB1046PF0320 | GEAR 22T |
| 321 | PSB1046PF0321 | SHAFT SPACER |
| 322 | PSB1046PF0322 | SPLINED SHAFT |
| 323 | PSB1046PF0323 | GEARBOX CASTING |
| 324 | PSB1046PF0324 | SPACER |
| 325 | PSB1046PF0325 | GEAR 32T |
| 326 | PSB1046PF0326 | GEAR 23T |
| 327 | PSB1046PF0327 | GEAR 16T |
| 328 | PSB1046PF0328 | SPACER |
| 329 | PR25M | INT RETAINING RING 47MM |
| 330 | P6204-OPEN | BALL BEARING 6204-OPEN |
| 331 | PSB1046PF0331 | SPACER |
| 332 | PSB1046PF0332 | SHAFT CLUTCH |
| 333 | PR09M | EXT RETAINING RING 20MM |
| 334 | PSB1046PF0334 | COMBO GEAR 35T/35T |
| 335 | PSB1046PF0335 | SPACER |
| 336 | PSB1046PF0336 | GEAR 22T |
| 337 | PSB1046PF0337 | GEAR 16T |
| 338 | PSB1046PF0338 | GEAR 20T |
| 339 | PSB1046PF0339 | SPACER |
| 340 | PSB1046PF0340 | GEAR 24T |
| 341 | PSB1046PF0341 | SPACER |
| 342 | PSB1046PF0342 | GEAR 23T |
| 343 | PSB1046PF0343 | SPACER |
| 344 | PSB1046PF0344 | GEAR 27T |
| 345 | PSB1046PF0345 | SPACER |
| 346 | PSB1046PF0346 | GEAR 24T |
| 347 | PSB1046PF0347 | SPACER |
| 348 | PSB1046PF0348 | GEAR 28T |
| 349 | PSB1046PF0349 | SPACER |
| 350 | PSB1046PF0350 | GEAR 26T |
| 351 | PSB1046PF0351 | GEAR 32T |
| 352 | PSB1046PF0352 | SHAFT NUT |
| 353 | PSS02M | SET SCREW M6-1 X 6 |
| 354 | PR10M | EXT RETAINING RING 22MM |
| 355 | PSB1046PF0355 | COMBO GEAR 45T/18T |
| 356 | PSB1046PF0356 | GEAR 22T |
| 357 | PSB1046PF0357 | GEAR 22T |
| 358 | PSB1046PF0358 | GEAR 33T |
| 359 | PSB1046PF0359 | GEAR 22T |
| 360 | PSB1046PF0360 | SPACER |
| 361 | PSB1046PF0361 | GEAR 36T |
| 362 | PSB1046PF0362 | SHAFT SEAT |
| 363 | PSB1046PF0363 | OIL SEAL 304005 |
| 364 | PSB1046PF0364 | SPACER |
| 365 | PSB1046PF0365 | SPLINED SHAFT |
| 366 | PSB1046PF0366 | SHAFT SEAT |
| 367 | PSB1046PF0367 | SPACER |
| 368 | PSB1046PF0368 | SHAFT |
| 369 | PSB1046PF0369 | PIN 6 X 36 |
| 370 | P6003-OPEN | BALL BEARING 6003 OPEN |
| 371 | PR18M | EXT RETAINING RING 17MM |
| 372 | PSB1046PF0372 | BEARING SEAT |
| 373 | PLW03M | LOCK WASHER 6MM |
| 374 | PSB1046PF0374 | PLATE |
| 375 | PSB1046PF0375 | REVERSE STOP PLATE |
| 376 | PSB1046PF0376 | UPPER/LOWER PLATE |
| 377 | PSTB001 | STEEL BALL 1/4 |
| 378 | PSB1046PF0378 | COMPRESSION SPRING |
| 380 | PRP24M | ROLL PIN 5 X 16 |
| 381 | PSB1046PF0381 | BOTTOM SHIFT FORK SUPPORT |
| 382 | PRP24M | ROLL PIN 5 X 16 |
| 383 | PSB1046PF0383 | BOTTOM SHIFT FORK |
| 384 | PCAP15M | CAP SCREW M5-.8 X 20 |
| 385 | PSB1046PF0385 | PARTITION |
| 386 | PSB1046PF0386 | LOWER-MID SHIFT FORK SUPPORT |
| 387 | PSB1046PF0387 | LOWER-MID SHIFT FORK |
| 388 | PSB1046PF0388 | UPPER-MID SHIFT FORK SUPPORT |
| 389 | PSB1046PF0389 | UPPER-MID SHIFT FORK |
| 390 | PSB1046PF0390 | TOP SHIFT FORK SUPPORT |
| 391 | PSB1046PF0391 | TOP SHIFT FORK |
| 392 | PSB1046PF0392 | SPACER |
| 393 | PSB1046PF0393 | PARTITION NUT |
| 394 | PSB1046PF0394 | PARTITION PLATE |
| 395 | PSB1046PF0395 | GEARBOX GASKET |
| 396 | PSB1046PF0396 | SHIFT GATE |
| 397 | PSB1046PF0397 | SELECTOR LEVER RETAINER |
| 398 | PORG035 | O-RING 3.1 X 34.4 G35 |
| 399 | PSB1046PF0399 | SELECTOR LEVER |
| 400 | PSB1046PF0400 | COMPRESSION SPRING |
| 401 | PORG040 | O-RING 39.4 X 3.1 G40 |
| 402 | PSB1046PF0402 | SELECTOR LEVER BASE |

# Gearbox Parts List


| REF | PART # | DESCRIPTION |
|---|---|---|
| 403 | PSB1046PF0403 | SELECTOR LEVER PIN |
| 404 | PSB1046PF0404 | LEVER CAP |
| 405 | PSB1046PF0405 | LEVER RETAINING FLAT WASHER |
| 406 | PSB1046PF0406 | SHIFT LEVER |
| 407 | PSB1046PF0407 | SIGHT GLASS |
| 408 | PSB1046PF0408 | GEARBOX COVER (SB1046PF-48PF) |
| 408 | PSB1056F0408 | GEARBOX COVER (SB1056F-58F) |
| 409 | PSB1046PF0409 | COUPLER 3/4" NPT |
| 410 | PSB1046PF0410 | ELBOW 3/4" NPT |
| 411 | PSB1046PF0411 | OIL FILL PLUG 3/4" NPT |
| 412 | PK05M | KEY 4 X 4 X 10 |
| 413 | PSB1046PF0413 | SELECTOR SHAFT |
| 414 | PSB1046PF0414 | SELECTOR BAR |
| 415 | PSB1046PF0415 | SHIFT KNUCKLE |
| 416 | PSB1046PF0416 | COMPRESSION SPRING |
| 417 | PSS20M | SET SCREW M8-1.25 X 8 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 418 | PSB1046PF0418 | SHIFT FORK |
| 419 | PCAP02M | CAP SCREW M6-1 X 20 |
| 420 | PRP24M | ROLL PIN 5 X 16 |
| 421 | PW03M | FLAT WASHER 6MM |
| 422 | PSS02M | SET SCREW M6-1 X 6 |
| 423 | PRP04M | ROLL PIN 4 X 24 |
| 424 | PSB1046PF0424 | SHIFT TAB |
| 425 | PSB1046PF0425 | SHIFT FORK |
| 426 | PSB1046PF0426 | SQUARE HEAD PLUG 1/2" NPT |
| 427 | PSB1046PF0427 | PIPE ELBOW 1/2" NPT |
| 428 | PSB1046PF0428 | COUPLER 1/2" NPT |
| 429 | PCAP26M | CAP SCREW M6-1 X 12 |
| 430 | PCAP29M | CAP SCREW M6-1 X 40 |
| 431 | PCAP38M | CAP SCREW M5-.8 X 25 |
| 432 | PCAP01M | CAP SCREW M6-1 X 16 |

# Apron 1


563
562
561
560
553
559
553
559
506
506
558
539
522
521
520
512
511
557
548
514
528
546
543
538
537
536
534
535
532
533
527
526
519
518
517
555
550
549
564
506
553
548
554
552
551
545
547
542
540
541
523
531
567
566
565
529
530
516
515
514
513
525
524
510
509
508
506
507
505
504
503
502
501

# Apron 2


569
570
558
558
571
558
568
572
573
574
575
576
634
570
579
570
580
581
582
570
577
578
586
587
585
588
589
594
593
595
590
592
591
596
597
598
599
600
605
606
611
612
613
614
619
618
620
621
622
623
624
625
626
607
608
601
602
603
604
609
610
615
612
611
616
617
633
632
631
627
629
630
628
582
548
584
583
582
581
580
570
579
570

# Apron Parts List

| REF | PART # | DESCRIPTION |
|---|---|---|
| 501 | PSB1046PF0501 | HANDLE CAP SCREW |
| 502 | PSB1046PF0502 | HANDLE |
| 503 | PSS12M | SET SCREW M6-1 X 25 |
| 504 | PSB1046PF0504 | HANDWHEEL CENTER CAP |
| 505 | PSB1046PF0505 | HANDWHEEL |
| 506 | PSTB001 | STEEL BALL 1/4 |
| 507 | PSB1046PF0507 | COMPRESSION SPRING |
| 508 | PSB1046PF0508 | GRADUATED DIAL |
| 509 | PFH05M | FLAT HD SCR M5-.8 X 12 |
| 510 | PSB1046PF0510 | GRADUATED DIAL BASE |
| 511 | PSB1046PF0511 | WOODRUFF KEY 19 X 5 |
| 512 | PSB1046PF0512 | GEAR SHAFT |
| 513 | PSB1046PF0513 | PLUG |
| 514 | PR07M | EXT RETAINING RING 18MM |
| 515 | PSB1046PF0515 | SPACER |
| 516 | PSB1046PF0516 | NEEDLE ROLLER BEARING 18/20 |
| 517 | PSB1046PF0517 | SPACER |
| 518 | PR11M | EXT RETAINING RING 25MM |
| 519 | PSB1046PF0519 | GEAR 56T |
| 520 | PSB1046PF0520 | NEEDLE ROLLER BEARING 28/20 |
| 521 | PSB1046PF0521 | NOTCHED SPACER |
| 522 | PSB1046PF0522 | GEAR SHAFT |
| 523 | PRIV018M | STEEL FLUTED RIVET 2.8 X 10 |
| 524 | PSB1046PF0524 | KNOB LABEL |
| 525 | PSB1046PF0525 | SHAFT |
| 526 | PSB1046PF0526 | GEAR SPACER |
| 527 | PSB1046PF0527 | COMBO GEAR 15T/33T |
| 528 | PSB1046PF0528 | GEAR SPACER |
| 529 | PSB1046PF0529 | APRON PIN |
| 530 | PSB1046PF0530 | SIGHT GLASS |
| 531 | PSB1046PF0531 | SHAFT |
| 532 | PSB1046PF0532 | NEEDLE BEARING TLA1616 |
| 533 | PSB1046PF0533 | GEAR SHAFT 26T |
| 534 | PSB1046PF0534 | NEEDLE ROLLER BEARING TLA3016 |
| 535 | PSB1046PF0535 | GEAR 24T |
| 536 | PSB1046PF0536 | GEAR 24T |
| 537 | PSB1046PF0537 | SPLINED GEAR |
| 538 | PR15M | EXT RETAINING RING 30MM |
| 539 | PSB1046PF0539 | COLLAR |
| 540 | PSB1046PF0540 | SLOTTED DOWEL PIN |
| 541 | PSB1046PF0541 | INDICATOR PLATE |
| 542 | PSB1046PF0542 | SHIFT SHAFT |
| 543 | PSB1046PF0543 | GEAR 24T |
| 545 | PSB1046PF0545 | GEAR SHAFT |
| 546 | PSB1046PF0546 | GEAR 24T |
| 547 | PSB1046PF0547 | HANDLE ASSEMBLY |
| 548 | PORP021 | O-RING 20.8 X 2.4 P21 |
| 549 | PSB1046PF0549 | SHIFT KNUCKLE |
| 550 | PR81M | EXT RETAINING RING 21MM |
| 551 | PFH38M | FLAT HD SCR M6-1 X 16 |
| 552 | PSB1046PF0552 | LEVER HUB FLAT WASHER |


| REF | PART # | DESCRIPTION |
|---|---|---|
| 553 | PSS20M | SET SCREW M8-1.25 X 8 |
| 554 | PSB1046PF0554 | COMPRESSION SPRING |
| 555 | PSB1046PF0555 | HALF-NUT LEVER ASSEMBLY |
| 557 | PSB1046PF0557 | O-RING G-25 |
| 558 | PSS03M | SET SCREW M6-1 X 8 |
| 559 | PSB1046PF0559 | COMPRESSION SPRING |
| 560 | PSB1046PF0560 | WOODRUFF KEY 16 X 5MM |
| 561 | PSB1046PF0561 | CAM SHAFT |
| 562 | PSS84M | SET SCREW M10-1.5 X 35 |
| 563 | PSS30M | SET SCREW M10-1.5 X 10 |
| 564 | PSB1046PF0564 | APRON CASTING |
| 565 | PSS75M | SET SCREW M10-1.5 X 16 |
| 566 | PSB1046PF0566 | COMPRESSION SPRING |
| 567 | PSTB003 | STEEL BALL 3/8" |
| 568 | PCAP26M | CAP SCREW M6-1 X 12 |
| 569 | PSB1046PF0569 | HALF-NUT GIB |
| 570 | PCAP01M | CAP SCREW M6-1 X 16 |
| 571 | PCAP07M | CAP SCREW M6-1 X 30 |
| 572 | PSB1046PF0572 | DOWEL PIN |
| 573 | PSB1046PF0573 | HALF-NUT PLATE |
| 574 | PSB1046PF0574 | HALF-NUT ASSEMBLY |
| 575 | PCAP07M | CAP SCREW M6-1 X 30 |
| 576 | PSS28M | SET SCREW M6-1 X 30 |
| 577 | PSB1046PF0577 | PLUG 1/4" NPT |
| 578 | PSB1046PF0578 | APRON TOP PLATE |
| 579 | PSB1046PF0579 | OIL SEAL 30 X 40 X 5 |
| 580 | PSB1046PF0580 | SLEEVE |
| 581 | PORG045 | O-RING 44.4 X 3.1 G45 |
| 582 | PSB1046PF0582 | THRUST BEARING 3047-NTB/AS2 |
| 583 | PSB1046PF0583 | GEARED PINION SHAFT 18T |
| 584 | PSB1046PF0584 | CASTING PLUG |
| 585 | PSB1046PF0585 | COLLAR |
| 586 | PCAP26M | CAP SCREW M6-1 X 12 |
| 587 | PRP76M | ROLL PIN 4 X 16 |
| 588 | PSB1046PF0588 | BRACKET SHAFT |
| 589 | PCAP38M | CAP SCREW M5-.8 X 25 |
| 590 | PSB1046PF0590 | SLOTTED DOWEL PIN |
| 591 | PSB1046PF0591 | CAPTIVE PIN |
| 592 | PSB1046PF0592 | EXTENSION SPRING |
| 593 | PSS91M | SET SCREW M6-1 X 14 |
| 594 | PLN03M | LOCK NUT M6-1 |
| 595 | PSB1046PF0595 | BRACKET |
| 596 | PK33M | KEY 5 X 5 X 45 |
| 597 | PSB1046PF0597 | WORM SHAFT |
| 598 | PSB1046PF0598 | WORM GEAR |
| 599 | PSB1046PF0599 | CLUTCH |
| 600 | PSB1046PF0600 | CLUTCH GEAR 36T |
| 601 | PSB1046PF0601 | PIVOT ARM |
| 602 | PSB1046PF0602 | SPRING CUP |
| 603 | PSB1046PF0603 | COMPRESSION SPRING |

# Apron Parts List

| REF | PART # | DESCRIPTION |
|---|---|---|
| 604 | PSB1046PF0604 | SPRING CUP |
| 605 | PRP04M | ROLL PIN 4 X 24 |
| 606 | PSB1046PF0606 | TRIP ROD |
| 607 | PSB1046PF0607 | TRIP ROD SPACER |
| 608 | PSB1046PF0608 | COMPRESSION SPRING |
| 609 | PSB1046PF0609 | TRIP ROD OUTER SPACER |
| 610 | PLN09M | LOCK NUT M12-1.75 |
| 611 | PSB1046PF0611 | THRUST BEARING NTB1528/AS2 |
| 612 | PSB1046PF0612 | FLANGED BEARING |
| 613 | PSB1046PF0613 | COMPRESSION PLATE |
| 614 | PSB1046PF0614 | DOWEL PIN |
| 615 | PRP05M | ROLL PIN 5 X 30 |
| 616 | PSB1046PF0616 | WORM SHAFT FLAT WASHER 10MM |
| 617 | PLN05M | LOCK NUT M10-1.5 |
| 618 | PSB1046PF0618 | DOMED NUT |
| 619 | PRP04M | ROLL PIN 4 X 24 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 620 | PRP02M | ROLL PIN 3 X 16 |
| 621 | PSB1046PF0621 | THREADED SHAFT |
| 622 | PSB1046PF0622 | COMPRESSION PLATE FLAT WASHER |
| 623 | PRP105M | ROLL PIN 3 X 24 |
| 624 | PSB1046PF0624 | COUPLER |
| 625 | PSB1046PF0625 | STEPPED SHAFT |
| 626 | P0RP018 | O-RING 17.8 X 2.4 P18 |
| 627 | PSB1046PF0627 | SHAFT END CAP |
| 628 | PFH74M | FLAT HD CAP SCR M5-.8 X 16 |
| 629 | PRP10M | ROLL PIN 5 X 36 |
| 630 | PSB1046PF0630 | KNURLED KNOB |
| 631 | PSB1046PF0631 | PLUNGER |
| 632 | PSB1046PF0632 | COMPRESSION SPRING |
| 633 | PSS15M | SET SCREW M12-1.75 X 12 |
| 634 | PSB1046PF0634 | SHAFT SLEEVE |


# End Gears




| REF | PART # | DESCRIPTION |
|---|---|---|
| 701 | PB25M | HEX BOLT M12-1.75 X 25 |
| 702 | PSB1046PF0702 | GEAR FLAT WASHER |
| 703 | PSB1046PF0703 | GEAR 24T (SB1046PF-48PF) |
| 703 | PSB1056F0703 | GEAR 24T (SB1056F-58F) |
| 704 | PSB1046PF0704 | PIVOT ARM (SB1046PF-48PF) |
| 704 | PSB1056F0704 | PIVOT ARM (SB1056F-58F) |
| 705 | PK166M | KEY 7 X 7 X 15 |
| 706 | PN32M | HEX NUT M14-2 |
| 707 | PSB1046PF0707 | GEAR FLAT WASHER |
| 708 | PR25M | INT RETAINING RING 47MM |
| 709 | P6005ZZ | BALL BEARING 6005ZZ |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 710 | PSB1046PF0710 | SPACER |
| 711 | PSB1046PF0711 | GEAR 44T/56T (SB1046PF-48PF) |
| 711 | PSB1056F0711 | GEAR 44T/56T (SB1056F-58F) |
| 712 | PSB1046PF0712 | SHAFT SLEEVE |
| 713 | PSB1046PF0713 | T-HEAD SHAFT |
| 714 | PK109M | KEY 7 X 7 X 35 |
| 715 | PSB1046PF0715 | STUD-FT M14-2 X 110 |
| 716 | PSB1046PF0716 | GEAR 57T (SB1046PF-48PF) |
| 716 | PSB1056F0716 | GEAR 57T (SB1056F-58F) |
| 717 | PSB1046PF0717 | GEAR SPACER |


# Motor & Headstock Oil System




# Motor & Headstock Oil System Parts List

| REF | PART # | DESCRIPTION |
|---|---|---|
| 801 | PSB1046PF0801 | OIL HOSE 5/8" |
| 802 | PSB1046PF0802 | OIL HOSE FITTING 5/8" NPT |
| 803 | PSB1046PF0803 | EXTENSION SPRING |
| 804 | PSB1046PF0804 | RETAINING SCREW |
| 805 | PSB1046PF0805 | PUMP HOUSING |
| 806 | PSB1046PF0806 | PUMP IMPELLER |
| 807 | PR05M | EXT RETAINING RING 15MM |
| 808 | PW01M | FLAT WASHER 8MM |
| 809 | PN03M | HEX NUT M8-1.25 |
| 810 | PCAP79M | CAP SCREW M5-.8 X 35 |
| 811 | PSB1046PF0811 | OIL PUMP BACK PLATE |
| 812 | PFH02M | FLAT HD SCR M6-1 X 12 |
| 813 | PBHS38M | BUTTON HD CAP SCR M5-.8 X 8 |
| 814 | PSB1046PF0814 | OIL TANK |
| 815 | PSB1046PF0815 | OIL TANK DRAIN PIPE |
| 816 | PSB1046PF0816 | IDLER ARM |
| 817 | PR21M | INT RETAINING RING 35MM |
| 818 | P6202ZZ | BALL BEARING 6202ZZ |
| 819 | PSB1046PF0819 | SPACER |
| 820 | PSB1046PF0820 | OIL SEAL 18 X 37 X 5MM |
| 821 | PSB1046PF0821 | IDLER PULLEY |
| 822 | PVA38 | V-BELT A38 |
| 823 | PSB1046PF0823 | PUMP PULLEY |
| 824 | PSB1046PF0824 | PUMP INPUT SHAFT |
| 825 | PK29M | KEY 4 X 4 X 8 |
| 826 | PK07M | KEY 6 X 6 X 20 |
| 827 | PR29M | INT RETAINING RING 32MM |
| 828 | PSB1046PF0828 | IDLER PULLEY SHAFT |
| 829 | P6201ZZ | BALL BEARING 6201ZZ |
| 830 | PR03M | EXT RETAINING RING 12MM |
| 831 | PSB1046PF0831 | MOTOR MOUNT SHAFT 32 X 625MM |
| 832 | PSB1046PF0832 | MOTOR 15HP 440V 3PH 60HZ |
| 832-1 | PSB1046PF0832-1 | MOTOR FAN COVER |
| 832-2 | PSB1046PF0832-2 | MOTOR FAN |
| 832-3 | PSB1046PF0832-3 | MOTOR JUNCTION BOX |
| 832-4 | PSB1046PF0832-4 | FRONT MOTOR BEARING |
| 832-5 | PSB1046PF0832-5 | REAR MOTOR BEARING |
| 833 | PVA79 | V-BELT A79 (SB1046PF-48PF) |
| 833 | PVA75 | V-BELT A75 (SB1056F-58F) |
| 834 | PSB1046PF0834 | MOTOR PULLEY |
| 835 | PSB1046PF0835 | PULLEY FLAT WASHER 12 X 45 X 5 |
| 836 | PCAP64M | CAP SCREW M10-1.5 X 25 |
| 837 | PN13M | HEX NUT M16-2 |
| 838 | PSB1046PF0838 | THREADED ROD M16-2 |
| 839 | PSB1046PF0839 | FLAT WASHER 16.5 X 40 |
| 840 | PSB1046PF0840 | RUBBER SPACER |
| 841 | PB31M | HEX BOLT M10-1.5 X 40 |
| 842 | PW04M | FLAT WASHER 10MM |
| 843 | PSB1046PF0843 | MOTOR MOUNT PLATE |
| 844 | PCAP64M | CAP SCREW M10-1.5 X 25 |
| 845 | PN02M | HEX NUT M10-1.5 |
| 846 | PSB1046PF0846 | REAR MOTOR ACCESS PLATE |
| 847 | PBHS09M | BUTTON HD CAP SCR M6-1 X 12 |
| 848 | PSB1046PF0848 | ELECTRICAL BOX ASSEMBLY |
| 849 | PSB1046PF0849 | JUNCTION BOX |
| 850 | PCAP06M | CAP SCREW M6-1 X 25 |
| 851 | PBHS38M | BUTTON HD CAP SCR M5-.8 X 8 |
| 852 | PN02M | HEX NUT M10-1.5 |
| 853 | PSB1046PF0853 | PLUG 1/4" NPT |
| 854 | PCAP11M | CAP SCREW M8-1.25 X 16 |
| 855 | PSB1046PF0855 | HOSE COUPLER 1" NPT |
| 856 | PSB1046PF0856 | ELBOW 1" NPT |
| 857 | PSB1046PF0857 | HOSE CLAMP 3/4" |
| 858 | PSB1046PF0858 | HOSE CONNECTOR 1" X 75MM |
| 859 | PSB1046PF0859 | OIL RETURN HOSE |
| 860 | PSB1046PF0860 | HOSE CLIP |
| 861 | PSB1046PF0861 | HOSE CLIP |
| 862 | PN04M | HEX NUT M4-.7 |
| 863 | PSB1042PF1160 | END COVER SAFETY SWITCH TM1307 |
| 864 | PS65M | PHLP HD SCR M4-.7 X 40 |

# Saddle 1


914
901
902
959
960
958
962
974
961
931
904
915
903
908
909
901
906
905
964
910
963
907
911
912
965
916
917
908
919
920
921
963
913
918
966
923
967
963
925
922
924
920
921
963
944
968
963
924
925
963
968
972
926
927
928
958
931
930
929
942
901
901
942
932
933
934
932
943
973
971
935
969
970
936
901
973
971
941
939
940
901
960
931
930
937
938
959


# Saddle 2


957
956
955
944
951
947
949
949
968
947
952
950
946
948
953
954
Headstock
(Viewed from beneath)

# Saddle Parts List

| REF | PART # | DESCRIPTION |
|---|---|---|
| 901 | PSB1046PF0901 | GIB ADJUST SCREW |
| 902 | PSB1046PF0902 | CROSS SLIDE |
| 903 | PSB1046PF0903 | COMPOUND REST PIVOT 25 X 40 |
| 904 | PSB1046PF0904 | COMPOUND REST T-BOLT |
| 905 | PSB1046PF0905 | CROSS SLIDE GIB |
| 906 | PSB1046PF0906 | CROSS SLIDE WAY WIPER |
| 907 | PSB1046PF0907 | CROSS SLIDE WAY WIPER PLATE |
| 908 | PSB1046PF0908 | THRUST BEARING NTB/AS2 1730 |
| 909 | PSB1046PF0909 | WEDGE 7 X 7 X 30 |
| 910 | PSB1046PF0910 | LEADSCREW HALF NUT |
| 911 | PRP28M | ROLL PIN 5 X 40 |
| 912 | PSB1046PF0912 | CROSS SLIDE LEADSCREW |
| 913 | PK179M | KEY 3 X 3 X 115 |
| 914 | PSB1046PF0914 | COOLANT NOZZLE 3/8 PT X 24" |
| 915 | PSB1046PF0915 | COOLANT STAND PIPE ASSY 3/8 PT |
| 916 | PSB1046PF0916 | BEARING COVER |
| 917 | PSB1046PF0917 | SPACER |
| 918 | PSB1046PF0918 | LEADSCREW BRACKET |
| 919 | PSB1046PF0919 | SADDLE CASTING |
| 920 | PSB1046PF0920 | SADDLE STRAIGHT WAY WIPER |
| 921 | PSB1046PF0921 | SADDLE STRAIGHT WAY WIPER PLATE |
| 922 | PSB1046PF0922 | OIL FILL CAP |
| 923 | PSB1046PF0923 | TAPER PIN #6 X 2-1/2" |
| 924 | PSB1046PF0924 | SADDLE V-WAY WIPER |
| 925 | PSB1046PF0925 | SADDLE V-WAY WIPER PLATE |
| 926 | PSB1046PF0926 | CROSS SLIDE PINION SHAFT 16T |
| 927 | PK96M | KEY 3 X 3 X 20 |
| 928 | PSB1046PF0928 | SHAFT CAP M16-2 X 5 |
| 929 | PSB1046PF0929 | PINION SHAFT BRACKET |
| 930 | PSB1046PF0930 | COMPRESSION SPRING |
| 931 | PSTB001 | STEEL BALL 1/4 |
| 932 | PSB1046PF0932 | THRUST BEARING NTB/AS2 2035 |
| 933 | PSB1046PF0933 | SPACER |
| 934 | PSB1046PF0934 | PINION SHAFT END CAP |
| 935 | PSB1046PF0935 | GRADUATED DIAL BASE RING |
| 936 | PSB1046PF0936 | GRADUATED DIAL |
| 937 | PSB1046PF0937 | HANDWHEEL |
| 938 | PSB1046PF0938 | HANDWHEEL END CAP |
| 939 | PSB1046PF0939 | HANDWHEEL HANDLE |
| 940 | PSB1046PF0940 | HANDLE CAP SCREW |
| 941 | PSB1046PF0941 | FRONT SADDLE GIB SUPPORT |
| 942 | PSB1046PF0942 | SADDLE GIB |
| 943 | PSB1046PF0943 | REAR SADDLE GIB SUPPORT |
| 944 | PSB1046PF0944 | ONE-SHOT OILER ASSEMBLY |
| 946 | PSB1046PF0946 | GEAR 16T/36T |
| 947 | PSB1046PF0947 | COUPLER 1/8"-4MM |
| 948 | PSB1046PF0948 | ALUMINUM OIL TUBE 4 X 258MM |
| 949 | PSB1046PF0949 | ELBOW COUPLER 1/8"-4MM |
| 950 | PSB1046PF0950 | ALUMINUM OIL TUBE 4 X 121MM |
| 951 | PSB1046PF0951 | CAPTIVE PIN |
| 952 | PSB1046PF0952 | COUPLER 1/8"-6MM |
| 953 | PSB1046PF0953 | ALUMINUM OIL TUBE 6 X 175MM |
| 954 | PSB1046PF0954 | OIL FILTER 6MM |
| 955 | PSB1046PF0955 | CLAMP PLATE |
| 956 | PSS44M | SET SCREW M8-1.25 X 40 |
| 957 | PCAP187M | CAP SCREW M12-1.75 X 85 |
| 958 | PLUBE001 | TAP-IN BALL OILER 1/4 |
| 959 | PSS12M | SET SCREW M6-1 X 25 |
| 960 | PCAP13M | CAP SCREW M8-1.25 X 30 |
| 961 | PW04M | FLAT WASHER 10MM |
| 962 | PN02M | HEX NUT M10-1.5 |
| 963 | PBHS06M | BUTTON HD CAP SCR M5-.8 X 12 |
| 964 | PCAP06M | CAP SCREW M6-1 X 25 |
| 965 | PSB1046PF0965 | NUT M16 |
| 966 | PCAP38M | CAP SCREW M5-.8 X 25 |
| 967 | PSB1046PF0967 | CAP SCREW M10-1.25 X 80 |
| 968 | PSS03M | SET SCREW M6-1 X 8 |
| 969 | PCAP14M | CAP SCREW M8-1.25 X 20 |
| 970 | PSBHS35M | BUTTON HD CAP SCR M5-.8 X 10 |
| 971 | PCAP12M | CAP SCREW M8-1.25 X 40 |
| 972 | PFH05M | FLAT HD SCR M5-.8 X 12 |
| 973 | PSB1046PF0973 | GIB RETAINING CLIP |
| 974 | PSS09M | SET SCREW M8-1.25 X 20 |


# Tool Post & Compound Rest




| REF | PART # | DESCRIPTION |
|---|---|---|
| 1000 | PSB1046PF1000 | 4-WAY TOOL POST ASSEMBLY |
| 1001 | PSB1046PF1001 | TOOL POST LEVER |
| 1002 | PSB1046PF1002 | TOOL POST LEVER HUB |
| 1003 | PSB1046PF1003 | HUB THRUST WASHER |
| 1004 | PSB1046PF1004 | TOOL POST BOLT |
| 1005 | PSB1046PF1005 | POST BODY |
| 1006 | PSB1046PF1006 | POST SHAFT |
| 1007 | PSB1046PF1007 | TOOL POST PLUNGER |
| 1008 | PSB1046PF1008 | COMPRESSION SPRING |
| 1009 | PSS09M | SET SCREW M8-1.25 X 20 |
| 1010 | PSB1046PF1010 | TOOL POST T-SLIDER |
| 1012A | PSB1046PF1012A | COMPOUND REST ASSEMBLY (SB1046PF-48PF) |
| 1012A | PSB1056F1012A | COMPOUND REST ASSEMBLY (SB1056F-58F) |
| 1012 | PSB1046PF1012 | COMPOUND REST (SB1046PF-48PF) |
| 1012 | PSB1056F1012 | COMPOUND REST (SB1056F-58F) |
| 1013 | PSS06M | SET SCREW M8-1.25 X 16 |
| 1014 | PSTB001 | STEEL BALL 1/4 |
| 1015 | PLUBE001 | TAP-IN BALL OILER 1/4 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 1016 | PSB1046PF1016 | GIB ADJUSTMENT SCREW |
| 1017 | PSB1046PF1017 | COMPOUND REST GIB |
| 1018 | PSB1046PF1018 | COMPOUND REST BASE (SB1046PF-48PF) |
| 1018 | PSB1056F1018 | COMPOUND REST BASE (SB1056F-58F) |
| 1019 | PSS19M | SET SCREW M8-1.25 X 30 |
| 1020 | PSB1046PF1020 | COMPOUND REST LEADSCREW W/NUT |
| 1022 | PK47M | KEY 4 X 4 X 15 |
| 1023 | PSB1046PF1023 | THRUST BEARING NTB/AS2 2035 |
| 1024 | PSB1046PF1024 | LEADSCREW BRACKET |
| 1025 | PSB1046PF1025 | COMPRESSION SPRING |
| 1026 | PCAP02M | CAP SCREW M6-1 X 20 |
| 1027 | PSB1046PF1027 | GRADUATED DIAL BASE |
| 1028 | PSB1046PF1028 | GRADUATED DIAL |
| 1029 | PSB1046PF1029 | HANDWHEEL |
| 1030 | PSB1046PF1030 | HANDWHEEL HANDLE |
| 1032 | PSB1046PF1032 | HANDWHEEL END CAP |
| 1033 | PSS25M | SET SCREW M6-1 X 20 |
| 1034 | PSB1046PF1034 | HANDWHEEL HANDLE |


# Bed & Shafts


1104
1106
1105
1111
1129
1115
1137
1116
1117
1158
1139
1140
1145
1130
1107
1108
1102
1103
1116
1134
1135
1146
1109
1136
1147
1101
1150
1118
1148
1149
1155
1156
1157
1158
1159
1110
1108
1107
1119
1120
1126
1125
1128
1127
1171
1160
1161
1103
1168
1167
1166
1170
1169
SB1048PF
ONLY
1172
1173
1174
1176
1175
1177
1178
1179
1176
1181
1180
1180
1181
1176
1182
SB1047PF,
SB1058F
ONLY
1172
1173
1174
1176
1175
1177
1178
1179
1176
1181
1180
1181
1176
1182

# Bed & Shafts Parts List

| REF | PART # | DESCRIPTION |
|---|---|---|
| 1101 | PSB1056F1101 | LATHE BED 40" (SB1056F) |
| 1101 | PSB1046PF1101 | LATHE BED 60" (SB1046PF, -57F) |
| 1101 | PSB1047PF1101 | LATHE BED 80" (SB1047PF, -58F) |
| 1101 | PSB1048PF1101 | LATHE BED 120" (SB1048PF) |
| 1102 | PSB1056F1102 | LATHE BED GAP (SB1056F) |
| 1102 | PSB1046PF1102 | LATHE BED GAP (SB1046PF, -57F) |
| 1102 | PSB1047PF1102 | LATHE BED GAP (SB1047PF, -58F) |
| 1102 | PSB1048PF1102 | LATHE BED GAP (SB1048PF) |
| 1103 | PN09M | HEX NUT M12-1.75 |
| 1104 | PSB1046PF1104 | BED STOP BOLT |
| 1105 | PW08M | FLAT WASHER 16MM |
| 1106 | PB80M | HEX BOLT M16-2 X 55 |
| 1107 | PCAP06M | CAP SCREW M6-1 X 25 |
| 1108 | PRP08M | ROLL PIN 6 X 30 |
| 1109 | PSB1056F1109 | BED RACK (SB1056F) |
| 1109 | PSB1046PF1109 | BED RACK (SB1046PF, -57F) |
| 1109 | PSB1047PF1109 | BED RACK (SB1047PF, -58F) |
| 1109 | PSB1048PF1109 | BED RACK (SB1048PF) |
| 1110 | PSB1056F1110 | GAP RACK (SB1056F) |
| 1110 | PSB1046PF1110 | GAP RACK (SB1046PF, -57F) |
| 1110 | PSB1047PF1110 | GAP RACK (SB1047PF, -58F) |
| 1110 | PSB1048PF1110 | GAP RACK (SB1048PF) |
| 1111 | PSB1046PF1111 | LEADSCREW LOCK NUT |
| 1115 | PSS03M | SET SCREW M6-1 X 8 |
| 1116 | P51105 | THRUST BEARING 51105 |
| 1117 | PSB1046PF1117 | SHAFT END BRACKET |
| 1118 | PSB1056F1118 | LEADSCREW (SB1056F) |
| 1118 | PSB1046PF1118 | LEADSCREW (SB1046PF, -57F) |
| 1118 | PSB1047PF1118 | LEADSCREW (SB1047PF, -58F) |
| 1118 | PSB1048PF1118 | LEADSCREW (SB1048PF) |
| 1119 | PK99M | KEY 6 X 6 X 15 |
| 1120 | PSB1046PF1120 | LEADSCREW SPRING HOUSING |
| 1125 | PSB1046PF1125 | LEADSCREW SPRING |
| 1126 | PSB1046PF1126 | KEYED LEADSCREW FLAT WASHER |
| 1127 | PSB101609327 | SHEAR PIN |
| 1128 | PSB1046PF1128 | LEADSCREW FLANGE BUSHING |
| 1129 | PSB1046PF1129 | FEED ROD END CAP |
| 1130 | PLUBE001 | TAP-IN BALL OILER 1/4 |
| 1134 | PSB1046PF1134 | LOCK COLLAR |
| 1135 | PSS01M | SET SCREW M6-1 X 10 |
| 1136 | PSB1056F1136 | FEED ROD (SB1056F) |
| 1136 | PSB1046PF1136 | FEED ROD (SB1046PF, -57F) |
| 1136 | PSB1047PF1136 | FEED ROD (SB1047PF, -58F) |
| 1136 | PSB1048PF1136 | FEED ROD (SB1048PF) |
| 1137 | PSS15M | SET SCREW M12-1.75 X 12 |
| 1138 | PSB1046PF1138 | COMPRESSION SPRING |
| 1139 | PSTB003 | STEEL BALL 3/8" |
| 1140 | PCAP84M | CAP SCREW M10-1.5 X 35 |
| 1145 | PSB1046PF1145 | TAPER PIN 7 X 50 |
| 1146 | PSB1046PF1146 | SPINDLE ON/OFF LEVER HUB |
| 1147 | PSB1046PF1147 | STEP PIN |
| 1148 | PSB1046PF1148 | SPINDLE ON/OFF LEVER |
| 1149 | PCAP01M | CAP SCREW M6-1 X 16 |
| 1150 | PSB1046PF1150 | SPINLE LEVER SELECTOR BRACKET |
| 1155 | PSB1046PF1155 | SPINDLE ROD SLEEVE |
| 1156 | PSB1046PF1156 | SPINDLE ROD COMPRESSION SPRING |
| 1157 | PSB1046PF1157 | SPINDLE ROD SPRING COVER |
| 1158 | PR37M | EXT RETAINING RING 32MM |
| 1159 | PSB1056F1159 | SPINDLE ROD (SB1056F) |
| 1159 | PSB1046PF1159 | SPINDLE ROD (SB1046PF, -57F) |
| 1159 | PSB1047PF1159 | SPINDLE ROD (SB1047PF, -58F) |
| 1159 | PSB1048PF1159 | SPINDLE ROD (SB1048PF) |
| 1160 | PSS20M | SET SCREW M8-1.25 X 8 |
| 1161 | PSB1046PF1161 | SPINDLE ROD LEVER HUB |
| 1166 | PSB1046PF1166 | SPINDLE ROD LEVER |
| 1167 | PEC015M | E-CLIP 8MM |
| 1168 | PSB1046PF1168 | SPINDLE SWITCH PIVOT ARM |
| 1169 | PSB1046PF1169 | SPINDLE SWITCH PIVOT PIN |
| 1170 | PSS14M | SET SCREW M8-1.25 X 12 |
| 1171 | PSB1046PF1171 | SPINDLE SWITCH LINKAGE |
| 1172 | PSB1047PF1172 | STEP SHAFT (SB1047PF, -58F) |
| 1172 | PSB1048PF1172 | STEP SHAFT (SB1048PF) |
| 1173 | PCAP128M | CAP SCREW M8-1.25 X 70 |
| 1174 | PSB1047PF1174 | BED CLAMP (SB1047PF, -58F) |
| 1174 | PSB1048PF1174 | BED CLAMP (SB1048PF) |
| 1175 | PSS09M | SET SCREW M8-1.25 X 20 |
| 1176 | PSB1047PF1176 | PLUNGER |
| 1177 | PSB1047PF1177 | LOWER CLAMP PLATE |
| 1178 | PSS06M | SET SCREW M8-1.25 X 16 |
| 1179 | PSB1047PF1179 | SHAFT SUPPORT (SB1047PF, -58F) |
| 1179 | PSB1048PF1179 | SHAFT SUPPORT (SB1048PF) |
| 1180 | PR12M | EXT RETAINING RING 35MM |
| 1181 | PSS20M | SET SCREW M8-1.25 X 8 |
| 1182 | PSB1047PF1182 | BUSHING |

# Stands & Panels (SB1046PF-47PF, SB1056F-58F)




# Stand & Panels Parts List (SB1046PF-47PF, SB1056F-58F)

| REF | PART # | DESCRIPTION |
|---|---|---|
| 1201 | PSB1056F1201 | BRAKE PEDAL SHAFT (SB1056F) |
| 1201 | PSB1046PF1201 | BRAKE PEDAL SHAFT (SB1046PF, -57F) |
| 1201 | PSB1047PF1201 | BRAKE PEDAL SHAFT (SB1047PF, -58F) |
| 1202 | PSB1056F1202 | BRAKE PEDAL (SB1056F) |
| 1202 | PSB1046PF1202 | BRAKE PEDAL (SB1046PF, -57F) |
| 1202 | PSB1047PF1202 | BRAKE PEDAL (SB1047PF, -58F) |
| 1203 | PSB1046PF1203 | PEDAL SHAFT LOCK COLLAR |
| 1204 | PCAP01M | CAP SCREW M6-1 X 16 |
| 1205 | PCAP04M | CAP SCREW M6-1 X 10 |
| 1206 | PW03M | FLAT WASHER 6MM |
| 1207 | PSB1056F1207 | CENTER PANEL (SB1056F) |
| 1207 | PSB1046PF1207 | CENTER PANEL (SB1046PF, -57F) |
| 1207 | PSB1047PF1207 | CENTER PANEL (SB1047PF, -58F) |
| 1208 | PSB1056F1208 | CHIP DRAWER (SB1056F) |
| 1208 | PSB1046PF1208 | CHIP DRAWER (SB1046PF, -57F) |
| 1208 | PSB1047PF1208 | CHIP DRAWER (SB1047PF, -58F) |
| 1209 | PSB1046PF1209 | CENTER PANEL BRACKET |
| 1210 | PBHS38M | BUTTON HD CAP SCR M5-.8 X 8 |
| 1211 | PSB1046PF1211 | SHAFT CLUTCH COVER (SB1046PF-47PF) |
| 1211 | PSB1056F1211 | SHAFT CLUTCH COVER (SB1056F-58F) |
| 1212 | PSB1046PF1212 | BRAKE LINKAGE GUARD |
| 1213 | PSB1046PF1213 | BACKSPLASH MOUNT (SB1046PF-47PF) |
| 1213 | PSB1056F1213 | BACKSPLASH MOUNT (SB1056F-58F) |
| 1214 | PSB1046PF1214 | CHUCK GUARD PIVOT BRACKET |
| 1215 | PB56M | CAP SCREW M10-1.5 X 20 |
| 1216 | PSS14M | SET SCREW M8-1.25 X 12 |
| 1217 | PN04M | HEX NUT M4-.7 |
| 1218 | PLW03M | LOCK WASHER 6MM |
| 1219 | PCAP26M | CAP SCREW M6-1 X 12 |
| 1220 | PSB1046PF1220 | SAFETY SWITCH BRACKET |
| 1221 | PSB1046PF1221 | CHUCK GUARD SAFETY SWITCH TZ9212 |
| 1222 | PBHCS38M | BUTTON HD CAP SCR M4-.7 X 40 |
| 1223 | PN03M | HEX NUT M8-1.25 |
| 1224 | PW01M | FLAT WASHER 8MM |
| 1225 | PCAP14M | CAP SCREW M8-1.25 X 20 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 1226 | PSB1056F1226 | BACKSPLASH (SB1056F) |
| 1226 | PSB1046PF1226 | BACKSPLASH (SB1046PF, -57F) |
| 1226 | PSB1047PF1226 | BACKSPLASH (SB1047PF, -58F) |
| 1227 | PSB1046PF1227 | CHUCK GUARD KNOB 1/2-13 |
| 1228 | PN06 | HEX NUT 1/2-13 |
| 1229 | PB52 | HEX BOLT 1/2-13 X 1 |
| 1230 | PSB1046PF1230 | CHUCK GUARD PIVOT ROD |
| 1231 | PSB1046PF1231 | CHUCK SAFETY GUARD |
| 1232 | PCAP26M | CAP SCREW M6-1 X 12 |
| 1233 | PSS34M | SET SCREW M5-.8 X 16 |
| 1234 | PSB1046PF1234 | COOLANT CHUTE |
| 1235 | PSB1056F1235 | HOSE 3/8 X 72" (SB1056F) |
| 1235 | PSB1046PF1235 | HOSE 3/8 X 78" (SB1046PF, -57F) |
| 1235 | PSB1047PF1235 | HOSE 3/8 X 96" (SB1047PF, -58F) |
| 1236 | PSB1046PF1236 | PIPE NIPPLE 3/8 PT X 3/8 PH |
| 1237 | PSB1046PF1237 | COOLANT PUMP ASSEMBLY |
| 1238 | PSB1046PF1238 | COOLANT TANK (SB1046PF-48PF) |
| 1238 | PSB1056F1238 | COOLANT TANK (SB1056F-58F) |
| 1239 | PSB1046PF1239 | COOLANT TANK COVER |
| 1240 | PBHS11M | BUTTON HD CAP SCREW M6-1 X 10 |
| 1241 | PSB1056F1241 | RIGHT SPLASH TRAY (SB1056F) |
| 1241 | PSB1046PF1241 | RIGHT SPLASH TRAY (SB1046PF, -57F) |
| 1241 | PSB1047PF1241 | RIGHT SPLASH TRAY (SB1047PF, -58F) |
| 1242 | PSB1046PF1242 | LEFT SPLASH TRAY |
| 1243 | PSB1046PF1243 | MOTOR ACCESS COVER |
| 1244 | PSB1046PF1244 | BACKSPLASH MOUNTING POST |
| 1245 | PSB1046PF1245 | CONTROL PANEL |
| 1246 | PSB1046PF1246 | LEFT CABINET |
| 1247 | PSB1046PF1247 | RIGHT CABINET |
| 1248 | PSB1046PF1248 | LEVELING FOOT |
| 1249 | PB80M | HEX BOLT M16-2 X 55 |
| 1250 | PSB1046PF1250 | CHUCK GUARD WINDOW PLASTIC |
| 1251 | PBHS09M | BUTTON HD CAP SCR M6-1 X 12 |
| 1252 | PSB1046PF1252 | END GEAR COVER ASSY (SB1046PF-48PF) |
| 1252 | PSB1056F1252 | END GEAR COVER ASSY (SB1056F-58F) |


# Brake




| REF | PART # | DESCRIPTION |
|---|---|---|
| 1303 | PEC09M | E-CLIP 6MM |
| 1305 | PSB1046PF1305 | CLEVIS PIN 6MM |
| 1306 | PSB1046PF1305 | CLEVIS PIN 6MM |
| 1307 | PSB1046PF1307 | SPACER |
| 1308 | PB01M | HEX BOLT M10-1.5 X 30 |
| 1309 | PSB1046PF1309 | ROCKER ARM |
| 1310 | PW01M | FLAT WASHER 8MM |
| 1314 | PW01M | FLAT WASHER 8MM |
| 1315 | PLN05M | LOCK NUT M10-1.5 |
| 1316 | PSB1046PF1316 | ROCKER ARM MOUNTING BRACKET |
| 1317 | PCAP07M | CAP SCREW M6-1 X 30 |
| 1318 | PLW03M | LOCK WASHER 6MM |
| 1319 | PSB1046PF1319 | SHIELD PLATE |
| 1320 | PSB1046PF1320 | BRAKE DRUM |
| 1324 | PSB1046PF1324 | BRAKE SHOE SET 2PC |
| 1325 | PSB1046PF1325 | EXTENSION SPRING |
| 1326 | PEC015M | E-CLIP 8MM |
| 1327 | PSB1046PF1327 | BRAKE SHOE ANCHOR PIN |
| 1328 | PSB1046PF1328 | BRAKE ACTUATOR |
| 1329 | PSB1046PF1329 | ACTUATOR PIN |
| 1330 | PSB1046PF1330 | ACTUATOR ROLLER |
| 1334 | PSB1046PF1334 | ACTUATOR BUSHING |
| 1335 | PORP010 | O-RING 9.8 X 1.9 P10 |
| 1336 | PR02M | EXT RETAINING RING 14MM |
| 1337 | PSB1046PF1337 | MOUNTING BLOCK |
| 1338 | PSB1046PF1338 | BRAKE ACTUATOR ROD (SB1046PF-48PF) |
| 1338 | PSB1056F1338 | BRAKE ACTUATOR ROD (SB1056F-58F) |
| 1339 | PSB1046PF1339 | ROD RETAINING PLATE |
| 1340 | PCAP40M | CAP SCREW M8-1.25 X 35 |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 1344 | PSB1046PF1344 | EXTENSION SPRING |
| 1345 | PSB1046PF1345 | SPRING ANCHOR PIN 5 X 30 |
| 1346 | PSB1046PF1346 | SPINDLE LEVER/BRAKE CONTROL ARM |
| 1349 | PSB1046PF1349 | CONTROL ARM RETAINING PLATE |
| 1350 | PLN04M | LOCK NUT M8-1.25 |
| 1353 | PN03M | HEX NUT M8-1.25 |
| 1355 | PSB1046PF1355 | BRAKE PEDAL PIN |
| 1356 | PSB1046PF1356 | PEDAL PIN SHOULDER BOLT |
| 1357 | PSB1046PF1357 | ROLLER STANDOFF |
| 1358 | PSB1046PF1358 | ROLLER |
| 1359 | PCAP31M | CAP SCREW M8-1.25 X 25 |
| 1360 | PSB1046PF1360 | CONTROL ARM BRACKET |
| 1364 | PSB1046PF1364 | STOP PLATE |
| 1365 | PSB1046PF1365 | STOP PLATE SHIELD |
| 1366 | PCAP04M | CAP SCREW M6-1 X 10 |
| 1367 | PB116M | HEX BOLT M10-1.5 X 45 |
| 1368 | PSB1046PF1368 | LOWER CLUTCH ACTUATOR ROD (SB1046PF-48PF) |
| 1368 | PSB1056F1368 | LOWER CLUTCH ACTUATOR ROD (SB1056F-58F) |
| 1369 | PSB1046PF1369 | ACTUATOR ROD JAM NUT M12-1.75 |
| 1370 | PSB1046PF1370 | ACTUATOR ROD COUPLER M12-1.75 |
| 1374 | PN09M | HEX NUT M12-1.75 |
| 1375 | PSB1046PF1375 | UPPER CLUTCH ACTUATOR ROD (SB1046PF-48PF) |
| 1375 | PSB1056F1375 | UPPER CLUTCH ACTUATOR ROD (SB1056F-58F) |
| 1376 | PRP39M | ROLL PIN 4 X 20 |
| 1377 | PSB1046PF1377 | UNIVERSAL JOINT ASSEMBLY |
| 1378 | PSB1046PF1378 | BRAKE DRUM FLAT WASHER |
| 1379 | PRP02M | ROLL PIN 3 X 16 |
| 1380 | PLW03M | LOCK WASHER 6MM |
| 1381 | PCAP02M | CAP SCREW M6-1 X 20 |


# Tailstock




| REF | PART # | DESCRIPTION |
|---|---|---|
| 1400 | PSB1046PF1400 | TAILSTOCK ASSEMBLY |
| 1401 | PSB1046PF1401 | HANDWHEEL HANDLE CAP SCREW |
| 1402 | PSB1046PF1402 | HANDWHEEL HANDLE |
| 1403 | PSS19M | SET SCREW M8-1.25 X 30 |
| 1404 | PSB1046PF1404 | HANDWHEEL CENTER CAP |
| 1405 | PSB1046PF1405 | HANDWHEEL |
| 1406 | PSB1046PF1406 | COMPRESSION SPRING |
| 1407 | PSTB001 | STEEL BALL 1/4 |
| 1408 | PSB1046PF1408 | GRADUATED DIAL |
| 1409 | PSB1046PF1409 | THRUST BEARING 3542AS2 |
| 1410 | PSB1046PF1410 | GRADUATED DIAL BASE |
| 1411 | PCAP02M | CAP SCREW M6-1 X 20 |
| 1412 | PSB1046PF1412 | LEADSCREW W/NUT |
| 1413 | PK10M | KEY 5 X 5 X 12 |
| 1414 | PCAP13M | CAP SCREW M8-1.25 X 30 |
| 1415 | PSB1046PF1415 | QUILL ALIGNMENT GUIDE |
| 1416 | PLUBE001 | TAP-IN BALL OILER 1/4 |
| 1417 | PSB1046PF1417 | TAILSTOCK CASTING |
| 1418 | PSB1046PF1418 | QUILL LOCK LEVER ASSEMBLY |
| 1419 | PCAP04M | CAP SCREW M6-1 X 10 |
| 1420 | PCAP128M | CAP SCREW M8-1.25 X 70 |
| 1421 | PSB1046PF1421 | TAILSTOCK LOCK LEVER ASSEMBLY |
| 1422 | PSB1046PF1422 | TAILSTOCK LOCK LEVER PIN |
| 1423 | PSB1046PF1423 | QUILL |


| REF | PART # | DESCRIPTION |
|---|---|---|
| 1424 | PN29M | HEX NUT M18-2.5 |
| 1425 | PW18M | FLAT WASHER 18MM |
| 1426 | PSB1046PF1426 | OFFSET INDICATOR PLATE |
| 1427 | PSS73M | SET SCREW M10-1.5 X 30 |
| 1428 | PSB1046PF1428 | ALIGNMENT PIN |
| 1429 | PSB1046PF1429 | PIVOT BLOCK |
| 1430 | PBHS16M | BUTTON HD CAP SCR M5-.8 X 16 |
| 1431 | PSB1046PF1431 | V-WAY WIPER PLATE |
| 1432 | PSB1046PF1432 | V-WAY WIPER |
| 1433 | PSB1046PF1433 | STRAIGHT WAY WIPER PLATE |
| 1434 | PSB1046PF1434 | STRAIGHT WAY WIPER |
| 1435 | PSB1046PF1435 | TAILSTOCK BASE (SB1046PF-48PF) |
| 1435 | PSB1056F1435 | TAILSTOCK BASE (SB1056F-58F) |
| 1436 | PW18M | FLAT WASHER 18MM |
| 1437 | PLW12M | LOCK WASHER 18MM |
| 1438 | PSB1046PF1438 | TAILSTOCK ANCHOR BOLT |
| 1439 | PSB1046PF1439 | TAILSTOCK GIB |
| 1440 | PSB1046PF1440 | TAILSTOCK GIB ADJUST SCREW |
| 1441 | PSB1046PF1441 | CLAMP PLATE |
| 1442 | PSB1046PF1442 | TAILSTOCK MOUNTING BOLT |
| 1443 | PSB1046PF1443 | CLAMP BLOCK |
| 1444 | PSB1046PF1444 | TAILSTOCK MOUNTING STUD |
| 1445 | PRP31M | ROLL PIN 6 X 36 |
| 1446 | PSB1046PF1446 | SQUARE DRILLED NUT |

# Thread Dial





| REF | PART # | DESCRIPTION |
|---|---|---|
| 1500 | PSB1046PF1500 | THREAD DIAL ASSEMBLY |
| 1501 | PSB1046PF1501 | DIAL PLATE |
| 1502 | PSB1046PF1502 | PIVOT BOLT |
| 1503 | PSB1046PF1503 | DIAL INDICATOR CASTING |
| 1504 | PSB1046PF1504 | KNURLED KNOB |
| 1505 | PSB1046PF1505 | PIVOT STUD-DE |
| 1507 | PSB1046PF1507 | GEAR SPACER |
| 1508 | PSB1046PF1508 | DIAL GEAR 16T |
| 1509 | PCAP04M | CAP SCREW M6-1 X 10 |
| 1511 | PSS02M | SET SCREW M6-1 X 6 |
| 1512 | PN03M | HEX NUT M8-1.25 |

# Micrometer Stop





| REF | PART # | DESCRIPTION |
|---|---|---|
| 1600 | PSB1046PF1600 | MICROMETER STOP ASSEMBLY |
| 1601 | PCAP71M | CAP SCREW M10-1.5 X 60 |
| 1602 | PRIV001M | STEEL FLUTED RIVET 2 X 5MM |
| 1603 | PSB1046PF1603 | INDICATOR PLATE |
| 1604 | PSB1046PF1604 | MICROMETER DIAL |
| 1605 | PSB1046PF1605 | INDICATOR STOP CASTING |
| 1606 | PSB1046PF1606 | INDICATOR STOP ROD |
| 1607 | PSB1046PF1607 | CLAMP PLATE |
| 1608 | PSS10M | SET SCREW M10-1.5 X 20 |
| 1609 | PSB1046PF1609 | PLUNGER COPPER |
| 1610 | PSS06M | SET SCREW M8-1.25 X 16 |
| 1611 | PSB1046PF1611 | DOG POINT SET SCREW M8-1.25 X 12 |
| 1612 | PSS14M | SET SCREW M8-1.25 X 12 |

# Steady Rest




| REF | PART # | DESCRIPTION |
|---|---|---|
| 1700 | PSB1046PF1700 | STEADY REST ASSEMBLY (SB1046PF-48PF) |
| 1700 | PSB1056F1700 | STEADY REST ASSEMBLY (SB1056F-58F) |
| 1701 | PSB1046PF1701 | FINGER ADJUSTMENT KNOB ASSY |
| 1702 | PSB1046PF1702 | FINGER ASSEMBLY |
| 1703 | PSS20M | SET SCREW M8-1.25 X 8 |
| 1704 | PSB1046PF1704 | CLAMP SCREW KNOB |
| 1705 | PSB1046PF1705 | CLAMP SCREW |
| 1706 | PSB1046PF1706 | CASTING 2PC (SB1046PF-48PF) |
| 1706 | PSB1056F1706 | CASTING 2PC (SB1056F-58F) |
| 1707 | PSB1046PF1707 | DOWEL PIN |
| 1708 | PSB1046PF1708 | DOG PT LEAF SCREW M8-1.25 X 25 |
| 1709 | PSB1046PF1709 | HINGE PIN |
| 1710 | PSB1046PF1710 | HEX NUT M18-2.25 |
| 1711 | PLW12M | LOCK WASHER 18MM |
| 1712 | PSB1046PF1712 | STUD-FT M18-2.25 X 75 |
| 1713 | PSB1046PF1713 | CLAMP PLATE |


# Follow Rest





| REF | PART # | DESCRIPTION |
|---|---|---|
| 1800 | PSB1046PF1800 | FOLLOW REST ASSEMBLY (SB1046PF-48PF) |
| 1800 | PSB1056F1800 | FOLLOW REST ASSEMBLY (SB1056F-58F) |
| 1801 | PSB1046PF1801 | ADJUSTMENT KNOB ASSEMBLY |
| 1802 | PSB1046PF1802 | FINGER ASSEMBLY |
| 1803 | PSS06M | SET SCREW M8-1.25 X 16 |
| 1804 | PSB1046PF1804 | FOLLOW REST CASTING (SB1046PF-48PF) |
| 1804 | PSB1056F1804 | FOLLOW REST CASTING (SB1056F-58F) |
| 1805 | PSB1046PF1708 | DOG PT LEAF SCREW M8-1.25 X 25 |

# Electrical Cabinet & Control Panel

Electrical Cabinet





Control Panel (viewed from behind)




| REF | PART # | DESCRIPTION |
|---|---|---|
| 1900 | PSB1046PF1900 | ELECTRICAL CABINET ASSEMBLY |
| 1901 | PSB1046PF1901 | CONTACTOR AB C23400 |
| 1902 | PSB1046PF1902 | OL RELAY AB 21-25A |
| 1903 | PSB1046PF1903 | MASTER POWER SWITCH |
| 1904 | PSB1046PF1904 | CONTACTOR AB C09400 |
| 1905 | PSB1046PF1905 | OL RELAY AB .25-.4A |
| 1906 | PSB1046PF1906 | CIRCUIT BREAKER 1492SP 25A |
| 1907 | PSB1046PF1907 | CIRCUIT BREAKER 1492SP 6A |
| 1908 | PSB1046PF1908 | TRANSFORMER SUEN LIANG SP-TBSW |
| 1909 | PSB1046PF1909 | FUSE 4A 250V TIME-DELAY |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 1910 | PSB1046PF1910 | FUSE 500M 250V TIME-DELAY |
| 1911 | PSB1046PF1911 | TERMINAL BAR 17P |
| 1912 | PSB1046PF1912 | ELECTRICAL PANEL BACK PLATE |
| 1913 | PSB1046PF1913 | STOP BUTTON |
| 1914 | PSB1046PF1914 | MOTOR ON BUTTON |
| 1915 | PSB1046PF1915 | MOTOR OFF BUTTON |
| 1916 | PSB1046PF1916 | COOLANT PUMP ON BUTTON |
| 1917 | PSB1046PF1917 | COOLANT PUMP OFF BUTTON |
| 1918 | PSB1046PF1918 | POWER LAMP |


# Accessories




| REF | PART # | DESCRIPTION |
|---|---|---|
| 2001 | SB1312 | 3-JAW CHUCK 12" |
| 2002 | PSB1042PF1802 | FACEPLATE ASSEMBLY 14" |
| 2003 | SB1232 | 4-JAW CHUCK 14" |
| 2004 | PSB1042PF1804 | DEAD CENTER MT#5 |
| 2005 | PSB1042PF1805 | DEAD CENTER CARBIDE-TIPPED MT#5 |
| 2006 | PSB1042PF1806 | SPINDLE SLEEVE MT#7-MT#5 |
| 2007 | PSB1042PF1807 | TOOL BOX |
| 2008 | PAW10M | HEX WRENCH 10MM |
| 2009 | PAW1510M | HEX WRENCH SET 1.5-10MM |
| 2010 | PSB10531710 | FOOT CAST-IRON |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 2011 | PSDF2 | STANDARD SCREWDRIVER #2 |
| 2012 | PSDP2 | PHILLIPS SCREWDRIVER #2 |
| 2013 | PWR1012 | WRENCH 10/12MM |
| 2014 | PWR1417 | WRENCH 14/17MM |
| 2015 | PWR2224 | WRENCH 22/24MM |
| 2016 | PWR27 | COMBO WRENCH 27MM |
| 2017 | PSB10531717 | DRO ASSEMBLY FAGOR 20I-T 2-AXIS |
| 2018 | PSB1042PF1818 | 4-WAY TOOL POST WRENCH |
| 2019 | SB1404 | 3-JAW CHUCK D1-8 BACK PLATE 12-1/2" |


# Front Machine Labels




| REF | PART # | DESCRIPTION |
|---|---|---|
| 2101 | PSB1046PF2101 | MACHINE ID LABEL (SB1046PF) |
| 2101 | PSB1047PF2101 | MACHINE ID LABEL (SB1047PF) |
| 2101 | PSB1048PF2101 | MACHINE ID LABEL (SB1048PF) |
| 2101 | PSB1056F2101 | MACHINE ID LABEL (SB1056F) |
| 2101 | PSB1057F2101 | MACHINE ID LABEL (SB1057F) |
| 2101 | PSB1058F2101 | MACHINE ID LABEL (SB1058F) |
| 2102 | PSB1048PF2102 | UNTRAINED PERSONNEL LABEL |
| 2103 | PSBLABEL02HL | DISCONNECT POWER LABEL HL |
| 2104 | PSBLABEL06HL | BIOHAZARD LABEL HL |
| 2105 | PSB1046PF2105 | TOOLROOM SIZE LABEL (SB1046PF) |
| 2105 | PSB1047PF2105 | TOOLROOM SIZE LABEL (SB1047PF) |
| 2105 | PSB1048PF2105 | TOOLROOM SIZE LABEL (SB1048PF) |
| 2105 | PSB1056F2105 | TOOLROOM SIZE LABEL (SB1056F) |
| 2105 | PSB1057F2105 | TOOLROOM SIZE LABEL (SB1057F) |
| 2105 | PSB1058F2105 | TOOLROOM SIZE LABEL (SB1058F) |
| 2106 | PSB1048PF2106 | CARRIAGE LOCK LABEL |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 2107 | PSB1048PF2107 | THREAD CHART |
| 2108 | PSB1048PF2108 | ONE SHOT OILER LABEL |
| 2109 | PSB1046PF2109 | MODEL NUMBER LABEL (SB1046PF) |
| 2109 | PSB1047PF2109 | MODEL NUMBER LABEL (SB1047PF) |
| 2109 | PSB1048PF2109 | MODEL NUMBER LABEL (SB1048PF) |
| 2109 | PSB1056F2109 | MODEL NUMBER LABEL (SB1056F) |
| 2109 | PSB1057F2109 | MODEL NUMBER LABEL (SB1057F) |
| 2109 | PSB1058F2109 | MODEL NUMBER LABEL (SB1058F) |
| 2110 | PSBLABEL04HL | SAFETY GLASSES LABEL HL |
| 2111 | PSBLABEL08HL | ENTANGLEMENT HAZARD LABEL |
| 2112 | PSB1048PF2112 | CHUCK KEY LABEL |
| 2113 | PSBLABEL01HL | READ MANUAL LABEL HL |
| 2114 | SB1322 | SOUTH BEND NAMEPLATE |
| 2115 | PSBPAINT01 | SB GRAY TOUCH-UP PAINT |
| 2116 | PSBPAINT02 | SB LIGHT BLUE TOUCH-UP PAINT |
| 2117 | PSBPAINT03 | SB DARK BLUE TOUCH-UP PAINT |

# Rear Machine Labels




| REF | PART # | DESCRIPTION |
|---|---|---|
| 2103 | PSBLABEL02HL | DISCONNECT POWER LABEL HL |
| 2118 | PSBLABEL15L | ELECTRICITY LABEL |

| REF | PART # | DESCRIPTION |
|---|---|---|
| 2119 | PSB1048PF2119 | 440V 3-PHASE LABEL |

## ⚠WARNING

**The safety labels provided with your machine are used to make the operator aware of the machine hazards and ways to prevent injury. The owner of this machine MUST maintain the original location and readability of these safety labels. If any label is removed or becomes unreadable, REPLACE that label before using the machine again. Contact South Bend Lathe Co. at (360) 734-1540 or www.southbendlathe.com to order new labels.**