Jeep® Cherokee



QUICK START GUIDE


Garage Door Opener
Instrument Cluster Display & Voice Recognition Buttons
Cruise Control Buttons
Stop/Start OFF Button
Memory Seat Control Buttons
Light Controls
Power Liftgate Button
Tune/Browse Button
Hood Release
4WD Controls
USB Ports

Garage Door Opener



1 While the car is ON, hold the handheld garage door transmitter 1-3 inches from the HomeLink® button you want to program in the vehicle.

2 Push and hold both the HomeLink® button being programmed and the button on the garage door transmitter.

TO ERASE ALL SET CHANNELS:
Push and hold the two outside HomeLink® buttons for 20 seconds until the orange indicator flashes. An individual channel cannot be erased.

ROLLING OR NON-ROLLING?
Check your garage door opener motor in your garage for a "LEARN" or "TRAIN" button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.

3 **For Non-Rolling Code** garage door openers, watch for the indicator light to go constant.

For Rolling Code garage door openers, watch for the indicator light to go from a slow blink to blinking rapidly.

4 **For Rolling Code** garage door openers only, firmly push and release the "LEARN" or "TRAIN" button on your garage door opener motor in your garage, then push the HomeLink® button in your vehicle three times (holding the button for two seconds each time).

5 If the programming was successful, your garage door should open and close with your chosen HomeLink® button.

NEED ASSISTANCE?
1-800-355-3515

Scan For HomeLink® Video

LINK YOUR GARAGE DOOR

Pair a Phone



1. Make sure Bluetooth® is enabled on your mobile device.
2. With the vehicle in the ACC or ON/RUN position, press the Phone button on the vehicle's touchscreen menu bar.
3. Press "Pairing".
4. Press "Paired Phones and Audio Devices".
5. Select "Add Device" then follow the prompts on your phone and on the touchscreen.

CONNECT YOUR APPS

Connect your smartphone to the media USB port.

The Android Auto™ or Apple CarPlay® icon will replace the phone icon on the touchscreen.

KEEP IN MIND:

For Android™ Users, if the Android Auto™ app was not previously downloaded, it will download the first time you plug in your device.

For Apple® Users, Apple CarPlay® is only compatible with iPhone® 5 or later and requires Siri being enabled in Settings.

Ready to remove a phone or audio device?

1. Press the Pairing button on the touchscreen.
2. Press "Paired Phones and Audio Devices".
3. Press "Settings" next to the phone or device you want to remove.
4. Press "Delete Device".
5. Press "X" to exit the settings screen. The device should be removed.



Connected Services

WITH CONNECTED SERVICES YOU CAN...

- **Lock Your Vehicle**
- **Unlock Your Vehicle**
- **Remote Start Your Vehicle**
- **Cancel Remote Start**
- **Activate Your Horn**

ACTIVATE YOUR REMOTE SERVICES

GO

1. Press “Apps” on the touchscreen.
2. Press “Activate Services”.
3. Press “Activate Now”.
4. There are two ways to activate: via email or via an agent. On the next screen, you can either enter your name and email, or press “Call An Agent” to directly speak with a certified agent.

Mopar® YOUR Way

CREATE YOUR OWNER'S PROFILE TODAY!

Get 24/7 Access To Everything You Need

- Custom vehicle dashboard
- Access to your vehicle's Owner's Information
- Schedule dealer service with ease
- Obtain special offers on Mopar® service
- View maintenance records**
- Mobile vehicle commands**

**Requires an active SiriusXM Guardian™ subscription

Registration is simple. Provide your email address to get started.

Scan me (U.S. Residents Only)*

*Canadian residents are not required to create a profile, as one is created when a SiriusXM Guardian™ account is activated.

GET PERSONALIZED BY REGISTERING

Hands-Free Liftgate

LIFTGATE NOT OPENING?

Make sure your kicking motion is straight in and out, and within the activation zone.

Please note, this feature is available only on vehicles equipped with Passive Entry.



Use a Straight
In-and-Out Kicking Motion



Activation Zone

X Do not move your foot sideways or in a sweeping motion; the sensors may not detect the motion.

Scan For
Liftgate Video

Keyless Enter 'n Go™ — Passive Entry

LOCK & UNLOCK YOUR VEHICLE WITH EASE

WITH YOUR KEY FOB ON YOUR PERSON:

Press the **Passive Entry Button** on the door handle, making sure not to grab the door handle, to lock the vehicle.

Grab the door handle to unlock the vehicle.



KEEP IN MIND:

The driver's door handle will unlock the driver's door (this can be adjusted within Uconnect Settings). The front passenger handle unlocks all doors and the liftgate.

LIFTGATE BUTTONS:

1 Passive Entry
Press the Passive Entry button to the left of the liftgate release handle to lock all doors and the liftgate.

2 Liftgate Release
Grab the liftgate release handle to open the liftgate.

Steering Wheel Controls

DID YOU KNOW THERE ARE BUTTONS ON THE BACK OF YOUR STEERING WHEEL?

The Right-Hand button will let you change between various sources/modes on the Uconnect system and increase or decrease the volume. The Left-Hand button will Seek Up/Seek Down through radio stations and audio tracks or to the next preset.



Scan For Audio Control Video

Lights & Wipers Operation

PUSH
TO ACTIVATE HIGH BEAMS

PULL
FOR FLASH-TO-PASS



Headlights, Parking Lights & Instrument Panel Lights

Parking Lights & Instrument Panel Lights

Fog Lights



Front Wipers

OFF
INT
LOW
HIGH

PUSH UP
TO MIST THE WINDSHIELD

PUSH FORWARD
TO ACTIVATE THE REAR WINDSHIELD WASHER

PULL
TO ACTIVATE THE FRONT WINDSHIELD WASHER

Rear Wipers ON



Rear Wipers OFF

Scan For Headlight Video

Advanced Driving Assist Systems



Use these buttons to activate your **Cruise Control system** and set your speed.

Use these buttons to activate your **Adaptive Cruise Control (ACC) system** and set your following distance.

Scan For ACC Video

Scan For FCW Video

Turn the **Forward Collision Warning (FCW) system** on or off, and adjust the sensitivity and active braking status through your radio.

Scan For LaneSense Video

Adjust your **LaneSense system** strength and sensitivity settings through your radio.

Scan For Park Assist Video

Turn your **ParkSense system** on or off by using the ParkSense switch. The chime volume settings can be programmed through your radio.

Turn the **ParkSense Active Park Assist system** on or off using the ParkSense Active Park Assist switch. You can switch parking maneuvers through your instrument cluster display using the arrows on the left side of the steering wheel.

Scan For BSM Video

Use your radio to choose between three **Blind Spot Monitoring (BSM) system** modes:

- Blind Spot Alert Lights Only
- Blind Spot Alert Lights/Chime
- Blind Spot Alert Off



Warning & Indicator Lights

	Air Bag		Battery Charge		Brake		Door Open		Electric Power Steering Fault (EPS)
	Electronic Throttle Control (ETC)		Engine Temperature		Hood Open		Liftgate Open		Oil Pressure
	Oil Temperature		Seat Belt Reminder		Transmission Temperature		Vehicle Security		Cruise Control Fault
	4WD Low		Anti-Lock Brake System (ABS)		Electronic Park Brake		Electronic Stability Control (ESC) Active		Electronic Stability Control (ESC) OFF
	Engine Check/ Malfunction		Forward Collision		Forward Collision Warning (FCW) OFF		Fuel Cutoff		Immobilizer Fail/VPS Electrical Alarm
	LaneSense		Low Fuel		Low Washer Fluid		Rear Axle Lock		Service 4WD
	Service Adaptive Cruise Control (ACC)		Service Forward Collision Warning (FCW)		Service LaneSense		Service Stop/Start System		Tire Pressure Monitoring System (TPMS)
	Wait To Start		Water In Fuel		Adaptive Cruise Control (ACC) Set No Target		Adaptive Cruise Control (ACC) Set With Target		Cruise Control SET
	Front Fog Lights		LaneSense		Parking/Headlights On		Stop/Start Active		Turn Signal
	Cruise Control Ready		Hill Descent Control (HDC)		LaneSense		High Beam		

For additional information on any of the topics in this publication, please refer to your Owner's Manual.

©2022 FCA US LLC. All Rights Reserved. Tous droits réservés. Jeep is a registered trademark of FCA US LLC. Jeep est une marque déposée de FCA US LLC.
App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

First Edition
KL_QSG_EN_USC_CA