QUICK START GUIDE



Jeep® Gladiator


Garage Door Opener
Instrument Cluster Display Buttons
Cruise Control Buttons
Mirror Controls
ON/OFF & Volume
Tune/Browse
Light Controls
Stop/Start Off Button
USB Ports
Window Switches
Shifter
Door Locks
Door Locks

Garage Door Opener



1 While the car is ON, hold the handheld garage door transmitter 1-3 inches from the HomeLink® button you want to program in the vehicle.

2 Push and hold both the HomeLink® button being programmed and the button on the garage door transmitter.

TO ERASE ALL SET CHANNELS:
Push and hold the two outside HomeLink® buttons for 20 seconds until the orange indicator flashes. An individual channel cannot be erased.

ROLLING OR NON-ROLLING?
Check your garage door opener motor in your garage for a "LEARN" or "TRAIN" button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.

3 **For Non-Rolling Code** garage door openers, watch for the indicator light to go constant.

For Rolling Code garage door openers, watch for the indicator light to go from a slow blink to blinking rapidly.

4 **For Rolling Code** garage door openers only, firmly push and release the "LEARN" or "TRAIN" button on your garage door opener motor in your garage, then push the HomeLink® button in your vehicle three times (holding the button for two seconds each time).

5 If the programming was successful, your garage door should open and close with your chosen HomeLink® button.

NEED ASSISTANCE?
1-800-355-3515

Scan For HomeLink® Video

LINK YOUR GARAGE DOOR

Pair a Phone



1. Make sure Bluetooth® is enabled on your mobile device.
2. With the vehicle in the ACC or ON/RUN position, press the Phone button on the vehicle's touchscreen menu bar.
3. Press "Pairing".
4. Press "Paired Phones and Audio Devices".
5. Select "Add Device" then follow the prompts on your phone and on the touchscreen.

CONNECT YOUR APPS

Connect your smartphone to the media USB port.

The Android Auto™ or Apple CarPlay® icon will replace the phone icon on the touchscreen.

KEEP IN MIND:

For Android™ Users, if the Android Auto™ app was not previously downloaded, it will download the first time you plug in your device.

For Apple® Users, Apple CarPlay® is only compatible with iPhone® 5 or later and requires Siri being enabled in Settings.

Ready to remove a phone or audio device?

1. Press the Pairing button on the touchscreen.
2. Press "Paired Phones and Audio Devices".
3. Press "Settings" next to the phone or device you want to remove.
4. Press "Delete Device".
5. Press "X" to exit the settings screen. The device should be removed.



Connected Services

WITH CONNECTED SERVICES YOU CAN...

- **Lock Your Vehicle**
- **Unlock Your Vehicle**
- **Remote Start Your Vehicle**
- **Cancel Remote Start**
- **Activate Your Horn**

ACTIVATE YOUR REMOTE SERVICES

1. Press “Apps” on the touchscreen.
2. Press “Activate Services”.
3. Press “Activate Now”.
4. There are two ways to activate: via email or via an agent. On the next screen, you can either enter your name and email, or press “Call An Agent” to directly speak with a certified agent.

   If you previously were registered for Connected Services at the dealer, you will only need to enter your email and PIN to activate them on your vehicle.
5. Download the Jeep® Mobile App from the Google Play Store or Apple® App Store® for access to Remote Commands. Log in with your account information.

Mopar® YOUR Way

CREATE YOUR OWNER'S PROFILE TODAY!

Get 24/7 Access To Everything You Need

- Custom vehicle dashboard
- Access to your vehicle's Owner's Information
- Schedule dealer service with ease
- Obtain special offers on Mopar® service
- View maintenance records**
- Mobile vehicle commands**

**Requires an active Jeep® Connect subscription

MOPAR®

Registration is simple. Scan the QR code below and provide your email address to get started.

Scan me (U.S. Residents Only)*

*Canadian residents are not required to create a profile, as one is created when a Jeep® Connect account is activated.

GET PERSONALIZED BY REGISTERING

Stop/Start

REDUCE FUEL CONSUMPTION

To manually turn off Stop/Start, push the Stop/Start OFF switch located on the switch bank below the climate controls.

Stop/Start OFF Switch



AUTOSTOP MODE

To activate:

- The system must be in STOP/START READY state.
- The vehicle must be completely stopped.
- The gear selector must be in a forward gear with the brake pedal pressed (automatic transmission).
- The gear selector must be in NEUTRAL with the clutch pedal fully released (manual transmission).

KEEP IN MIND:

Prior to engine shut down, the system will check many safety and comfort conditions to determine if they are fulfilled. Certain conditions will prevent the engine from autostopping. See your Owner's Manual for a detailed list of these conditions.

Scan For Stop/Start Video

Uconnect 5/5 NAV

Available Modes

- Home: Customize the Home screen with widgets.
- Media: Listen to the radio and play media.
- Phone: Pair your smartphone and make hands-free calls.
- Comfort: Adjust the vehicle's multiple climate systems.
- Vehicle: Change vehicle settings.
- Navigation: Search for and navigate to any destination.

Swipe Down To Customize Profile Options



Press And Drag An Icon To Rearrange

KEEP IN MIND:

Push and hold the Power button on the radio's faceplate for a minimum of 15 seconds to reset the radio.

Using Android Auto™ Or Apple CarPlay®?

You can use Voice Recognition with Android Auto™ and Apple CarPlay®!

1. Activate Android Auto™ or Apple CarPlay® from "Device Manager" in Phone Mode. The respective icon will replace the Phone icon in the menu bar.
2. Push and hold the Voice Recognition button to start a Voice session using Android Auto™ or Apple CarPlay®.

There may be an inconsistent volume between different audio sources.

4x4 Operation

FIVE-POSITION TRANSFER CASE

2WD High
Used for normal street and highway driving.

4WD High AUTO
Sends power to the front wheels.

4WD High Part-Time
Forces the front and rear wheels to rotate at the same speed.

Neutral
Used for flat towing behind another vehicle.

4WD Low
Provides low speed four-wheel drive. Forces the front and rear wheels to rotate at the same speed.

If your vehicle is equipped with a four-position transfer case, see “Four-Wheel Drive Operation” in “Starting And Operating” in your Owner's Manual.



Scan For 4x4 Video

Axle Lock
To unlock the axles, push the axle lock **OFF** button.

OFF ROAD+
When activated, the vehicle's performance will improve depending on which 4WD mode is activated.



Axle Lock Switch
- Push the switch up to lock the front axle & rear axle.
- Push the switch down to lock the rear axle only.

Sway Bar Disconnect
Shift to either 4WD High or 4WD Low and push the **SWAY BAR** button.

If your vehicle is equipped with Tru-Lok, see “Four-Wheel Drive Operation” in “Starting And Operating” in your Owner's Manual.

KEEP IN MIND:
Sway Bar Disconnect should be off during normal driving conditions.

Scan For Sway Bar Video

Door & Top Removal



Hard Top

HARD TOP
INSTALL/REMOVE

READY TO REMOVE YOUR DOORS?

FRONT DOOR REMOVAL

REAR DOOR REMOVAL

Soft Top



RAISING

LOWERING

INSTALL/ REMOVE

REMOVE YOUR DOORS & TOP

Warning & Indicator Lights

	Air Bag		Battery Charge		Brake		Door Open		Electric Power Steering Fault
	Electronic Throttle Control (ETC)		Engine Coolant Temperature		Hood Open		Oil Pressure		Oil Temperature
	Rear Seat Belt Reminder With Premium Cluster		Seat Belt Reminder		Transmission Temperature		Vehicle Security		4WD
	4WD Low		4WD Part-Time		Anti-Lock Brake System (ABS)		Axle Lock Fault		Cargo Light On
	Cruise Control Fault		Electronic Stability Control (ESC) Active		Electronic Stability Control (ESC) OFF		Engine Check/ Malfunction Indicator		Forward Collision Warning (FCW) OFF
	Front And Rear Axle Lock		Low Fuel		Low Washer Fluid		Neutral		Off-Road+
	Rear Axle Lock		Service 4WD		Service Stop/Start System		Service Adaptive Cruise Control		Service Forward Collision Warning (FCW)
	Sway Bar		Sway Bar Fault		Tire Pressure Monitoring System (TPMS)		4WD Auto		Adaptive Cruise Control (ACC) Set With Target
	Adaptive Cruise Control (ACC) Set Without Target		Cruise Control Set With Premium Cluster		Front Fog		Parking/Headlights On		Rear Seat Belt Fastened With Premium Cluster
	Stop/Start Active		Turn Signal		2WD High		Adaptive Cruise Control Set With Base Cluster		Adaptive Cruise Control With Base Cluster
	Adaptive Cruise Control With Premium Cluster		Cruise Control Ready		Cruise Control Set With Base Cluster		Rear Seat Belt Fastened With Base Cluster		Rear Seat Belt Reminder With Base Cluster
	Rear Seat Unoccupied		Selec-Speed Control (SSC)		High Beam				

For additional information on any of the topics in this publication, please refer to your Owner's Manual.

©2023 FCA US LLC. All Rights Reserved. Tous droits réservés. Jeep is a registered trademark of FCA US LLC. Jeep est une marque déposée de FCA US LLC.
App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

First Edition V1
24_JT_QSG_EN_USC