Grand Cherokee WK



QUICK START GUIDE


Instrument Cluster Display Buttons
Cruise Control Buttons
Garage Door Opener
Light Controls
Memory Buttons
Hood Release
On/Off/ Volume
Tune/Browse
Stop/Start OFF Button
Fuel Door Release
Parking Brake
Power Outlet
USB & Aux Ports
Scan me

Garage Door Opener



1 While the car is ON, hold the handheld garage door transmitter 1-3 inches from the HomeLink® button you want to program in the vehicle.

2 Push and hold both the HomeLink® button being programmed and the button on the garage door transmitter.

TO ERASE ALL SET CHANNELS:
Push and hold the two outside HomeLink® buttons for 20 seconds until the orange indicator flashes. An individual channel cannot be erased.

ROLLING OR NON-ROLLING?
Check your garage door opener motor in your garage for a “LEARN” or “TRAIN” button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.

3 **For Non-Rolling Code** garage door openers, watch for the indicator light to go constant.

For Rolling Code garage door openers, watch for the indicator light to go from a slow blink to blinking rapidly.

4 **For Rolling Code** garage door openers only, firmly push and release the “LEARN” or “TRAIN” button on your garage door opener motor in your garage, then push the HomeLink® button in your vehicle for two long presses.

5 If the programming was successful, your garage door should open and close with your chosen HomeLink® button.

NEED ASSISTANCE?
1-800-355-3515

Scan For HomeLink® Video

LINK YOUR GARAGE DOOR

Pair a Phone



1. Make sure Bluetooth® is enabled on your mobile device.
2. With the vehicle in the ACC or ON/RUN position, press the Phone button in the vehicle's touchscreen menu bar.
3. Press "Pairing".
4. Press "Paired Phones and Audio Devices".
5. Select "Add Device" then follow the prompts on your phone and on the touchscreen.

CONNECT YOUR APPS

Connect your smartphone to the media USB port.

The Android Auto™ or Apple CarPlay® icon will replace the phone icon on the touchscreen.

KEEP IN MIND:

For Android™ Users, if the Android Auto™ app was not previously downloaded, it will download the first time you plug in your device.

For Apple® Users, Apple CarPlay® is only compatible with iPhone® 5 or later and requires Siri being enabled in Settings.

Ready to remove a phone or audio device?

1. Press the Pairing button on the touchscreen.
2. Press "Paired Phones and Audio Devices".
3. Press "Settings" next to the phone or device you want to remove.
4. Press "Delete Device".
5. Press "X" to exit the settings screen. The device should be removed.



Connected Services

WITH CONNECTED SERVICES YOU CAN...

- **Lock Your Vehicle**
- **Unlock Your Vehicle**
- **Remote Start Your Vehicle**
- **Cancel Remote Start**
- **Activate Your Horn**

ACTIVATE YOUR REMOTE SERVICES

1. Press "Apps" on the touchscreen.
2. Press "Activate Services".
3. Press "Activate Now".
4. There are two ways to activate: via email or via an agent. On the next page, you can either enter your name and email, or press "Call An Agent" to directly speak with a certified agent.

Mopar® YOUR Way

CREATE YOUR OWNER'S PROFILE TODAY!

Get 24/7 Access To Everything You Need

- Custom vehicle dashboard
- Access to your vehicle's Owner's Information
- Schedule dealer service with ease
- Obtain special offers on Mopar® service
- View maintenance records**
- Mobile vehicle commands**

**Requires an active SiriusXM Guardian™ subscription

Registration is simple. Provide your email address to get started.

Scan me (U.S. Residents Only)*

*Canadian residents are not required to create a profile, as one is created when a SiriusXM Guardian™ account is activated.

SET UP SERVICES & OWNER'S PROFILE

Lights & Wipers



KEEP IN MIND:
Vehicles sold in Canada are equipped with a headlight switch with an AUTO and ON detent but without an OFF detent. Headlights will be deactivated when the headlight switch is placed in the parking lights position. However, the Daytime Running Lights will be activated along with the front and rear marker lights.

Scan For Lights Video



PUSH
TO ACTIVATE **HIGH BEAMS**

PULL
FOR **FLASH-TO-PASS**

ROTATE UP
TO ACTIVATE THE **REAR WINDSHIELD WASHER**

PUSH END
TO ACTIVATE THE **FRONT WINDSHIELD WASHER**

Climate Controls



TIP:
Push the **red arrow** button to increase the temperature or push the **blue arrow** button to decrease the temperature for the driver or the passenger.

A/C
Pushing the button will engage the Air Conditioning (A/C) system.

RECIRCULATION
Pushing the button will change the system to recirculation mode.

AUTO
Pushing the button will automatically control the cabin temperature.

FRONT DEFROST
Pushing the button will engage the Front Defrost mode.

REAR DEFROST
Pushing the button will turn on the rear window defroster and heated outside mirrors.

BLOWER CONTROL
Rotating the knob regulates the amount of air forced through the system in any mode.

MODE
Pressing the button (touchscreen) will change the airflow distribution mode.

OFF
Pushing the button will turn the Climate Controls on/off.

Scan For Climate Controls Video

ParkSense Active Park Assist

ALLOW YOUR VEHICLE TO PARALLEL OR PERPENDICULAR PARK FOR YOU!

The Active Park Assist system will guide you safely into a parking spot by identifying a proper parking space, providing audible and visual instructions in the instrument cluster display, and controlling your steering wheel.

Turn the **ParkSense Active Park Assist system** on and off using the ParkSense Active Park Assist button. You can switch parking maneuvers through your instrument cluster display using the arrows on the left side of the steering wheel.



KEEP IN MIND:
Active Park Assist is a Semi-Automatic system. The driver controls the accelerator, gear selector, and brakes.

Scan For Active Park Assist Video

Forward Collision Warning (FCW) With Mitigation

FCW with Mitigation provides both audible and visual warnings, and may also apply a brake jerk to warn you of a potential frontal collision. The warnings and limited braking are intended to provide you with enough time to react, avoid, or mitigate the potential collision.



The system can be turned on and off by pressing the Forward Collision button in your radio. You can also use your touchscreen to adjust the system's sensitivity and active braking status.

Select between the following **sensitivity** settings:

- Near
- Medium
- Far

Select between the following **brake** settings:

- Warning & Braking
- Warning Only
- Off

KEEP IN MIND:
The default settings are "Medium" and "Warning & Braking". This allows the FCW system to warn the driver of a possible collision with the vehicle in front using audible/visual warnings while applying autonomous braking.

Scan For FCW Video

Warning & Indicator Lights

	Air Bag		Battery Charge		Brake		Door Open		Electric Power Steering Fault
	Electronic Throttle Control (ETC)		Engine Coolant Temperature		Hood Open		Liftgate Open		Oil Pressure
	Oil Temperature		Seat Belt Reminder		Transmission Temperature		Vehicle Security		4WD Low
	Air Suspension Active		Air Suspension Aerodynamic		Air Suspension Entry/Exit		Air Suspension Off-Road 1		Air Suspension Off-Road 2
	Anti-Lock Brake System (ABS)		Electronic Stability Control (ESC) Active		Electronic Stability Control (ESC) OFF		Engine Check/ Malfunction Indicator		Forward Collision Warning (FCW) OFF
	LaneSense		Low Fuel		Low Washer Fluid		NEUTRAL		Service 4WD
	Service Adaptive Cruise Control (ACC)		Service Forward Collision Warning (FCW)		Service LaneSense		Service Stop/ Start System		Tire Pressure Monitoring System (TPMS)
	Adaptive Cruise Control (ACC) Set With No Target		Adaptive Cruise Control (ACC) Set With Target		Cruise Control Set		Front Fog		LaneSense
	Parking Lights/ Headlights On		Sport Mode		Stop/Start Active		Turn Signal		Adaptive Cruise Control (ACC) Ready
	Cruise Control Ready		Hill Descent Control (HDC)		LaneSense		Selec-Speed Control		High Beam

For additional information on any of the topics in this publication, please refer to your Owner's Manual.

©2021 FCA US LLC. All Rights Reserved. Tous droits réservés. Jeep is a registered trademark of FCA US LLC. Jeep est une marque déposée de FCA US LLC.
App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

First Edition
WK_QSG_EN_USC_BA