
QUICK START GUIDE




WAGONEER

GRAND WAGONEER SHOWN



GARAGE DOOR OPENER



1. With the ignition in the ON/RUN position and the garage door open, hold the garage door transmitter 1-3 inches from the HomeLink® button you want to program.
2. Push and hold the HomeLink® button and the button on the garage door transmitter.
3. **For Non-Rolling Code** garage door openers, watch for the indicator light to go constant.

   For Rolling Code garage door openers, watch for the indicator light to blink rapidly.
4. **For Rolling Code** garage door openers, push the "LEARN" or "TRAIN" button on your garage door opener, then push the HomeLink® button in your vehicle three times(holding for two seconds each time).
5. If programming was successful, your garage door will open and close with the HomeLink® button.

TO ERASE ALL SET CHANNELS:
Push and hold the two outside HomeLink® buttons until the indicator flashes.

ROLLING
OR
NON-ROLLING

Check your garage door opener motor in your garage for a "LEARN" or "TRAIN" button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.

NEED ASSISTANCE?
1-800-355-3515

Scan For HomeLink® Video

PAIR A PHONE

Scan For Phone Pairing Video

1. Make sure Bluetooth® is enabled on your mobile device
2. With the vehicle in the ON/RUN position, press the Phone button on the vehicle's touchscreen menu bar
3. Press "Device Manager"
4. Press "Add Device"
5. Follow the prompts on your phone and on the touchscreen

Troubleshooting

1. Perform a reset by holding the power button on the radio for 15 seconds
2. Reboot your phone
3. Remove the paired phone
4. Follow the Pair a Phone steps above to set up phone

Scan For Android™ Auto

Scan For Apple Carplay®

LINK YOUR GARAGE DOOR & PHONE PARING

CONNECTED SERVICES

WITH CONNECTED SERVICES YOU CAN...

- Lock Your Vehicle
- Unlock Your Vehicle
- Remote Start Your Vehicle
- Cancel Remote Start
- Activate Your Horn

WAGONEER

ACTIVATE YOUR REMOTE SERVICES

1. Press “Apps” on the touchscreen.
2. Press “Activate Services”.
3. Press “Activate Now”.
4. You can activate via email or an agent. Press "Call An Agent" to speak with an agent. If you were registered for Connected Services at the dealership, simply enter your email and PIN to activate them.
5. Download the Wagoneer Mobile App from the Google Play® Store or Apple® App Store® for access to Remote Commands. Log in with your account information.

MOPAR®

Scan me (U.S. Residents Only)*

Mopar® YOUR Way

Get 24/7 access to everything you need, including custom vehicle dashboards, maintenance records, mobile vehicle commands and more. Scan the QR code to register.

*Canadian residents are not required to create a profile, as one is created when a Wagoneer Connect account is activated.

UCONNECT 5/5 NAV

- **Home** — Customize your Home page by adding shortcut widgets
- **Media** — Listen to radio stations or play music from your USB or Bluetooth® device
- **Comfort** — Adjust your manual or automatic climate controls through your comfort settings
- **NW Nav** — Enter an address or search from multiple points of interest to navigate to
- **Phone** — Pair your Bluetooth® enabled phone and make hands-free calls
- **Vehicle** — Access radio and vehicle settings
- **Apps** — Access the available apps installed on your Uconnect system

Swipe down to customize Profile options



Press and drag an icon to rearrange

Voice Recognition

USE YOUR VOICE TO CONTROL UCONNECT


To begin, push the Voice Recognition button on the steering wheel. If activated within Vehicle settings, you can also say the vehicle's “Wake Up” word, “Hey, Uconnect”, without pushing any buttons.

KEEP IN MIND:
There may be an inconsistent volume between different audio sources.

HEAD UP DISPLAY (HUD)

HOW TO CUSTOMIZE HUD:

1. Select “Settings” in the instrument cluster using the Up or Down Arrow button on the steering wheel.
2. Select “HUD” using the Right or Left Arrow button on the steering wheel. Press “OK”.
3. Adjust available Settings like Content & Layout, Display Height, and Brightness. Press “OK” to change the setting.





TIP:
Select from four available options: Standard, Simple, Advanced, and Custom.

NOTE:
HUD will appear on your windshield.

Scan For Head Up Display Video



Recommended settings for hot and cold weather:

COLD WEATHER
Have both the front and rear climate control systems on and set to Floor or Mix modes. Set the temperature to High and adjust blower speeds to preference.

HOT WEATHER
Have both the front and rear climate control systems on and set to Panel mode. Set the temperature to Low and adjust blower speeds to preference.

GRAND WAGONEER SHOWN

MULTI-ZONE CLIMATE CONTROL

YOUR VEHICLE IS EQUIPPED WITH FRONT AND REAR CLIMATE CONTROL SYSTEMS

To optimally heat or cool your vehicle, we suggest you have both the front and rear climate control systems running.

AUTOMATIC CLIMATE CONTROL
This system will measure conditions like outside temperature, solar load, cabin temperature and humidity, and desired cabin temperature to automatically select the optimum HVAC mode, blower, and outlet settings to keep you comfortable.




Recommended settings are: Auto at 72°F with front and rear climate synced.

MANUAL OVERRIDE CLIMATE CONTROL
This system allows you to control your climate systems. You can choose between various modes, temperature settings, blower speeds, and more.

Scan For Climate Control Video

SEAT CONTROLS

20-WAY POWER FRONT SEATS WITH POWER HEAD RESTRAINT




1 Front Head Restraint Adjust
2 Power Massage
3 Decrease Back/Thigh Bolster & Lumbar
4 Increase Back/Thigh Bolster & Lumbar
5 Upper Seatback
6 Seatback Recline
7 Seat Switch
8 Cushion Extender

Scan For Seat Controls Video

GRAND WAGONEER SHOWN

FRONT PASSENGER SCREEN

This screen provides the passenger access to Radio, Rear Seat Entertainment with Amazon Fire TV built-in, HDMI, Vehicle Cameras, and Navigation functions. It is located on the passenger side of the vehicle, above the glove compartment.






Scan For Voice Recognition Video

Scan For Uconnect 5 Video

Scan For Passenger Screen Video

CRUISE CONTROL SYSTEMS



TIP:
The ACC distance setting appears in the instrument cluster display.


The Cruise Control system will hold your vehicle's speed when you take your foot off of the accelerator.

The Adaptive Cruise Control (ACC) system will adjust the set speed in order to maintain a set distance from the vehicle in front of yours.

Scan For ACC Video

ACTIVE DRIVING ASSIST (ADA) SYSTEM

COMBINES ACTIVE LANE MANAGEMENT AND ADAPTIVE CRUISE CONTROL



The base ADA system requires the driver to keep both hands on the steering wheel at all times.

INDICATOR LIGHT & INSTRUMENT CLUSTER DISPLAY GLOW:

OFF System not turned on/enabled

WHITE System is turned on/enabled, but is not actively steering the vehicle

GREEN System detects driver attentiveness and is actively steering the vehicle

YELLOW System detects driver inattentiveness and warns the driver to place hands on the steering wheel, or if equipped with hands-free ADA, look back toward the road

RED System still detects driver inattentiveness and still warns the driver to place hands on the steering wheel, or if equipped with hands-free ADA, take control of the vehicle, or the system will cancel


Scan For Active Driving Assist Video


SECOND & THIRD ROW SEATS

ADJUST, FOLD, AND UNFOLD YOUR REAR SEATS

Rear Seat Power Folding Switch

A one-touch power folding seat switch is located in the right rear trim panel inside the cargo area.





Third Row Power Recline Switch

Adjust the third row seatback angle forward/rearward for occupant comfort. This switch is located on the trim panel next to the seat.

Scan For Power Folding Seat Video

HANDS-FREE LIFTGATE

OPEN YOUR LIFTGATE WITHOUT PRESSING A BUTTON

USE A STRAIGHT IN-AND-OUT KICKING MOTION

Use a straight in-and-out kicking motion within the activation zone or a sweeping motion under the zone for hands-free activation.

KEEP IN MIND:

The liftgate will only respond to kicks if the key fob is within 5 ft (1.5 m) of the liftgate handle.



TO SET AN OPENING HEIGHT:

1. Open the liftgate fully, then manually pull down or push up to the desired height.
2. Push and hold the liftgate close button, located on the left side trim panel inside the cargo area, for three seconds. An audible chime will sound.



Scan For Hands-Free & Adjustable LIFTGATE Video

REAR SEAT ENTERTAINMENT WITH AMAZON FIRE TV BUILT-IN


GET STARTED

You will be prompted to pair the Voice Remote with Alexa, connect to a network, and sign into an Amazon account. You can also enable parental controls.

Rear Seat Entertainment with Fire TV built-in can stream movies, music, and much more!

1. Push the Power button on the Voice Remote with Alexa or tap on either of the rear touchscreens to turn on the screen
2. Select from one of the available apps or source inputs, like HDMI or USB, through the Fire TV interface





Scan For Rear Seat Entertainment Video

Scan For Bluetooth® Video

GET TO KNOW YOUR VOICE REMOTE WITH ALEXA



REAR SEAT ENTERTAINMENT WITH AMAZON FIRE TV BUILT-IN HEADPHONE PAIRING

1. Push the Gear/Settings button on the Voice Remote with Alexa or tap the screen
2. Select the Gear/Settings icon on the screen
3. Select “Settings” on the screen
4. While in Settings, select “Controllers & Bluetooth® Devices”
5. Select “Other Bluetooth® Devices” and follow the on-screen steps for pairing

DID YOU KNOW?

You can download games from the Apps menu to play on your rear touchscreen

WARNING & INDICATOR LIGHTS

	Air Bag		Battery Charge		Brake		Door Open		Drowsiness Detected
	Electric Power Steering (EPS) Fault		Electronic Throttle Control (ETC)		Engine Temperature		Hood Open		Liftgate Open
	Night Vision Animal Detected		Night Vision Pedestrian Detected		Oil Pressure		Oil Temperature		Seat Belt Reminder
	Transmission Temperature		Vehicle Security		4WD Low		Active Lane Management		Air Suspension Active
	Air Suspension Aerodynamic Height		Air Suspension Entry/Exit Indicator		Air Suspension Fault		Air Suspension Off-Road 1		Air Suspension Off-Road 2
	Anti-Lock Brake System (ABS)		Auto HOLD! Fault		Drowsiness Detected System Fault		Electric Park Brake (EPB)		Electronic Stability Control (ESC) Active
	Electronic Stability Control (ESC) Off		Engine Check/ Malfunction Indicator		Forward Collision Warning (FCW) Off		Low Fuel		Low Washer Fluid
	Maximum Payload Exceeded		NEUTRAL		Night Vision Animal Detected		Night Vision Pedestrian Detected		Oil Level Sensor Fault
	Service 4WD		Service Active Lane Management		Service Adaptive Cruise Control (ACC)		Service Forward Collision Warning (FCW)		Service Stop/Start System
	Tire Pressure Monitoring System		TOW/HAUL		Towing Hook Breakdown		Adaptive Cruise Control (ACC) Set With Target		Adaptive Cruise Control (ACC) Set Without Target
	Auto HOLD		Cruise Control SET		Front Fog		Night Vision Active		Parking /Headlights On
	Rear Seat Belt Fastened		Sport Mode		Stop/Start Active		Turn Signal		Adaptive Cruise Control (ACC) Ready
	Cruise Control Ready		Hill Descent Control (HDC)		Rear Seat Unoccupied		Selec-Speed Control		High Beam
	Night Vision Suppressed								

Your vehicle may be equipped with different features than shown in this guide.

For additional information on any of the topics in this publication, please refer to your Owner's Manual.

©2024 FCA US LLC. All Rights Reserved. Tous droits réservés. Wagoneer is a registered trademark of FCA US LLC.
Wagoneer est une marque déposée de FCA US LLC. App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

First Edition
25_WS_QSG_EN_USC