


QUICK
START
GUIDE
WAGONEER


Garage Door Opener
Overhead Console
Driver Seat Controls
Cruise Control Buttons
On/Off & Volume
Tune/Browse
Passenger Screen Display
Passenger Seat Controls
Light Controls
Climate Controls
Front Comfort & Convenience Display
Instrument Cluster Display Control Buttons
Selec-Terrain Mode Selector
Air Suspension Control

GARAGE DOOR OPENER



1 While the car is ON, hold the handheld garage door transmitter 1-3 inches from the HomeLink® button you want to program in the vehicle.

2 Push and hold both the HomeLink® button being programmed and the button on the garage door transmitter.

TO ERASE ALL SET CHANNELS:
Push and hold the two outside HomeLink® buttons for 20 seconds until the orange indicator flashes. An individual channel cannot be erased.

ROLLING OR NON-ROLLING?
Check your garage door opener motor in your garage for a "LEARN" or "TRAIN" button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.

3 **For Non-Rolling Code** garage door openers, watch for the indicator light to go constant.

For Rolling Code garage door openers, watch for the indicator light to go from a slow blink to blinking rapidly.

4 **For Rolling Code** garage door openers only, firmly push and release the "LEARN" or "TRAIN" button on your garage door opener motor in your garage, then push the HomeLink® button in your vehicle three times (holding the button for two seconds each time).

5 If the programming was successful, your garage door should open and close with your chosen HomeLink® button.

Scan For HomeLink® Video

NEED ASSISTANCE?
1-800-355-3515

LINK YOUR GARAGE DOOR

CONNECTED SERVICES



HOW TO ACTIVATE YOUR REMOTE SERVICES

1. Press “Apps” on the touchscreen
2. Press “Activate Services”
3. Press “Activate Now”
4. There are two ways to activate: via email or via an agent. On the next screen, you can either enter your name and email, or press “Call Care” to directly speak with an agent.

NOTE:
If you previously were registered at the dealership, enter your email and PIN to activate services.

MOPAR® YOUR WAY

CREATE YOUR OWNER'S PROFILE TODAY!

Get 24/7 Access To Everything You Need

- Custom vehicle dashboard
- Access to your vehicle's Owner's Information
- Schedule dealership service with ease
- Obtain special offers on Mopar® services
- View maintenance records**
- Mobile vehicle commands**

** Requires an active Wagoneer Connect subscription

Registration is simple. Scan the QR code below and provide your email address to get started.

Scan me
(U.S. Residents Only)*

*Canadian residents are not required to create a profile, as one is created when a Wagoneer Connect account is activated.

GET PERSONALIZED BY REGISTERING

HEAD UP DISPLAY (HUD)

HOW TO CUSTOMIZE HUD:

1. Select “Settings” in the instrument cluster using the Up or Down Arrow button on the steering wheel.
2. Select “HUD” using the Right or Left Arrow button on the steering wheel. Press “OK”.
3. Adjust available Settings like Content & Layout, Display Height, and Brightness. Press “OK” to change the setting.




Instrument Cluster Display Control Buttons

TIP:
Select from four available options: Standard, Simple, Advanced, and Custom.

NOTE:
HUD will appear on your windshield.

Scan For Head Up Display Video

CRUISE CONTROL SYSTEMS



The Cruise Control system will hold your vehicle's speed when you take your foot off of the accelerator.

The Adaptive Cruise Control (ACC) system will adjust the set speed in order to maintain a set distance from the vehicle in front of yours.

TIP:
The ACC distance setting appears in the instrument cluster display.

Scan For ACC Video

PAIR A PHONE



1. Make sure Bluetooth® is enabled on your mobile device.
2. With the vehicle in the ON/RUN position, press the Phone button on the vehicle's touchscreen menu bar.
3. Press "Device Manager" and then "Add Device". Follow the prompts on your phone and on the touchscreen.

CONNECT YOUR APPS

Connect your smartphone to the media USB port or pair your smartphone within Device Manager. The Android Auto™ or Apple CarPlay® icon will replace the phone icon on the touchscreen.

If the Android Auto™ app was not previously downloaded, it will download the first time you plug in your device.

Apple CarPlay® is only compatible with iPhone® 5 or later and requires Siri being enabled in Settings.

MULTI-ZONE CLIMATE CONTROL

YOUR VEHICLE IS EQUIPPED WITH FRONT AND REAR CLIMATE CONTROL SYSTEMS

To optimally heat or cool your vehicle, we suggest you have both the front and rear climate control systems running.

AUTOMATIC CLIMATE CONTROL

This system will measure conditions like outside temperature, solar load, cabin temperature and humidity, and desired cabin temperature to automatically select the optimum HVAC mode, blower, and outlet settings to keep you comfortable.

Recommended settings are: Auto at 72°F with front and rear climate synced.



MANUAL OVERRIDE CLIMATE CONTROL

This system allows you to control your climate systems. You can choose between various modes, temperature settings, blower speeds, and more.

Recommended settings for hot and cold weather:

COLD WEATHER

Have both the front and rear climate control systems on and set to Floor or Mix modes. Set the temperature to High and adjust blower speeds to preference.

HOT WEATHER

Have both the front and rear climate control systems on and set to Panel or Bi-Level modes. Set the temperature to Low and adjust blower speeds to preference.

UCONNECT 5/5 NAV

Home — Customize your Home page by adding shortcut widgets

Media — Listen to radio stations or play music from your USB or Bluetooth® device


Comfort — Adjust your manual or automatic climate controls through your comfort settings

NW Nav — Enter an address or search from multiple points of interest to navigate to

Phone — Pair your Bluetooth® enabled phone and make hands-free calls

Vehicle — Access radio and vehicle settings

Apps — Access the available apps installed on your Uconnect system



Voice Recognition

USE YOUR VOICE TO CONTROL UCONNECT

To begin, push the Voice Recognition button on the steering wheel. If activated within Vehicle settings, you can also say the vehicle's "Wake Up" word, "Hey, Uconnect", without pushing any buttons.

KEEP IN MIND:
There may be an inconsistent volume between different audio sources.

FRONT PASSENGER SCREEN

This screen provides the passenger access to Radio, Rear Seat Entertainment with Amazon Fire TV built-in, HDMI, Vehicle Cameras, and Navigation functions. It is located on the passenger side of the vehicle, above the glove compartment.

Push the Power button under the right side of the Climate Controls screen or under the storage compartment.

The Passenger Screen Permissions menu within "Settings" will activate/deactivate features within the Passenger Screen.


FRONT PASSENGER SCREEN HEADPHONE PAIRING

1. In "Device Manager", press "Add Device" or "Pair Bluetooth® Headphones"
2. Press "Search For Headphones"
3. Select the Headphones you wish to pair and follow the on-screen instructions

KEEP IN MIND:
Push and hold the Power button on the radio's faceplate for a minimum of 15 seconds to reset the radio.


Scan For Voice Recognition Video

Scan For Uconnect 5 Video



SEAT CONTROLS

20-WAY POWER FRONT SEATS WITH POWER HEAD RESTRAINT



Scan For Seat Controls Video

1 FRONT HEAD RESTRAINT ADJUST

Adjust the head restraint up, down, forward or rearward.

2 POWER LUMBAR & BACK/THIGH BOLSTER

Press the "+" or "-" switch to bring up the Seat menu on the Uconnect display or the Front Comfort & Convenience Display, then select the desired adjustment. Adjust the lumbar support in/out or up/down. Extend or retract the seatback and seat cushion bolsters.

3 MEMORY SETTINGS PROFILE

Save your seat preferences and more to Memory Profile 1 or 2.

4 SEAT CUSHION

Adjust the seat cushion up, down, forward, or rearward, or tilt the angle of the cushion up or down.

5 CUSHION EXTENDER

Extend or retract the seat cushion.

6 POWER MASSAGE

Turn the power massage on or off from the door-mounted switch. Adjust the power massage settings to High, Medium, and Low, and choose from five massage types in the Uconnect display or Front Comfort & Convenience Display.

7 UPPER AND LOWER SEATBACK

Adjust the angle of the upper or lower seatback.

SECOND & THIRD ROW SEATS

ADJUST, FOLD, AND UNFOLD YOUR REAR SEATS

Rear Seat Power Folding Switch

A one-touch power folding seat switch is located in the right rear trim panel inside the cargo area.



2L Second Row Left Side Fold

2R Second Row Right Side Fold

3L Third Row Left Side Fold/Unfold

3R Third Row Right Side Fold/Unfold



Third Row Power Recline Switch

Adjust the third row seatback angle forward/rearward for occupant comfort. This switch is located on the trim panel next to the seat.

Scan For Power Folding Seat Video

HANDS-FREE LIFTGATE

OPEN YOUR LIFTGATE WITHOUT PRESSING A BUTTON

USE A STRAIGHT IN-AND-OUT KICKING MOTION

Use a straight in-and-out kicking motion within the activation zone or a sweeping motion under the zone for hands-free activation. The Hands-Free Liftgate feature can be turned on or off within the Uconnect system.

KEEP IN MIND:

The liftgate will only respond to kicks if the key fob is within 5 ft (1.5 m) of the liftgate handle.



TO SET AN OPENING HEIGHT:

1. Open the liftgate fully, then manually pull down or push up to the desired height.
2. Push and hold the liftgate close button, located on the left side trim panel inside the cargo area, for three seconds. An audible chime will sound.



Scan For Hands-Free & Adjustable Liftgate Video


REAR SEAT ENTERTAINMENT WITH AMAZON FIRE TV BUILT-IN

GET STARTED

You will be prompted to pair the Voice Remote with Alexa, connect to a network, and sign into an Amazon account. You can also enable parental controls.

Rear Seat Entertainment with Fire TV built-in can stream movies, music, and much more!

1. Push the Power button on the Voice Remote with Alexa or tap on either of the rear touchscreens to turn on the screen
2. Select from one of the available apps or source inputs, like HDMI or USB, through the Fire TV interface



KNOW & GO

Scan me
(U.S. Residents Only)*

Download the Know & Go app to your smartphone to discover more about the exciting features on your new Wagoneer/Grand Wagoneer using augmented reality, a features library, and push notifications.

Rear Seat Entertainment

GET TO KNOW YOUR VOICE REMOTE WITH ALEXA



REAR SEAT ENTERTAINMENT WITH AMAZON FIRE TV BUILT-IN HEADPHONE PAIRING

1. Push the Gear/Settings button on the Voice Remote with Alexa or tap the screen
2. Select the Gear/Settings icon on the screen
3. Select “Settings” on the screen
4. While in Settings, select “Controllers & Bluetooth® Devices”
5. Select “Other Bluetooth® Devices” and follow the on-screen steps for pairing

DID YOU KNOW?

You can download games from the Apps menu to play on your rear touchscreen

WARNING & INDICATOR LIGHTS

	Air Bag		Battery Charge		Brake		Door Open		Drowsiness Detected
	Electric Power Steering (EPS) Fault		Electronic Throttle Control (ETC)		Engine Temperature		Hood Open		Liftgate Open
	Night Vision Animal Detected		Night Vision Pedestrian Detected		Oil Pressure		Oil Temperature		Seat Belt Reminder
	Transmission Temperature		Vehicle Security	4WD LOW	4WD Low		Active Lane Management		Air Suspension Active
AERO	Air Suspension Aerodynamic Height	ENTRY/ EXIT	Air Suspension Entry/Exit Indicator		Air Suspension Fault	OFF RD 1	Air Suspension Off-Road 1	OFF RD 2	Air Suspension Off-Road 2
	Anti-Lock Brake System (ABS)	HOLD!	Auto HOLD! Fault		Drowsiness Detected System Fault		Electric Park Brake (EPB)		Electronic Stability Control (ESC) Active
	Electronic Stability Control (ESC) Off		Engine Check/ Malfunction Indicator		Forward Collision Warning (FCW) Off		Low Fuel		Low Washer Fluid
	Maximum Payload Exceeded	NEUTRAL	NEUTRAL		Night Vision Animal Detected		Night Vision Pedestrian Detected		Oil Level Sensor Fault
SERV 4WD	Service 4WD		Service Active Lane Management		Service Adaptive Cruise Control (ACC)		Service Forward Collision Warning (FCW)		Service Stop/Start System
	Tire Pressure Monitoring System	TOW/ HAUL	TOW/HAUL		Towing Hook Breakdown		Active Lane Management		Adaptive Cruise Control (ACC) Set With Target
	Adaptive Cruise Control (ACC) Set Without Target	HOLD	Auto HOLD		Cruise Control SET		Front Fog		Night Vision Active
	Parking /Headlights On		Rear Seat Belt Fastened		Sport Mode		Stop/Start Active		Turn Signal
	Active Lane Management		Adaptive Cruise Control (ACC) Ready		Cruise Control Ready		Hill Descent Control (HDC)		Rear Seat Unoccupied
	Selec-Speed Control		High Beam		Night Vision Suppressed				

Your vehicle may be equipped with different features than shown in this guide.
For additional information on any of the topics in this publication, please refer to your Owner's Manual.

©2022 FCA US LLC. All Rights Reserved. Tous droits réservés. Wagoneer is a registered trademark of FCA US LLC.
Wagoneer est une marque déposée de FCA US LLC. App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

Second Edition
WS_QSG_EN_USC_CA