Remedy DRCV SUSPENSION SETUP GUIDE

Bike	Remedy 7, 8, 9.8, 9.9				
Travel	150mm				
Shock stroke	56mm				
Shock Sag %	25-35% - sitting on bike				
Fork Sag %	20-25% - standing on bike				
Suspension	Front Remedy 7 - 32 Float RL Remedy 8 - 32 TALAS RL Remedy 9.8 - 32 TALAS FIT RL Remedy 9.9 - 32 TALAS FIT RLC			Rear Remedy 7, 8, 9.8 - DRCV RP2 Remedy 9.9 - DRCV RP23 Boost Valve	
Rider Weight (lbs)	Spring	Reb (clicks out)	Remedy 9.9 LS comp	Spring	Reb (clicks out)
100	50	14	8	110	7
110	55	14	8	120	7
120	60	14	8	130	6
130	65	12	8	140	6
140	70	12	8	150	6
150	75	12	7	160	5
160	80	10	7	170	5
170	85	10	7	180	5
180	90	10	6	190	4
190	95	10	6	200	4
200	100	9	6	210	4
210	105	9	5	220	3
220	110	9	5	230	3
230	115	8	5	240	3
240	120	8	4	250	2
250	130	7	4	260	2

Follow these steps to optimize the performance of your Trek Full Suspension Mountain Bike. Steps 3 & 5 are specific to DRCV-equipped bikes:

1. Determine rider weight (individual weight plus riding gear).
2. Adjust rebound and low speed compression settings if applicable as indicated in chart. Turn Pro Pedal off.
3. Be sure to thread the pump head completely on to the valve. Apply pressure as indicated in the chart. Remove pump.
4. Install Trek Sag Meter.
5. Compress shock at least 50%.
   Note: this step is vital for proper DRCV setup.
6. If adjusting fork, stand on the pedals. If adjusting shock, remain seated.
7. Slide O-ring so that it rests against dust seal.
8. Dismount bike.
9. If o-ring falls within sag meter's window, or if o-ring is within recommended sag measurement, you're ready to ride.
10. If the o-ring falls outside of that window, or is greater or less than recommended measurement, add or subtract pressure as needed.
    Note: be sure to cycle shock 2-3 times after any pressure adjustment