

Features & Functions Guide



NIRO
Electric Vehicle (EV)

WELCOME TO THE KIA FAMILY!

Your new Kia vehicle has been designed, engineered and manufactured to provide you with years of comfortable and dependable driving. Kia is committed to quality, innovation, safety and — above all — your satisfaction.

USING THIS FEATURES & FUNCTIONS GUIDE

The information contained in this guide is a brief overview of the operation and features of your new Kia vehicle.

This Features & Functions Guide and the specific operational and safety information it provides are not a substitute for your Owner's Manual. In the interest of your safety and that of the vehicle's occupants, and to help you avoid risks that may result in death or serious injury, Kia reminds you to carefully read the Owner's Manual in order to fully familiarize yourself with the important information and safety warnings it contains.

While Kia endeavors to ensure that the information contained in this guide is accurate at the time of printing, Kia may change vehicle specifications without notice in advance of or after the fact and assumes no liability in connection with such changes.

VIDEOS AND QR CODES

Kia provides a number of video resources to assist you with becoming familiar with the features and functions found in your Kia vehicle. You can access these resources by snapping the QR Codes with your mobile device using the built-in QR Code Reader or a downloaded QR Code Reader App.

After opening the QR Code Reader App on your mobile device, the app will utilize your device's camera. Center the code in the camera viewing area — with some apps, as soon as the app recognizes the code, it will launch the corresponding video.

With other apps, you will have to snap or "take a picture" of the code. The app will then launch the corresponding video.

For operation specifics, refer to the instructions that come with the QR Code Reader App. You can also view the videos by visiting the following website: www.youtube.com/KiaFeatureVideos

QUICK TIPS

If you're having trouble scanning codes, check the following:

- The code should be centered and focused in your mobile device's camera screen
- Consider moving your device closer to or farther away from the code
- The code should be well lit, without significant shadow
- Avoid scanning from a significant angle
- Confirm that the device's app supports 2D QR Code scanning
- Try another QR Code Reader App; not all apps are created equal

After scanning, you may experience a "connection error" message or a "connecting" message with no subsequent response. These messages typically indicate that your device is having trouble connecting to the Internet

QR CODES

Getting Started With Your New Kia Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

As you get to know your new Kia, you can explore this booklet to better understand how to operate its many features and systems. You can find the complete Table of Contents on the next two pages, but first, be sure to review the following to better understand some of your Kia's most used features:

1	Smart Key with Remote Start	58
2	Power Adjustable Driver's Seat / Front Seat Headrest Adjustment . .	53
3	Seat Warmers / Ventilated Seats*	51
4	Folding Rear Seats	54
5	Windshield / Rear Wipers & Washers	39
6	Navigation-based Smart Cruise Control (NSCC)*	24
7	Maintenance Schedule	Back Cover
8	User Settings* - Instrument Cluster	10
9	Vehicle Settings* - Infotainment System	11
10	Bluetooth® Wireless Technology	40
11	Kia Connect Activation* / Kia Connect Assistance*	43
12	Kia Access App Download	45
13	Kia Access App Features Guide	45
14	Kia Connect with Navigation*	44
15	Android Auto™ / Apple CarPlay® Setup	42

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury or death. The driver's primary responsibility is in the safe and legal operation of a vehicle. Handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law, should never be used during operation of the vehicle.

www.kia.com
 Consumer Affairs -
 Roadside Assistance^{†††};
 1-800-333-4KIA (800-333-4542)

Always check the Owner's Manual for complete operating information and safety warnings.

QR CODES

Getting Started With Your New Kia Video



Your New Kia Important Care Tips Video



Vehicle Cameras Important Tips Video



*Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos*

VIDEOS & QR CODES ... Inside Front Cover

INSTRUMENT CLUSTER

Instrument Cluster Overview	03
Indicators & Warning Lights	04
Electric Vehicle (EV) Indicators.....	05
Energy Consumption.....	05
Charge Warning Messages on LCD Display.....	06
Tire Pressure Monitoring System (TPMS).....	07
Drive Mode Integrated Control System.....	08

VEHICLE SETTINGS

Instrument Cluster LCD Modes	09
Trip Modes / Trip Computer	09
User Settings* - Instrument Cluster	10
Vehicle Settings* - Infotainment System	11
Service Interval Mode	11

ELECTRIC VEHICLE (EV) FEATURES

Charging Connector Lock Mode	12
Scheduled Charging*.....	12
EV Mode - Infotainment System	13
Charging the EV	14
Regenerative Braking with Paddle Shifters.....	16
EV Charge Transfer / Vehicle to Load (V2L)*.....	18

ADVANCED DRIVER ASSISTANCE SYSTEMS (ADAS)

Forward Collision-Avoidance Assist (FCA).....	19
Blind-spot Collision-Avoidance Warning (BCW)*	20
Blind-spot Collision-Avoidance Assist (BCA)*	21
Lane Keeping Assist (LKA).....	22
Driver Attention Warning (DAW)	23
Leading Vehicle Departure Alert (LVDA).....	23
Navigation-based Smart Cruise Control - (NSCC)*	24
Intelligent Speed Limit Assist (ISLA).....	26
Head-Up Display (HUD)	27
Lane Following Assist (LFA).....	28

ADAS (CONTINUED)

Highway Driving Assist (HDA)	28
Rear View Monitor (RVM).....	29
Safe Exit Warning (SEW).....	29
Remote Smart Parking Assist (RSPA)*.....	30
Rear Parking Collision Avoidance (PCA)*	31
Forward*/Reverse Parking Distance Warning (PDW)*	32
Rear Cross-traffic Collision-Avoidance Assist (RCCA)	33

DRIVER'S PANEL

Instrument Cluster Control	34
Electronic Stability Control (ESC).....	34
Hill-start Assist Control (HAC)	34
Power Button.....	35
Power Windows, Window Lock & Central Door Lock.....	36
Automatic Door Lock.....	36
Heated Outside Mirrors	36
Power Folding Outside Mirrors*.....	36
Manual Folding Mirrors*	36

STEERING WHEEL CONTROLS

Headlights & High Beams	37
High Beam Assist (HBA).....	37
Turn Signals & Fog Lights*	38
Tilt/Telescoping Steering Wheel	38
Windshield/Rear Wipers & Washers.....	39

INFOTAINMENT SYSTEM

Bluetooth® Wireless Technology	40
Audio Controls.....	41
Android Auto™ / Apple CarPlay® Setup	42
Kia Connect Activation*	43
Kia Connect Assistance*	43
Kia Connect with Navigation.....	44
Kia Access App Download	45
Kia Access App Features Guide.....	45

CENTER PANEL

Digital Clock - Infotainment System	47
Multimedia USB Ports, USB-C Charger Ports & Power Outlets	47
Wireless Smartphone Charging System	48
Rotary Dial Shifter / Heated Steering Wheel*	49
Automatic Climate Control	50
Seat Warmers / Ventilated Seats*	51
Electronic Parking Brake (EPB) / Auto Hold.....	52

SEATING

Power Adjustable Driver's Seat*.....	53
Driver Position Memory System*.....	53
Front Seat Headrest Adjustment.....	53
6-Way Manual Adjustable Driver's Seat*.....	54
Folding Rear Seats	54
Rear Occupant Alert (ROA) with Door Monitoring	55

OTHER KEY FEATURES

Hood Release Lever and Latch	55
Sun Visor	55
Digital Key 2 Touch.....	56
Smart Key with Remote Start	58
Double-Turn Lock/Unlock All	58
Map/Room Lamps	59
Power Sunroof with Sunshade*	59
Smart Power Liftgate*	60
Liftgate Release Button*.....	61
HomeLink®12 with Auto-Dimming Rearview Mirror*	62
Tire Mobility Kit	63
Child-Protector Rear Door Lock.....	63


SAFETY FEATURES

Occupant Detection System (ODS) / Passenger Airbag Off Indicator.....	64
Seat Belts.....	64

LEGAL DISCLAIMERS... Inside Back Cover

MAINTENANCE CHART..... Back Cover

Instrument Cluster Overview



- A** Electric energy economy
- B** Power/Charge gauge - The energy consumption rate of the vehicle and the charge/discharge status of the regenerative brakes
- C** Regenerative Braking Level
- D** Speedometer
- E** Warning and indicator lights
- F** LCD display
- G** Distance to Empty (DTE)
- H** Battery State of Charge (SOC) gauge

QUICK TIPS

- Distance to Empty displayed on the Instrument Cluster after a recharge may vary depending on previous driving patterns, high voltage battery charge amount, weather, temperature, durability of the battery and geographical features
- Energy consumption is increased in cold or hot weather. When using the heater, more energy will be consumed, which reduces the Distance to Empty

Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster, the LCD Warning Messages and the function of all indicator and warning lights, please refer to section 5 of the Owner's Manual.

This illustration is for demonstration purposes only. Some indicators and warning lights may not appear in illustration. On the vehicle, they may appear in the LCD.

QR CODES

EV Instrument Cluster Overview Video




EV Distance to Empty (DTE) Video



*Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos*

Indicators & Warning Lights



Your vehicle's instrument cluster & indicator light locations may differ from those in the illustrations. For more information on the instrument cluster, the LCD Warning Messages and the function of all indicator and warning lights, please refer to section 4 of the Owner's Manual.

This illustration is for demonstration purposes only. Some indicators and warning lights may not appear in illustration. On the vehicle, they may appear in the LCD.

- | | | | | | |
|--|--|--|--|--|---|
| | High Beam Indicator | | Electronic Stability Control (ESC) OFF Indicator | | READY Indicator |
| | Light ON Indicator | | Parking Brake & Brake Fluid Warning Indicator | | EV Temperature Warning* |
| | Low Beam Indicator Light | | Motor Driven Power Steering (MDPS) Warning Indicator | | Charging System Warning Indicator |
| | AUTO HOLD Indicator Light | | Airbag Warning Indicator | | Regenerative Brake Warning Indicator (Two separate indicators on Instrument Cluster lit at same time) |
| | Master Warning Light | | Anti-lock Braking System (ABS) Warning Indicator | | Charging Cable Connection Indicator |
| | Electronic Brakeforce Distribution (EBD) System Warning Indicator (Two separate indicators on Instrument Cluster lit at same time) | | Cruise Indicator* | | Power Down Warning Light |
| | Icy Road Warning Indicator Light* | | LED Headlamp Warning Indicator* | | High Voltage Battery Level Warning Light |
| | Immobilizer Indicator* | | Electronic Parking Brake (EPB) | | 12V Battery |
| | Seat Belt Warning Indicator | | Forward Safety Warning Indicator | | SNOW Mode Indicator |
| | Low Tire Pressure Light / Tire Pressure Monitoring System (TPMS) Malfunction Indicator* | | Lane Safety Indicator* | | ECO Mode Indicator |
| | Electronic Stability Control (ESC) Indicator / ESC Malfunction Indicator | | Highway Lane Change Assist Indicator Light* | | SPORT Mode Indicator |
| | | | Lane Following Assist Indicator | | |
| | | | EV Service Warning Light | | |

Electric Vehicle (EV) Indicators

A Battery State of Charge (SOC) gauge

The State of Charge gauge displays the high-voltage battery charge status.

- L (low) position on the gauge indicates that the driving battery energy is low
- H (high) position on the gauge indicates that the driving battery is fully charged

B Electric Energy Economy

C Regenerative Braking Level

D Remaining Distance

Remaining Distance is the estimated distance the vehicle can be driven with the remaining high-voltage battery level. It is displayed differently according to the selected drive mode and Climate Control settings.

READY **Ready indicator light** - Illuminates when the vehicle is ready to drive. When the ready indicator light is blinking, a malfunction has occurred. Have an authorized Kia dealer address the concern as soon as possible.



EV Service warning light - Illuminates when there is a malfunction related to the electric vehicle control system. Have an authorized Kia dealer address the concern as soon as possible.



Power down warning light - Illuminates when the vehicle's speed and performance are limited for the safety of the electric vehicle.



Charging indicator light - Shows the charging status of the high-voltage battery. When charging, the red indicator turns on. The indicator turns off when not charging.



High-voltage battery level warning light - Illuminates when the high-voltage battery charge level is insufficient.



Regenerative brake warning lights (when both indicators are lit) - Illuminates when the regenerative brake system is not functioning correctly.

For more information, refer to the Owner's Manual.

ALWAYS CHECK THE OWNER'S MANUAL FOR COMPLETE OPERATING INFORMATION AND SAFETY WARNINGS.

Energy Consumption

There are several factors that contribute to your electric vehicle's energy consumption, including maintenance of your vehicle, driving style, environmental conditions, vehicle weight and vehicle aerodynamics.

Below are tips on how to help reduce energy consumption:

- Keep your vehicle in good condition with regular maintenance
- Don't "ride" the brake pedal
- Drive at a moderate speed, accelerating smoothly and at a moderate rate
- Keep tires inflated to the recommended pressure
- Travel lightly, without carrying unnecessary weight in your vehicle
- Ensure wheels are aligned correctly
- Avoid placing large or heavy items on roof racks
- Avoid hilly, winding or poorly maintained roads

For more information, refer to section 6 of the Owner's Manual.

QR CODES

EV Instrument Cluster Overview Video



EV Energy Consumption Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Charge Warning Messages on LCD Display

Low EV Battery



Low Battery Warning - When the high-voltage battery level reaches 8% or less, this warning message appears on the LCD and the warning indicator light on the instrument cluster illuminates. Charge the high-voltage battery immediately.

Charge immediately.
Power limited



Charge immediately. Power limited - When the high-voltage battery level reaches 3% or less, this warning message appears on the LCD, the warning indicator light on the instrument cluster illuminates and the power down warning light turns ON simultaneously.

The vehicle's power will be reduced to minimize the energy consumption of the high-voltage battery. Charge the high-voltage battery immediately.

Power limited



Power limited - This warning message appears when the vehicle's power is limited due to the following reasons:

1. When the high-voltage battery is below a certain level, or voltage is decreasing
2. When the temperature of the motor or high-voltage battery is too high or too low
3. When there is a problem with the cooling system or a failure that may interrupt normal driving

Power limited
due to low EV battery
temperature.
Charge battery

Power limited due to low EV battery temperature. Charge battery - When the outside temperature is low and you turn the vehicle on or off, this warning message may appear on the LCD. If the battery level is low and the vehicle is parked outside for a long time, vehicle power may be limited. Charging battery before driving helps increase power.

EV Battery Overheated!
Pull over safely
and leave the vehicle



EV Battery Overheated! Stop Vehicle - When the high-voltage battery temperature is too high, this warning message will appear on the LCD. Stop the vehicle and turn off the Power button so that the battery temperature decreases.

Stop safely and
check power supply



Stop vehicle and check power supply - When there is a failure in the power supply system, this warning message appears on the LCD. Park the vehicle in a safe location and have it towed to the nearest Kia dealer for inspection.

REMINDERS:

- When these warning messages are displayed, do not accelerate or start the vehicle suddenly
- All stored driving information (except Odometer and Range) is reset if the battery is disconnected

These illustrations are for demonstration purposes only. Some messages may appear differently. See your Owner's Manual for more information.

Tire Pressure Monitoring System (TPMS)^{†19}



The TPMS indicator (🟢!) functions as both Low Tire Pressure Light and TPMS Malfunction Indicator. The indicator (🟢!) will illuminate if it detects one or more tires is significantly underinflated, the vehicle has a spare tire installed without TPMS or the outside temperature becomes significantly lower.

The LCD screen in the instrument cluster will display the Low Tire Pressure indicator (A) showing which tire(s) is underinflated. Inflate tire(s) to specifications using an accurate digital tire pressure gauge to turn off Low Tire Pressure Light (🟢!). See front driver's door jamb for PSI specification.


When there is a problem with the TPMS, the TPMS Malfunction Indicator (🟢!) will blink for approximately one minute then illuminate - see dealer for service.

QUICK TIPS

- Even with TPMS, tire pressure should be checked manually at least once a month. Only adjust tire pressure on "cold tires" that have been sitting for 3 hours or more, and tires that are not hot in temperature from direct sunlight or heat
- For proper maintenance and optimal fuel economy, maintain recommended tire inflation pressures and stay within the load limits and weight distribution recommended for your vehicle
- A significant drop in temperature can cause tire inflation pressures to drop, which may activate the TPMS light. Manually confirm tire pressures after significant changes in temperature or altitude

REMINDERS:

- Check the recommended tire pressure label located on the left side of driver's door jamb, visible when the door is open
- Consult your dealer for service if Low Tire Pressure Light remains illuminated after inflating your tire(s)



QR CODE

Tire Pressure Monitoring System Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Personal electronic devices (such as laptops, wireless chargers, remote start systems, etc.) may interfere with TPMS system, which may cause the Malfunction Warning Indicator (Check Engine Light) to illuminate.

For more information, refer to the Owner's Manual.

Drive Mode Integrated Control System

There are four distinct driving modes. Press the Drive Mode button **A** to select the desired mode.

ECO - This mode can help enhance electric energy efficiency by managing battery usage. The acceleration response may be slightly reduced in this mode

NORMAL - This mode balances drivability and efficiency

SPORT - This mode provides enhanced acceleration and dynamic drivability. The electric energy efficiency may decrease in this mode


SNOW - Press and hold the Drive Mode button to enter Snow mode

An indicator in the instrument cluster will illuminate to show which drive mode you have selected (no indicator will appear for the NORMAL mode).


QUICK TIPS

- To help reduce energy consumption:
 - Drive at a moderate speed, accelerating smoothly and at a moderate rate
 - Keep tires inflated to the recommended pressure and wheels aligned properly

For more information on driving modes, refer to section 6 in the Owner's Manual or contact your local dealership.



(Button located bottom left center of steering wheel)



QR CODE

Drive Mode Integrated Control Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Instrument Cluster LCD Modes

Press Mode button **A** to scroll through different Instrument Cluster LCD Modes.


Driving Assist: Displays information for Forward Collision-Avoidance Assist, Lane Keeping Assist, Blind-spot Collision-Avoidance Assist, Smart Cruise Control, Lane Following Assist, Highway Driving Assist

Trip Computer Mode: Displays driving information for consumption info, accumulated info, drive info, driving style and energy flow

Turn-by-Turn Mode: Displays the route guidance, destination info

User Settings Mode: Change settings for driver assistance, doors, lights, sound, convenience, service interval, other, reset

Information/Master Warning: Displays information on TPMS, engine temperature and warning messages related to the vehicle when one or more systems is not operating normally



(Buttons located on Steering Wheel - Type A shown)

Your vehicle's steering wheel buttons may differ from those in the illustrations.


Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

Trip Modes / Trip Computer

The Trip Computer is a driver information system that displays information related to driving, such as Average and Instant accumulated info, drive info, driving style and energy flow. It appears on the display when the Engine Start/Stop button is in the ON position.

To cycle through the instrument cluster modes **B**, press the Mode button **A**.

When in the Trip Computer mode **B**, press the Select/Reset (OK) button **C** to cycle through the screens. When displaying ACCUMULATED INFO or DRIVE INFO screens, press and hold the OK button **C** to reset to zero.



REMINDERS:

- Appearance of Trip Computer display may differ as equipped
- All stored driving information (except Odometer and Range) is reset if the battery is disconnected

QR CODES

Instrument Cluster's LCD Display Video



Steering Wheel Controls Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

User Settings* - Instrument Cluster

To enter the User Settings mode in the LCD Instrument Cluster Modes, press the Mode button **A** when the vehicle is at a standstill, Rotary Dial Shifter Knob in Park while the Engine Start/Stop button is in the ON position. Then select User Settings **B** by pressing the Move/Reset (OK) button.

You can navigate the selections on the display by pressing the OK button **B** up/down, and then selecting the item by pressing the OK button **B** again.



(Buttons located on Steering Wheel - Type B)

Driver Assistance:

- Driving Convenience
- Speed Limit
- Warning Volume
- Driver Attention Warning
- Driving Safety
- Parking Safety

Cluster:

- Cluster Theme
- Wiper/Lights Display
- Traffic Signs
- Icy Road Warning
- Cluster Voice Guidance Volume
- Welcome Sound

Lights:

- Illumination
- One Touch Turn Signal
- Ambient Brightness
- Ambient Light Color
- Headlight Delay
- High Beam Assist

Door:

- Automatically Lock
- Automatically Unlock
- Horn Feedback
- Power Tailgate
- Power Tailgate Opening Height / Speed
- Remote Window Control*

Convenience:

- Seat Easy Access
- Rear Occupant Alert
- Service Interval
- Welcome Mirror/Light
- Wireless Charging System*
- Auto Rear Wiper
- Passenger Airbag

Units:

- Speed Unit
- Temperature Unit
- Fuel Economy Unit
- Tire Pressure Unit Reset

Reset:

- Reset all settings

ECO/EV Vehicle:

- Utility Mode
- Smart Recuperation
- Lock Charging Cable

QR CODES

Vehicle & User Settings Video



Ambient, Mood & Theme Lighting Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Driving while distracted is dangerous and should be avoided. Do not attempt to change vehicle system settings while driving.

Vehicle Settings* - Infotainment System

To enter the Vehicle Settings mode in the Infotainment System **A**, press the SETUP button on the Infotainment System. Then press Vehicle  onscreen, which will take you to Vehicle Settings. Use the touchscreen to navigate through the menus.

Vehicle Settings:

- Driver Assistance
- Drive Mode
- Cluster
- Climate
- Seat
- Lights
- Door
- Digital Key
- Convenience



Service Interval Mode

To enter Service Interval mode settings, press the SETUP button on the infotainment system. Then press VEHICLE, CLUSTER, and SERVICE INTERVAL MODE. The system will display the number of miles remaining until next service is due, as well as type of service. When service is required, the following will be displayed: **Service Required**

QR CODES

Vehicle & User Settings Video



Vehicle Settings - Infotainment System Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Driving while distracted is dangerous and should be avoided. Do not attempt to change vehicle system settings while driving.

Illustrations are for demonstration purposes only. Some information may appear differently.

Charging Connector Lock Mode

The Charging Connector can be set to be locked or unlocked while in the charging inlet and charging. Go to the Vehicle Settings in the Infotainment System to set the connector to Lock Mode.

Press SETUP, ECO Vehicle or EV and then Charging Connector Locking Mode.

Select the preference: Always Lock, Lock While Charging, Do Not Lock.

QUICK TIPS

- If in lock mode & the doors are unlocked, the charging connector unlocks, but if the charging cable is not disconnected within 10 seconds, the connector will be automatically locked again
- If the charging connector is unlocked but all the doors are locked again, immediately, the connector will be automatically locked again
- If charging does not work, disconnect the connector and try charging again

REMINDERS:

- If the connector cannot be unlocked, refer to section 5 in the Owner's Manual on how to unlock the connector in an emergency
- To prevent charging cable theft, the charging connector cannot be disconnected from the inlet when the doors are locked or the charging connector is in the LOCK mode. Unlock all doors to disconnect the charging connector from the inlet. If the release button does not work even after the all doors are unlocked, pull the emergency lift cable in the engine compartment or refer to section in the Owner's Manual on how to unlock the connector in an emergency

Scheduled Charging*


Charging times can be set using the Infotainment System screen. You can also use the Scheduled Charging* feature on the Kia Access app.

Charging with the Kia Access app:

The Kia Access app can help you find the nearest charging station, and also displays charging status and Scheduled Charging information. On your smartphone, go to an app store or marketplace to download the Kia Access app.

REMINDER: When Scheduled Charging is set and the charger is plugged in, charging of the electric vehicle will not begin until the time and date set.

Deactivate Scheduled Charging - Depress the Deactivate Scheduled Charging button **A** to temporarily disable the scheduled charging feature when immediate charging is required.



(Located at exterior charging port)

QUICK TIP

When you press the Deactivate Scheduled Charging button the reserved charging setting will temporarily disable, and start immediate charging mode. If you need to completely deactivate the scheduled charge setting, change the setting from the Infotainment System, or the smartphone Kia Access app.

REMINDERS:

- For more detail and/or subsequent steps in charging your vehicle, including safety precautions that should be taken, please see the Owner's Manual
- Reserved charging may not be available at public chargers

QR CODES

EV Scheduled Charging Video




EV Charging Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

EV Mode - Infotainment System

EV Mode on the Infotainment System screen allows you to navigate through menus that include information on available driving range, energy usage, energy information, charging and climate settings, and EV settings.



- Energy Information
- Next Departure
- Scheduled Charging and Climate
- Vehicle to Load (V2L)
- Nearby Stations
- Settings

QR CODE

EV Mode on the Infotainment System Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

See the Car Infotainment System Quick Reference Guide for more detailed information on screens.

These illustrations are for demonstration purposes only.

Some items may appear different or vary in illustrations.

Charging the EV

AC Charger Level 1 Charging - "Trickle" Charge

An AC Charger Level 1 or "trickle" charger is the most common type of charging system for an EV. This type of charger uses 110 volts of household electricity and takes up to 9 hours for a full charge.

Indicators:

- A** ICCB plug
- B** **Power** - When the charger and AC plug is plugged in and functioning normally, the indicator will turn green. Indicator is red if plug temperature sensor warning is present
- C** **Charge** - Indicates that the vehicle is charging
- D** **Fault** - Indicates charge failure
- E** **Charge Level** - Indicates the level of charge: 6A, 8A, 10A, 12A
- F** ICCB - In-Cable Control Box

REMINDER: Do not use an extension cord. Plug trickle charger directly into wall socket. Do not charge to a receptacle that is old, damaged, corroded or cracked. When using outdoors, be careful not to expose it to external environments such as rain, snow, and high temperatures.

AC Charger Level 2 Charging - "Normal" Charge


An AC Charger Level 2 or "normal" 240-volt charger is the recommended charging system for the EV. This type of charger uses 240 volts of electricity and takes approximately 2.5-3 hours for a full charge (Based on Kia Corporation testing with SAE J1772 charger performed at 3.3kW). This charger may be able to be installed at your home by a qualified electrician or found at a public charging station.

QUICK TIP

A Level 2 or "normal" 240-volt charger is recommended for regular charging of the vehicle.

REMINDERS:

- Shape of charger and how to use the charger may be different for each manufacturer. Please see Owner's Manual for more information
- For more detail and/or subsequent steps in charging your vehicle, please see the Owner's Manual
- Distance to empty may depend on many factors such as the charge amount of the high voltage battery, weather, temperature, durability of the battery, geographical features, and driving style
- Operating the air conditioner or heater excessively may reduce the distance to empty



QR CODE

EV Charging Video





Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos



Charging the EV (Continued)

To charge the EV using a normal/trickle charger:

1. Connect the ICCB **A** plug to an electrical outlet
2. Check if the power light (green) **B** on the ICCB turns on
3. Press the brake pedal and engage the parking brake
4. Turn off all switches, put the shift lever in P (Park), and turn off the vehicle
5. Open the charging door **C** by pressing the charging door (Ensure doors are unlocked)
6. Remove any dust or water on the charging connector and charging inlet **D**
7. Hold the charging connector handle **E** and connect it to the vehicle's charging inlet **D** by pushing the connector until you hear a clicking sound
8. Charging begins automatically (Ensure the charge indicator light **S** is illuminated on your instrument cluster, indicating the vehicle is charging)



(Door located at front of vehicle)



(Message on Cluster Display)

Checking the Charging Status

The charging status can be checked by viewing the charging status indicator on the dash panel. The lights will progressively become lit as the vehicle approaches a full charge.

After charging has started, the light turns green and the estimated charging time is displayed on the Instrument Cluster LCD **F** for about 1 minute. It is also displayed when the driver's door is opened with charging in progress. When fully charged, the light turns off.

REMINDER: For more detail and/or subsequent steps in charging your vehicle, please see section 1 in the Owner's Manual.

Regenerative Braking with Paddle Switches

The regenerative braking system charges the battery when coasting or when you use the brakes to stop the vehicle. Use the paddle switches to adjust the regenerative braking level from 0 to 3 during decelerating or braking. The level will be displayed on the instrument cluster **A**.

- Pull the left paddle switch **B** to increase regenerative braking and deceleration
- Pull the right paddle switch **C** to decrease regenerative braking and deceleration

The paddle switches do not operate when:



- Both paddle switches are pulled at the same time
- The vehicle is decelerating by depressing the brake pedal
- Cruise Control or Smart Cruise Control (SCC) is active

i-Pedal

i-Pedal driving controls the vehicle speed by the accelerator pedal, both acceleration and deceleration. To activate i-Pedal:

- Pull the left side paddle switch **B** to Level 3 regenerative braking (see indicator on Instrument Cluster)
- Then pull the left side paddle switch **B** once again when the regenerative braking level is set to Level 3

The i-Pedal indicator symbol will be illuminated on the instrument cluster.



QUICK TIP

Each of the different Drive Modes allows the regenerative braking level to be set at the driver's preference.

REMINDER: The driver's seat belt must be fastened to operate i-pedal driving.

Do not solely rely on i-pedal driving to stop the vehicle, as it may not be able to stop the vehicle depending on vehicle and road conditions. Always use pedal braking when necessary. Pay attention to the road condition ahead and apply the brake if necessary.

QR CODES

Regenerative Braking - Paddle Switches, Drive Mode Video



Regenerative Braking - i-Pedal Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

For more information on regenerative braking, one-pedal driving or the Smart Regeneration System, please refer to your Owner's Manual.

Regenerative Braking with Paddle Switches (Continued)

One pedal driving

One pedal driving increases the regenerative braking amount to above level 3 and enables you to come to a full stop by pulling down the left paddle.

- Pull and hold the left paddle switch **A** while coasting
- When the vehicle speed is above 2 mph, release the left paddle switch **A** for less than 0.5 seconds to return to the previously set level of regenerative braking
- When the vehicle speed is below 2 mph, the brake and hold system stops the vehicle even though the left paddle switch is released
- While one-pedal driving is active, the driver can stop the vehicle by pulling the paddle switch

REMINDER: The driver's seat belt must be fastened to operate one-pedal driving.

Do not solely rely on one-pedal driving to stop the vehicle, as it may not be able to stop the vehicle depending on vehicle and road conditions. Pay attention to the road condition ahead and apply the brake if necessary.



Smart Regeneration System

This system automatically adjusts the regenerative braking level based on a vehicle being detected in front of the Niro EV.

- Activate Smart Regeneration in the User Settings* or the Vehicle Settings* mode. AUTO **B** will be displayed on the instrument cluster. AUTO regenerative brake adjusts regenerative braking based on the distance with the vehicle in front and its speed
- Pull and hold the right paddle switch **C** for more than 1 second to turn on/off the automatic change of the regenerative braking. The minimum regenerative braking level can be adjusted when in AUTO mode by using the left and right paddle switch

Smart Regeneration is a supplemental system for the driver's convenience. Do not solely rely on this system to stop the vehicle or avoid collisions. Always cautiously look ahead to prevent unexpected or sudden situations.

For more information on regenerative braking, one-pedal driving or the Smart Regeneration System, please refer to your Owner's Manual.



(Indicator on lower left corner of Instrument display)

QR CODE

Regenerative Braking -
Paddle Switches, Drive
Mode Video



Regenerative Braking -
Smart Regeneration Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

EV Charge Transfer / Vehicle to Load (V2L)*

EV Charge Transfer / Vehicle to Load (V2L) allows you to use the vehicle's high voltage battery to power electrical devices like home appliances or other electronic devices. V2L can also be used to charge items like electric bikes or another electric vehicle.

If equipped, there are two ports in the interior and exterior. The interior port **A** is under the rear seat and the other is the charging port for your EV.

If your EV's high-voltage battery discharges to the limit set, the system will automatically stop supply to the ports. You can set your EV's battery discharge limit from the EV screen. From the infotainment system home screen, press the EV button. Then press EV Charge Transfer.



Interior Port - The EV Power button needs to be on to operate the port. Use the Smart Key fob mechanical key to unlock the power outlet cover **B**. Check the indicators on the port to ensure power is on.

Exterior Port - Open the cover of the V2L connector **C** and connect your appliance or electronic device. Connect the V2L connector to the charging inlet on the EV, and press the button **D** on the connector.


REMINDER: Maximum wattage is 1.9 kW, or 1,900 watts.

Refer to section 1 in the Owner's Manual for more information.

These illustrations are for demonstration purposes only. Some items may appear different or vary in illustrations.



(Trickle / normal charge shown)



QR CODE

EV Charge Transfer /
Vehicle to Load (V2L)
Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

Forward Collision-Avoidance Assist (FCA)^{†3}

FCA is designed to detect and monitor a vehicle ahead or detect a pedestrian in the roadway through front view camera recognition and front radar signals to warn the driver that a collision is imminent and, if necessary, temporarily apply emergency braking. Initially, FCA provides Collision Warning when it detects a potential collision with a vehicle, pedestrian, or cyclist, emitting an audible warning and visual alert on the instrument cluster.

If FCA detects that the collision risk has increased, Forward Collision-Avoidance Assist (FCA) automatically applies the brakes to reduce your speed, potentially helping to reduce the effects of a possible collision.

With the turn signal on, if it detects a potential collision, **Junction Turning** **A** may help to avoid the collision with an oncoming vehicle in an adjacent lane when turning left by applying emergency braking.



FCA Settings:




- FCA is on by default in most Kia models. FCA can be turned on/off by going to the User Settings* in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- To access User settings* in the Instrument Cluster** - Press the Mode button **B** on the Steering Wheel to toggle to User Settings. Press the OK button **C** up/down to toggle to Driver Assistance and Forward Safety
- To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select Driver Assistance, Driving Safety and Forward Safety
- To adjust the FCA initial warning activation time, go to User Settings **G**, Driver Assistance, Warning Timing, then select Standard or Late, depending on your Kia model:
 - Standard:** This setting allows for a nominal amount of distance between the vehicles before the initial warning occurs
 - Late:** Reduces the amount of distance between the vehicles before the initial warning occurs

FCA/FCW will become active when the:


- Ignition is on or the Engine Start/Stop button* is ON
- Vehicle is traveling faster than 5 mph
- Electronic Stability Control (ESC) is ON

Forward Collision-Avoidance Assist (FCA) is not a substitute for safe driving and may not detect all objects in front of the vehicle. Always drive safely and use caution.

Actual User Settings steps may vary by model. Refer to section 6 in the Owner's Manual for more information.



(Buttons located on Steering Wheel - Type B)



(Junction Turning)

QR CODE

Forward Collision-Avoidance Assist (FCA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

QUICK TIP

The Warning Volume can be adjusted in the User Settings **G** in the Instrument Cluster or the Vehicle Settings* on the infotainment system. Go to Driver Assistance, Warning Method, then Warning Volume.

REMINDERS:

- FCA will be activated by default when the ignition is cycled ON, even when previous setting was OFF
- If FCA is operating and ESC (Electronic Stability Control) is turned off, FCA is automatically turned off
- When FCA is off, the FCA warning indicator is on in the Instrument Cluster **G**

Blind-spot Collision Warning (BCW)*†3

BCW uses rear corner radar sensors in the rear bumper to monitor and warn the driver in certain situations if it detects an approaching vehicle in the driver's blind spot area, before changing lanes and before exiting a parallel parking space. BCW provides Collision Warning when it detects a potential collision with a vehicle, emitting an audible warning and visual alert on the outside rearview mirrors. On select Kia models, when exiting a parallel parking space and BCW detects that the collision risk has increased, BCW can help avoid a collision by applying the brakes.

Vehicle detection: When another vehicle is detected within BCW warning boundary **A**, an indicator will illuminate on the outside rearview mirrors **B**.

Collision warning: When vehicle detection warning is on and the driver activates a turn signal, a flashing indicator will illuminate on the outside rearview mirrors and the system will sound a warning.



Collision-Avoidance Assist*: On select Kia models, when collision warning has already occurred, and the collision risk has increased, BCW can help avoid a collision by applying the brakes. Your vehicle needs to be traveling less than 2 mph, and the approaching vehicle is traveling less than 3 mph.

BCW Settings:

- BCW can be turned on/off by going to the User Settings* in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access User settings* in the Instrument Cluster** - Press the Mode button  **C** on the Steering Wheel to toggle to User Settings . Press the OK **D** up/down to toggle to Driver Assistance, Driving Safety, then Blind-spot Safety
- **To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select Driver Assistance, Driving Safety, then Blind-spot Safety

QUICK TIPS

- The Warning Volume can be adjusted in the User Settings  in the Instrument Cluster or the Vehicle Settings* on the Infotainment System. Go to Driver Assistance, Warning Method, then Warning Volume
- BCW will activate when:
 - BCW is turned on
 - Other vehicles are detected on the rear sides of the vehicle
 - Collision Warning: Vehicle speed is above approximately 12 mph and the speed of the vehicle in the blind spot is above 7 mph



(Buttons are located left of the Steering Wheel)

QR CODE

Blind-spot Collision Warning Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

When engaged, BCW is a supplemental system. Do not solely rely on this system and always pay attention to the road and its conditions.

The images on this page are for illustrative purposes only and may not reflect actual feature or operation.

Refer to section 6 in the Owner's Manual for more information.

REMINDERS:

- When BCA is ON and the ignition is cycled, BCW returns to its previous state
- If the turn signal is turned on to make a left turn at an intersection, BCW may warn the driver regardless of driver's intentions. Maintain a proper distance from oncoming vehicles

Blind-spot Collision-Avoidance Assist (BCA)*†‡

BCA uses rear corner radar sensors in the rear bumper to monitor and warn the driver in certain situations if it detects an approaching vehicle in the driver's blind spot area, before changing lanes and before exiting a parallel parking space. Initially, BCA provides Collision Warning when it detects a potential collision with a vehicle, emitting an audible warning and visual alert on the outside rearview mirrors. If the system detects that the collision risk has increased, BCA can help avoid a collision by applying the brakes.

Vehicle detection: When another vehicle is detected within BCW warning boundary **A**, an indicator will illuminate on the outside rearview mirrors **B**.

Collision warning: When vehicle detection warning is on and the driver activates a turn signal, a flashing indicator will illuminate on the outside rearview mirrors and the system will sound a warning.



Collision-Avoidance Assist: When collision warning has already occurred, and the collision risk has increased, BCA can help avoid a collision by applying the brakes.

BCA Settings:

- BCA can be turned on/off by going to the User Settings* in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access User settings* ⚙ in the Instrument Cluster** - Press the Mode button  **C** on the Steering Wheel to toggle to User Settings ⚙. Press the OK  up/down to toggle to Driver Assistance, Driving Safety, then Blind-spot Safety
- **To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select Driver Assistance, Driving Safety, then Blind-spot Safety

QUICK TIPS

- The Warning Volume can be adjusted in the User Settings ⚙ in the Instrument Cluster or the Vehicle Settings* on the Infotainment System. Go to Driver Assistance, Warning Method, then Warning Volume
- BCA will activate when:
 - BCA is turned on
 - Other vehicles are detected on the rear sides of the vehicle
 - Vehicle speed is above approximately 12 mph and the speed of the vehicle in the blind spot is above 7 mph



(Buttons are located left of the Steering Wheel)

QR CODE

Blind-spot Collision-Avoidance Assist (BCA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

When engaged, BCA is a supplemental system. Do not solely rely on this system and always pay attention to the road and its conditions.

The images on this page are for illustrative purposes only and may not reflect actual feature or operation.

Refer to section 6 in the Owner's Manual for more information.

REMINDERS:

- BCA will not issue a warning if the vehicle speed is 6 mph or more above the surrounding vehicles
- When BCA is ON and the ignition is cycled, BCA returns to its previous state
- If the turn signal is turned on to make a left turn at an intersection, BCA may warn the driver regardless of driver's intentions. Maintain a proper distance from oncoming vehicles

Lane Keeping Assist (LKA)^{†3}

Lane Keeping Assist (LKA) is designed to detect the lane markers on the road with a front view camera on the windshield, and may assist the driver's steering to potentially help keep the vehicle in the lane. When turned on, the instrument cluster indicator  will initially illuminate white. It will remain white when the vehicle is traveling slower than 40 mph or when LKA does not detect the lane markers. When LKA detects the lane markers and can assist the steering, the LKA icon will illuminate green.

If the LKA detects that you are moving outside of your lane, without using the turn signal, LKA may give an audible warning and display Lane Departure Warning on the instrument cluster or LKA may provide steering inputs, trying to prevent the vehicle from moving outside its lane.

Hands-off Warning - If the driver takes their hands off the Steering Wheel for several seconds, a warning message will appear on the Instrument Cluster, and if hands on the Steering Wheel is not detected continually, LFA will be turned off with additional emergency warning.

LKA Settings:


- Press and hold the Lane Driving Assist button **A** to turn LKA on or off, when it is first enabled in the User Settings* in the Instrument Cluster or Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- To access User settings* in the Instrument Cluster** - Press the Mode button  **B** on the Steering Wheel to toggle to User Settings . Press the OK button **C** up/down to toggle to Driver Assistance and then Lane Safety
- To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select Driver Assistance, Driving Safety and then Lane Safety

LKA will operate under the following conditions:

- The vehicle speed exceeds approximately 40 mph
- LKA recognizes both sides of the lane markers the vehicle is traveling in
- The vehicle is between the lane markers





When LKA detects the lane markers, both lanes are displayed white



When LKA does not detect the lane markers, the lanes are displayed gray



When LKA detects the vehicle moving outside of the lane being traveled in, a yellow lane marker will illuminate either on the left or right lane (shown in both images above)



(Buttons are located left of the Steering Wheel)

QR CODE

Lane Keeping Assist (LKA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

QUICK TIP

The Warning Volume can be adjusted in the User Settings  in the Instrument Cluster or the Vehicle Settings* on the infotainment system. Go to Driver Assistance, Warning Method, then Warning Volume

REMINDERS:

- LKA will not issue a warning if the turn signals or hazard lights are activated
- When the ignition is cycled, LKA will return to the previously set state

Lane Keeping Assist is not a substitute for safe driving and may not always alert the driver if the vehicle is driven outside of its lane. Always drive safely and use caution.

Actual User Settings steps may vary by model. Refer to section 6 in the Owner's Manual for more information.



For illustrative purposes only. Your actual display, buttons and/or features may vary.

Driver Attention Warning (DAW)^{†4}

Driver Attention Warning is designed to alert the driver if it detects inattentive driving practices and, in certain situations, can give a warning signal to take a break from driving. A message, "Consider taking a break," **A** appears on the LCD and a warning sounds to suggest the driver take a break when the driver's attention level becomes low.

DAW Settings:


- DAW can be turned on/off by going to the User Settings* in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access User settings* in the Instrument Cluster** - Press the Mode button **B** on the Steering Wheel to toggle to User Settings **A**. Press the OK **C** up/down to toggle to Driver Assistance, then Driver Attention Warning and select Inattentive Driving
- **To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select Driver Assistance, then Driver Attention Warning and select Inattentive Driving



When engaged, Driver Attention Warning is not a substitute for safe driving and may not detect all instances of inattentive driving practices. Failure to pay attention to travel conditions and vehicle operation could result in loss of vehicle control. Always drive safely and use caution.

Images are for illustrative purposes only and may not reflect actual feature or operation.

Refer to section 6 in the Owner's Manual for more information.



(Steering Wheel buttons on left side)

Leading Vehicle Departure Alert (LVDA)^{†3}

Leading Vehicle Departure Alert is designed to inform the driver when the vehicle in front starts moving or departs from a stop. When LVDA is on, your vehicle is stopped and detects that the leading vehicle is driving away, LVDA sounds an alert to let you know you can start driving. If no action is taken after the vehicle in front drives away, then a message **D** will appear on the Instrument Cluster LCD.

LVDA User Settings:

- To turn LVDA on, press the Mode button **B** on the Steering Wheel, and go to User Settings **A** in the Instrument Cluster. Press the Move (OK) button **C** up/down and select Driver Assistance, then press the OK button **C** to select. Go to Driver Attention Warning and then Leading Vehicle Departure Alert
- Some models access settings through the Vehicle Settings in the infotainment system. Press the Setup hard key on the infotainment system, then press **VEHICLE** **A** on the screen to enter Vehicle Settings. Press Driver Attention Warning, then Leading Vehicle Departure Alert



Images are for illustrative purposes only and may not reflect actual feature or operation. Refer to section 6 in the Owner's Manual for more information.

QR CODES

Driver Attention Warning (DAW) Video



Leading Vehicle Departure Alert (LVDA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

REMINDERS:

- When the ignition is cycled, the system returns to its previous state, on or off
- Always check the front of the vehicle and road conditions before departure

The Leading Vehicle Departure Alert system is not a substitute for safe and proper driving. Always drive safely and use caution.

Navigation-based Smart Cruise Control (NSCC)*†3,7

Navigation-based Smart Cruise Control will help automatically adjust vehicle speed when driving on highways with posted speed limits by using road information from the navigation system, while Smart Cruise Control (SCC) is operating.

Smart Cruise Control is designed to maintain a predetermined distance from vehicles detected ahead by automatically adjusting the driving speed as needed. When traffic is detected, the vehicle will slow down to maintain a set distance behind traffic without depressing the accelerator or brake pedal.


Highway Curve Zone Auto Slowdown: NSCC can automatically adjust the vehicle speed when it detects a curved road ahead and when it receives road information from the navigation system. When NSCC detects a curve ahead, NSCC activates and reduces the vehicle speed, and the NAV icon changes to AUTO and turns green **A** in the instrument cluster. When the vehicle passes the curved road, the vehicle may return to its previously set speed.

Highway Auto Speed Change: If the set speed is set to the current posted speed limit on the highway during NSCC operation, the set speed is changed automatically whenever the posted speed limit changes and when it receives information from the navigation system.


SCC Operation: With SCC turned on and activated, the vehicle distance set, and the system detects a vehicle slowing or stopping, the system can bring the vehicle to a complete stop. When the vehicle ahead starts to move forward, SCC re-engages. If the vehicle ahead stops for more than 3 seconds, the accelerator pedal or the **+||->** button **B** must be pressed to start moving the vehicle. SCC will adjust acceleration based on the drive mode selected in the Drive Mode Integrated Control system.

NSCC Settings:

- NSCC can be turned on/off by going to the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select Driver Assistance > Driving Convenience > Highway Auto Speed Change



(Displays on LCD screen)



NSCC system is a supplemental system and is not a substitute for safe driving. It is the responsibility of the driver to always check the speed and distance to the vehicle ahead.

See section 6 in the Owner's Manual for more information. Images are for illustrative purposes only and may not reflect actual feature or operation.

QR CODES

Navigation-based Smart Cruise Control (NSCC) Video



Smart Cruise Control with Overtaking Acceleration Assist Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Navigation-based Smart Cruise Control (NSCC)^{*†3,7} (continued)

NSCC Settings (continued):

To set the vehicle distance: Press the Vehicle Distance button **C** on the steering wheel (see previous page). Each time you press the button, the vehicle distance will change **D**, indicated by the number of bars that appear on the display **A**.


To pause/resume NSCC operation: Depress the brake pedal or press the Pause/Resume button **+||- B**. The cruise indicator on the instrument cluster will change.

QUICK TIPS

- If your vehicle speed is between 0-20 mph when you press the Driving Assist button to turn NSCC on, the set speed will be set to 20 mph
- When following a vehicle, the system can automatically adjust your cruise speed based on the vehicle detected in front. It will even bring the vehicle to a complete stop if necessary. If the vehicle remains at a standstill for more than 3 seconds, you must depress the accelerator pedal or press the +/- switch up/down to start the vehicle
- NSCC will not activate until the brake pedal has been depressed at least once after ignition ON or engine start
- The navigation part of Smart Cruise Control does not function when a destination is not set on the infotainment navigation system

REMINDERS:

- CRUISE indicator must be ON in order to operate SCC
- The speed setting will need to be reset when ignition is cycled
- The distance settings are approximations and may vary depending on vehicle speed. See the owner's manual for more information
- SCC is also canceled when the driver's door is opened, gear shift is changed out of D (Drive), Electronic Parking Brake (EPB) is activated and various other conditions. See owner's manual for other conditions
- If SCC is left on, it can be activated inadvertently. Keep the system off when not in use to avoid setting a speed which the driver is not aware of
- The navigation part of NSCC does not function when a destination is not set on the infotainment navigation system.
- NSCC requires an active navigation subscription
- NSCC is only available on controlled access roads and highways



(Distances are approximate and vary depending on vehicle speed)


Intelligent Speed Limit Assist (ISLA)*†3

Intelligent Speed Limit Assist is designed to use the information from the posted speed limit and the navigation system to inform the driver of the speed limit.

When ISLA is on and active, LFA will display an alert on the Instrument Cluster LCD of the detected speed limit **A**. If the vehicle's current speed exceeds the detected speed limit, a warning will sound and the vehicle's current speed will blink on the LCD.

ISLA Settings:

- To enable ISLA on, press the **SETUP** key/button on the Infotainment System. Select the **VEHICLE** button to enter the Vehicle Settings. Select DRIVER ASSISTANCE, then SPEED LIMIT.
- Select one of the three modes:
 - Speed Limit Assist:** Informs the driver of the posted speed limit, displays a message to change the speed to help the driver stay within the posted speed limit, and informs the driver to change set speed of Manual Speed Limit Assist or Smart Cruise Control to help the driver stay within the speed limit
 - Speed Limit Warning:** Informs the driver of the posted speed limit **A** and warns the driver when the vehicle is traveling faster than the posted speed limit
 - Off:** ISLA is disabled



QUICK TIP

You can set a speed limit offset to the posted speed limit by going to Vehicle Settings, Driver Assistance, Speed Limit, then Speed Limit Offset. Set the offset to "0" if you want the vehicle to travel at the posted speed limit when ISLA is on

REMINDERS:

- Vehicle must be parked and in a safe location to change the speed settings
- Additional information may be displayed if additional road sign information is detected

See section 6 in the Owner's Manual for more detailed information, limitations and conditions.

QR CODE

Intelligent Speed Limit Assist (ISLA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Head-Up Display (HUD)*†3

The Head-Up Display (HUD) is a semi-transparent display that projects a snippet of information from the instrument cluster and navigation system* onto the windshield glass.

To turn the HUD ON or OFF, go to User Settings* in the LCD Modes.

The HUD displays:


- Turn By Turn (TBT) navigation information*
- Road signs*
- Speedometer
- SCC set speed information
- SCC Vehicle Distance information
- Blind-spot Safety
- Lane Safety
- Highway Driving Assist information*
- Lane Following Assist
- HDA system automatic speed setting information*
- Warning lights (low fuel)
- AV mode information

Head-Up Display (HUD) User Settings

Drivers can adjust the HUD settings from Vehicle Settings in the Infotainment System. Press SETUP, VEHICLE and HEAD UP DISPLAY.

HUD settings include:

- Display Height: Adjust the height of the HUD image on the windshield glass
- Rotation: Adjust the degree of HUD rotation
- Brightness: Adjust the intensity of the HUD brightness
- Contents Selection: Activate or deactivate HUD content
- Speedometer Size: Choose the size of the HUD speedometer
- Speedometer Color: Choose the color of the HUD speedometer



QR CODE

Head-Up Display (HUD) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

REMINDER: The HUD image on the windshield glass may not be visible in these cases:

- The driver has poor sitting posture
- The driver is wearing polarized sunglasses
- There is an object covering the HUD
- Driving on a wet road
- Excessive lighting inside or outside the vehicle
- Modifications made to the windshield, such as tinting or other aftermarket treatments, could affect the HUD. When replacing the front windshield glass of vehicles equipped with the HUD, owners must replace it with windshield glass designed for HUD operation. Otherwise, duplicated images may be displayed on the windshield glass
- If Turn By Turn (TBT) navigation information is selected as HUD content, TBT information will not be displayed on the LCD

The Head-Up Display is a supplemental system. Do not solely rely on the system, always drive safely, and pay attention to the driving conditions on the road.

Images are for illustrative purposes only and may not reflect actual feature or operation.


See section 4 in the Owner's Manual for more information.

Lane Following Assist (LFA)^{†3}

Lane Following Assist (LFA) is designed to help ensure that the vehicle stays centered in its lane **(A)** by monitoring the detected lane markings ahead and adjusting the steering. The instrument cluster indicator will initially illuminate white **(A)** when turned ON. It will remain white when LFA does not detect the lane markers. When LFA detects the lane markers and can assist the steering, the Lane Following Assist icon will illuminate green **(B)**.

Hands-off Warning - If the driver takes their hands off the Steering Wheel for several seconds, a warning message will appear on the Instrument Cluster. And if hands on the Steering Wheel is not detected continually, LFA will be turned off with additional emergency warning.

- Press the Lane Safety button **(C)** to turn LFA on or off, when it is first enabled in the User Settings* in the Instrument Cluster or Vehicle Settings* in the Infotainment System
- LFA will operate only when these conditions are met:
 - LFA recognizes both sides of the lane markers the vehicle is traveling in
 - The vehicle is traveling slower than 90 mph



LFA is supplemental. Do not solely rely on LFA and always pay attention to the road and its conditions.

Actual User Settings steps may vary by model. See section 6 in the Owner's Manual for more detailed information, limitations and conditions.

QUICK TIP

The Warning Volume can be adjusted in the User Settings in the Instrument Cluster or the Vehicle Settings* on the infotainment system. Go to Driver Assistance, Warning Method, then Warning Volume.

REMINDER: LFA is not a substitute for safe and proper driving. Always drive safely and use caution.

Highway Driving Assist (HDA)^{†3}

Highway Driving Assist (HDA) is designed to adjust the speed of the vehicle when driving on limited/controlled access highways/freeways.


When HDA is activated **(F)** and the conditions are met, the HDA indicator **(E)** will illuminate green. If proper conditions are not met, HDA will be in standby mode and the indicator light **(E)** will illuminate white. When in operation, and if both lanes are recognized, the Instrument Cluster will show the lanes illuminated white and the HDA indicator illuminated green **(D)**.

HDA User Settings:

To enable HDA, access settings through the Vehicle Settings in the Infotainment System. Press the **SETUP** key, then press **VEHICLE** on the screen to enter Vehicle Settings. Select Driver Assistance, Driving Convenience and then Highway Driving Assist.

HDA will operate only when these conditions are met:

- The vehicle is traveling slower than 110 mph or the highway speed limit
- When driving on limited/controlled access highways/freeways
- When the SCC is on and operating
- When the SCC speed is set to current posted highway speed or slower



QR CODES

Lane Following Assist (LFA) Video



Highway Driving Assist (HDA) Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Highway Driving Assist is not a substitute for safe driving, may not detect all objects around the vehicle, and only functions on certain federal highways. Always drive safely and use caution.

See section 6 in the Owner's Manual for more detailed information, limitations and conditions.

Images are for illustrative purposes only and may not reflect actual feature or operation.



REMINDER: When the ignition is cycled, the system returns to its previous state, on or off.



(Buttons located on steering wheel)

Rear View Monitor (RVM)^{†3}

Rear View Monitor is a supplemental system that displays the view behind the vehicle through the audio system screen while the vehicle is in Reverse.

The Rear View Monitor activates when the:

- POWER button is in the ON/READY position
- Rotary Dial Shifter Knob is in the R (Reverse) position



REMINDERS:

- The images shown are for illustration purposes only and may not reflect actual operation
- While camera is active, only the Audio System can be operated on the Steering Wheel and Infotainment System. All other features are disabled

Rear View Monitor is not a substitute for proper and safe backing-up procedures. Rear View Monitor may not display every object behind the vehicle. Always drive safely and use caution when backing up.


Refer to section 6 in the Owner's Manual for more information.

Safe Exit Warning (SEW)^{†3}


Safe Exit Warning (SEW) can help prevent passengers from opening their door by displaying a warning message on the Instrument Cluster and sounding an audible warning when a vehicle is detected, approaching from behind, and after your vehicle has stopped.

SEW Settings:

- SEW can be turned on/off by going to the User Settings* in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access User settings* in the Instrument Cluster** - Press the Mode button  **A** on the Steering Wheel to toggle to User Settings . Press the OK button **B** up/down to toggle to Driver Assistance, then Exit Safety
- **To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select Driver Assistance, Driving Safety, then Exit Safety.



REMINER: The setup of SEW will be maintained, as selected, when the ignition is cycled.



(Buttons located on steering wheel)

When engaged, SEW is not a substitute for one's attention and may not detect all objects surrounding the vehicle. Always pay attention to traffic and to the area around your vehicle when exiting the vehicle. Refer to section 6 in the Owner's Manual for more information.

QR CODE

Safe Exit Warning (SEW) Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Remote Smart Parking Assist (RSPA)*†‡

Remote Smart Parking Assist (RSPA) uses the vehicle sensors to help park and exit parking spaces remotely from inside or outside the vehicle.


To park with Smart Parking (from inside the vehicle):

- Press and hold the Parking/View button **A** to turn on Remote Smart Parking Assist
- Drive until you find your preferred parking spot, and come to a complete stop
- Operating instructions will be displayed on the Infotainment System screen
- Take your hands off the steering wheel to allow RSPA to operate
- Then press and hold the Parking/View button **A** for RSPA to operate and park the vehicle - hold the button until the vehicle has finished parking. The transmission will automatically shift into Park and the parking brake will be engaged



To park and exit with Remote Parking (from outside the vehicle), you will use the Smart Key:

- While in the vehicle, with the vehicle stopped in front of the parking space, vehicle aligned, and the transmission in Park, press and hold the Parking/View button **A**
- Select REMOTE on the infotainment system screen. When the message UNDER REMOTE CONTROL appears, exit the vehicle with the Smart Key on hand. Ensure all doors are closed
- The emergency lights will blink to when the system is ready to be activated
- Press and hold either the Forward **B** or Backward **C** button on the Smart Key, depending on how you want to park, and the vehicle will move in the direction of whichever button you press




QR CODE

Remote Smart Parking Assist (RSPA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 6 in the Owner's Manual for more information.



Remotely moving forward or backward

REMINDERS:


- Remote Smart Parking Assist will only operate if you are within 13 feet of the vehicle, with the Smart Key in your possession
- Remote Smart Parking Assist will not function when:
 - There is a parking space open, with a vehicle on one side only
 - When trying to park in a diagonal space
 - When the parking space is too narrow or near a wall

Remote Smart Parking Assist (RSPA)*†3 (Continued)

To turn off RSPA at any point while it's operating, press the Parking View button **A** or Parking Safety button **B**, press the Park button on the Rotary Dial Shifter **C** or press the Remote Start button **D** on the Smart Key.

To adjust the warning volume, press the SETUP key/button on the Infotainment System, **VEHICLE**, DRIVER ASSISTANCE then WARNING VOLUME.

Refer to section 6 in the Owner's Manual for more information.



QR CODE

Reverse Parking Collision-Avoidance Assist (PCA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Reverse Parking Collision-Avoidance Assist (PCA)†3

Reverse Parking Collision-Avoidance Assist (PCA) is designed to detect certain objects/pedestrians behind the vehicle and issues an audible warning and/or applies emergency braking to help reduce the possibility of a collision when the vehicle is in reverse. When Reverse Parking Collision Avoidance Assist activates, a line appears behind the vehicle image **E** on the instrument cluster LCD.

PCA User Settings:

To turn PCA on, press the SETUP key/button on the Infotainment System. Select **VEHICLE**, DRIVER ASSISTANCE, PARKING SAFETY. Select from one of the three modes:


- **Rear Active Assist** - PCA will warn the driver with an audible alert and may apply temporary braking
- **Rear Warning Only** - PCA will warn the driver with an audible alert
- **Off** - PCA is disabled

To adjust the warning volume, press the SETUP key/button on the Infotainment System, **VEHICLE**, DRIVER ASSISTANCE, then WARNING VOLUME. Select high, medium, low.

To set the warning timing, press the SETUP key/button on the Infotainment System, **VEHICLE**, DRIVER ASSISTANCE then WARNING TIMING:

- **Standard**: Maximizes the amount of distance between the vehicles before the initial warning occurs
- **Late**: Reduces the amount of distance between the vehicles before the initial warning occurs

REMINDER: Adjusting the Warning Timing and Warning Volume may adjust timing and volume levels for other driving assist systems.



(Message on Cluster Display)




Images are for illustrative purposes only and may not reflect actual feature or operation.

Refer to section 6 in the Owner's Manual for more information.

Forward/Reverse Parking Distance Warning (PDW)*†3

Forward/Reverse Parking Distance Warning (PDW)* is a supplemental system that is designed to assist the driver by chiming if any object is detected within the sensing area in the rear and rear side of the vehicle when backing up.

- To turn PDW on, press the Parking Safety button **A** (LED illuminated). To turn PDW off, press again **A** (LED not illuminated)
- PDW will activate when the ignition is on/ready and the vehicle is in D (Drive) or R (Reverse)
- Parking Distance Warning Auto On** - To set the parking distance warning to be on at low speeds, enable it in the User Settings* in the Instrument Cluster or the Vehicle Settings in the infotainment system
- To enable in User settings* in the Instrument Cluster** - Press the Mode button **B** on the Steering Wheel to toggle to User Settings. Press the OK button **C** up/down to toggle to Driver Assistance, then Parking Safety, and select Parking Distance Warning Auto On
- To enable in Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select Driver Assistance, then Parking Safety and select Parking Distance Warning Auto On



(Buttons located on steering wheel)

QUICK TIP

The Warning Volume can be adjusted in the User Settings in the Instrument Cluster or the Vehicle Settings on the Infotainment System. Go to Driver Assistance, Warning Method, then Warning Volume.

REMINDERS:

- If the vehicle is moving at speeds over 3 mph, PDW may not activate correctly
- When more than two objects are sensed at the same time, the closest one will be recognized first
- Images are for illustration purposes only and may not reflect actual operation

QR CODE

Forward/Reverse Parking Distance Warning (PDW) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Parking Distance Warning (PDW) is not a substitute for proper and safe parking and backing-up procedures. Always drive safely and use caution when backing up. Parking Distance Warning (PDW) may not detect every object in front of or behind the vehicle.

Refer to section 6 in the Owner's Manual for more information.

Rear Cross-traffic Collision-Avoidance Assist (RCCA)^{†3}

Rear Cross-traffic Collision-Avoidance Assist (RCCA) is designed to warn the driver under certain conditions. It may temporarily apply braking if it detects cross traffic approaching the vehicle when the vehicle is in reverse.




When the rear-corner radar sensors detect approaching vehicles from the rear left or rear right side of the vehicle **A**, RCCA will sound a warning, the warning indicators on the outside rearview mirror will illuminate and a message will appear on the Instrument Cluster LCD **B** and the Infotainment System. If RCCA detects that the collision risk has increased, RCCA automatically applies the brakes to reduce your speed, potentially helping to minimize the effects of a possible collision.

RCCA is designed to operate under the following conditions:

- When the gear shift is in Reverse
- When the vehicle is moving slower than 6 mph

RCCA Settings:

- RCCA can be turned on/off by going to the User Settings* ⚙️ in the Instrument Cluster or the Vehicle Settings* in the Infotainment System
- Only adjust settings when the vehicle is at a standstill, gear shift is in Park and the ignition is on or the Engine Start/Stop button* in the on position
- **To access User settings* ⚙️ in the Instrument Cluster** - Press the Mode button **C** on the Steering Wheel to toggle to User Settings ⚙️. Press the OK **D** up/down to toggle to Driver Assistance, then Parking Safety. Select Rear Cross-traffic Safety and press the OK button **D**
- **To access Vehicle settings* in the Infotainment System** - Press the **SETUP** key or the onscreen **SETUP** button. Press **VEHICLE** to enter Vehicle Settings. Select Driver Assistance, then Parking Safety and select Rear Cross-traffic Safety



(Buttons located on steering wheel)

QUICK TIP

The Warning Volume can be adjusted in the User Settings ⚙️ in the Instrument Cluster or the Vehicle Settings on the Infotainment System. Go to Driver Assistance, Warning Method, then Warning Volume.

QR CODE

Rear Cross-traffic Collision-Avoidance Assist (RCCA) Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 6 in the Owner's Manual for more information.


REMINDERS:

- When vehicle power is cycled, RCCA will remain in the previous state
- When a vehicle is approaching within the sensing range, and traveling faster than 3 mph, the RCCA system will show a warning

When engaged, RCCA is a supplemental system. Do not solely rely on this system and always pay attention to the road and its conditions.

Instrument Cluster Control

Press switch **A** up or down to adjust display brightness of the instrument panel illumination.



(Buttons are located left of the Steering Wheel)

Electronic Stability Control (ESC)^{†5}

The ESC system is designed to help stabilize the vehicle during certain cornering maneuvers. It is a good idea to keep ESC turned ON whenever possible.

Press ESC OFF button **B** to disable Traction Control in ESC (ESC OFF indicator will illuminate).

To turn both Traction Control and Stability Control off, press and hold ESC OFF button **B** (ESC OFF indicator will illuminate, and an alert sounds).

REMINDERS:

- ESC is active by default at vehicle startup
- The ESC Indicator Light  in the instrument cluster will illuminate whenever the ESC is in operation

Refer to section 6 in the Owner's Manual for more information.

Hill-start Assist Control (HAC)^{†5}

The HAC system is designed to help prevent the vehicle from rolling backward when accelerating from a stop while on a steep incline.

The HAC system automatically activates whether the ESC is OFF or ON but does NOT activate when the ESC has malfunctioned.

QUICK TIPS

- When HAC is active (e.g. accelerating from a stop on an incline), you may notice that the brakes will momentarily remain engaged after you depress the accelerator. This is normal HAC operation
- HAC provides a two-second delay before the vehicle may start rolling backward

REMINDERS:

- The HAC system does not operate when the Rotary Dial Shifter Knob is in the P (Park) or the N (Neutral) position
- In the event of an HAC system malfunction, see an Authorized Kia Dealer for service
- HAC does not replace the need to apply brakes while the vehicle is stopped on an incline

Refer to section 5 in the Owner's Manual for more information.


Power Button^{†9}

To start the vehicle:

1. Depress the brake pedal
2. Press the POWER button while Rotary Dial Shifter Knob is in P (Park) or (N) Neutral

To turn the vehicle power OFF, press the POWER button.

To use the POWER button, you must have the Smart Key fob on your person.



QUICK TIPS

To use electrical accessories:

- **ACC position**
 - When in the OFF position and without depressing the brake pedal, press the POWER button once (amber light **A**)
- **ON position**
 - When already in the ACC position (amber light **A**) and without depressing the brake pedal, press the POWER button again (red light **A**)
 - When in the OFF position (not illuminated) and without depressing the brake pedal, press the POWER button twice (red light **A**)

REMINDERS:

- In an emergency situation while the vehicle is in motion, you are able to turn the vehicle off and to the ACC position by pressing the POWER button for more than 2 seconds or 3 times successively within 3 seconds
- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the POWER button (Lock button side closest) and press to start vehicle
- Do not turn the vehicle off by pushing the POWER button while the vehicle is in motion. If the vehicle has been turned off the power brake and power steering system cannot operate
- With the vehicle off, hydraulic power assist for steering and braking will be disabled and the vehicle will be more difficult to control

QR CODE

EV Power Button Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 6 in the Owner's Manual for more information.

Power Windows, Window and Handle Lock & Central Door Lock

- A** Pull/Press to operate Driver's and Front Passenger's Windows Auto-Up/Down*

QUICK TIP

Press the button again to stop Auto Up/Down function.

- B** Press to Unlock/Lock All Doors
C Press to disable rear passenger window controls and rear door handle operation

QUICK TIPS

- While driving with the rear windows down or with the sunroof* in an open or partially open position, a wind buffeting or pulsation noise may be heard. This noise is a normal occurrence and can be reduced or eliminated by the following:
- If the noise occurs with one or both of the rear windows down, partially lower both front windows approximately 1 inch
- If the noise occurs with the sunroof open, slightly reduce the size of the sunroof opening

REMINDERS:


- When pressed **C**, window controls for the Rear Passenger Windows are disabled
- When closing, be mindful of any objects or persons

Refer to section 5 in the Owner's Manual for more information.

Automatic Door Lock

Auto Door Lock will engage when the Rotary Dial Shifter Knob is moved into or out of the P (Park) position. Refer to the User Settings in the LCD Instrument Cluster modes on how to turn Auto Door Lock/Unlock ON/OFF.

Button configuration may vary depending on vehicle model. Refer to section 5 in the Owner's Manual for more information.



Heated Outside Mirrors

Mirror heaters automatically turn ON/OFF at the same time the Rear Window Defroster is turned ON/OFF. Rear Window Defroster button* is located on climate control system panel.

Refer to section 4 in the Owner's Manual for more information.

Power Folding Outside Mirrors*

Press L or R buttons **D** (left or right) to select mirrors. Then press arrows **E** to adjust mirror position.

To fold and unfold both the outside rearview mirrors, press the folding mirror button **F** as pictured:

- Left** – The mirrors will unfold
- Right** – The mirrors will fold
- Center** – The mirrors will fold/unfold automatically when doors are locked/unlocked with the Smart Key or a door handle button is pressed. Also, the mirrors will unfold when approaching the vehicle with the Smart Key fob in proximity

QUICK TIP

To automatically fold mirrors when exiting vehicle, press the LOCK button once on the Smart Key.

REMANDER: To lock position of mirrors, toggle switch to the neutral (center) position.

Refer to section 4 in the Owner's Manual for more information.


Manual Folding Mirrors*

To fold the mirrors in manually, pull the mirror towards the window.

QUICK TIP

If needed, pull the mirror firmly until it folds.


Refer to section 5 in the Owner's Manual for more information.



Headlights & High Beams

To operate:

- Rotate lever to change the Headlight function
- Push lever to turn High Beams ON
- Pull lever to flash Headlights/High Beams



AUTO Light position - When the light switch is in the AUTO Light position, the tail lights and headlights will turn ON/OFF automatically depending on the amount of light outside the vehicle.

Daytime Running Lights (DRL) - DRL may help others to see the front of your vehicle during the day. The lights will be on automatically when the ignition or Engine Start/Stop button* is ON and the headlight switch is in the AUTO position, unless one of the following occurs:

- Headlights are on
- Parking brake is applied
- Fog lights are on
- Engine is turned off

REMINDERS:

- DRL only operates during the daytime
- The DRL system turns off when the headlights are ON, parking brake is applied or the front fog lights are turned on

High Beam Assist (HBA)

High Beam Assist is designed to automatically adjust the headlight range by switching between high and low beams based on light detected from oncoming vehicles and road conditions.

When switch is in the AUTO position and the vehicle's ignition or the Engine Start/Stop button* is on, the High Beam Assist will operate. To turn HBA off, change the switch setting.

REMINDERS:

- High Beam Assist does not operate below certain speeds, or in some lighting and driving conditions. Please be aware of your surroundings and exercise proper road etiquette when operating a vehicle while using the high beams
- HBA will operate when vehicle speed exceeds 25 mph
- If the lever is pushed away from you while HBA is operational, HBA will turn off and the high beams will be on continuously. If the lever is pulled toward you while HBA is operational, HBA will turn off
- If the light switch is switched to the headlight position, HBA will turn off and low beams will be on continuously

QR CODE

High Beam Assist (HBA) Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Turn Signals & Fog Lights

To operate:

Turn Signals - Move lever Up/Down for Right/Left Turn Signal

REMINDER: Headlights must be in the ON/AUTO position for Fog Light operation.



One-Touch Lane Change Signal is activated by briefly pressing the Turn Signal Lever slightly up or down for less than 1 second and then releasing. The lane change signal will blink 3-7 times.

To change how many times (3/5/7 times) the Lane Change Signal blinks, go to User Settings Mode in the LCD Instrument Cluster modes.


For illustrative purposes only. Your actual display, buttons and/or features may vary.

Refer to section 5 in the Owner's Manual for more information.

Tilt/Telescoping Steering Wheel^{†18}

To adjust the Steering Wheel, push the lock-release lever **A** down and adjust the desired angle **B** and distance **C**.

When finished, pull the lock-release lever **A** up to lock Steering Wheel in place.



QUICK TIP

It may be helpful to pull/push bottom of Steering Wheel towards/away from you to adjust desired distance.

Refer to section 5 in the Owner's Manual for more information.

QR CODE

Tilt/Telescoping/Heated Steering Wheel Video



*Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos*


Do not attempt to adjust steering wheel position when vehicle is in motion as this may cause you to lose control of the vehicle.

Bluetooth® Wireless Technology†2,16

- A Volume button:** Press up/down to raise/lower speaker volume
Mute button: Push to mute the microphone during a call
- B Talk button:** Press to activate voice recognition/bring up menus/
place calls with minimal voice command prompts from the system.
Press and hold to exit voice recognition
When enrolled with a Kia Connect†11 subscription, press this button to
activate the Kia Connect Assist to use navigation guidance and search
destinations
- C Receive/Place Call button:** Press to receive/place calls. In vehicles
with navigation, if no phone is paired, press button to pair a phone

QUICK TIPS

- Phone book transfer upload time varies by phone model and with number of phone book entries
- When using the voice command feature, wait for the system BEEP before speaking the command
- Because of differences in phone quality, service providers and Bluetooth® Wireless Technology chip programming, functionality may differ from one phone to another
- The system may register or pair multiple Bluetooth® devices. See the Car Multimedia System User's Manual for more information on setup and limitations



(Type B shown)

Pairing a Phone

For instructions on how to pair a phone, refer to the Car Multimedia System User's Manual or your vehicle's Quick Start Guide.

QUICK TIP

During the pairing process, be sure to accept the connection requests on the phone for contacts download and to allow acceptance of all future Bluetooth® connection requests.

How to Place a Call

- **Option 1:** Press the Receive/Place Call button **C** (displays the phone screen with call history)
- **Option 2:** Press the Talk button **B**. Then say the command "Call {name}" or "Dial {number}" followed by contact name or number

QUICK TIP

When using the voice command feature, wait for the system BEEP before speaking the command.

Bluetooth® wireless Technology audio and calling functions are supported when connected to a Bluetooth® enabled device (sold separately).

Your vehicle's steering wheel buttons may differ from those in the illustrations. See your Owner's Manual for more details.

Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving.

For more information, refer to the Car Infotainment System Quick Reference Guide. For Bluetooth® Wireless Technology FAQs, go to www.kia.com, Owners section, or call Consumer Information for Bluetooth® Technology at (800) 333-4KIA. Refer to your Owner's Manual for more specific Bluetooth® Wireless Technology phone pairing and operation instructions.

Bluetooth® Wireless Technology^{†2,16} (Continued)

Voice Recognition and Phone Contact Tips

The system may have difficulty understanding some accents or uncommon names. Improve the performance by making a few simple changes to your phone contacts, listed below. To help optimize the Bluetooth® Wireless Technology Voice Recognition system, see other tips and reminders under Quick Tips:

- Use full names (first and last names) vs. short or single-syllable names (e.g., "John Smith" vs. "Dad," "Smith Residence" vs. "Home")
- Avoid using special characters, emojis or hyphenated names (e.g., @, &, #, /, -, *, +, etc.)
- Avoid using acronyms (e.g., "In Case of Emergency" vs. "ICE") or words with all capital letters
- Spell words completely, no abbreviations (e.g., "Doctor Smith" vs. "Dr. Smith")

Audio Controls^{†16}


- A Audio MODE button:** Press to cycle through FM/AM/SiriusXM®/Media modes
Audio System ON/OFF: Press to turn power on; Press and hold to turn power off
- B Seek/Presets button:**
FM/AM/SiriusXM® Modes: Press up/down to advance through Preset Stations. Press and hold to auto seek
Media Mode: Press up/down to move Track Up/Down. Press & hold up/down to fast forward/rewind (except for Bluetooth® Audio)
- C Volume button:** Press up/down to raise/lower volume
Mute button: Press to mute/unmute all audio (Media pauses in some Media modes when pressed)
- D Custom button ★:** Press to access user-selected feature. Press and hold the button to select one of the features available

QUICK TIP

Pressing the Audio Mode button for more than 1 second will turn Audio Mode ON/OFF (Standard Audio System - Value only).

QUICK TIP

- Bluetooth® Music Streaming - If the Bluetooth® music is inaudible or too low, you may need to turn up the volume on the connected phone
- When placing a call, speak in a natural, moderate tone, with clear pronunciation. The system may have trouble recognizing commands if you speak too softly or too loudly
- Always wait for the beep before speaking any commands
- Close windows and turn off A/C - Open windows, weather (wind/rain), or an A/C fan operating at higher speeds can interfere with Voice Recognition
- Press the talk button and say "Help" to get a list of available commands
- The system may register or pair multiple Bluetooth® devices. See the Car Infotainment System Quick Reference Guide for more information on setup and limitations



Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the steering-wheel-mounted controls while driving. To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

Your vehicle's steering wheel buttons may differ from those in the illustrations. See the Owner's Manual or the Car Infotainment System Quick Reference Guide. For further audio system operation, refer to pages 40-45.

QR CODES

Steering Wheel Controls Video



Voice Recognition Tips Video



Star, Favorite & Radio Presets Buttons Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Android Auto™†2 / Apple CarPlay®†2 Setup

Android Auto™ compatible smartphone setup - Download the Android Auto™ app from the Google Play™ Store†2. Open the Android Auto™ app and proceed with the onscreen instructions to complete setup on the mobile device.

Cable Connection setup for Android Auto™:

1. Press the SETUP key on the Infotainment System
2. Press DEVICE CONNECTION, select Android Auto™ and then select ENABLE ANDROID AUTO™. Review all terms, conditions and requests on the head unit and phone, and, if you agree, accept them in order to use Android Auto™
3. Connect the Android™ device with the vehicle's USB port using the manufacturer's cable provided with your phone
4. From the Infotainment System screen, select the Android Auto™ button, where you'll see all the Android Auto™ supported apps

QUICK TIPS

- If Android Auto™ / Apple CarPlay® randomly disconnects:
 - Ensure the USB cable is certified by the phone manufacturer for both power and data
 - Clean the phone's port, which the USB cable connects to, as instructed by the phone's manufacturer.
 - The phone should not be disturbed while driving as this can cause a disconnection at the phone's USB port
 - Visit the phone manufacturer's website for Android Auto™/ Apple CarPlay® app concerns

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.

Cable Connection setup for Apple CarPlay®:

1. Connect the Apple CarPlay® compatible iPhone® with the vehicle's USB port using the manufacturer's cable provided with your iPhone®
2. Press the SETUP key on the Infotainment System
3. Press DEVICE CONNECTION on the screen and select Apple CarPlay®
4. Select ENABLE APPLE CARPLAY®, Review all terms, conditions and requests on the head unit and phone, and, if you agree, accept them in order to use Apple CarPlay®
5. From the audio head unit home screen, select the Apple CarPlay® button, where you'll see all the Apple CarPlay® supported apps

REMINDERS:

- Android Auto™ compatibility requirements for connection:
 - USB cable connection only: OS Android™ 5.0 or higher, phone manufacturer's USB cable and data plan for applicable feature(s)
- Apple CarPlay® compatibility requirements for connection:
 - USB cable connection only: iOS® software 8.0 or higher, phone manufacturer's USB cable and data plan for applicable feature(s)
- It is recommended to always update your phone to the latest operating system release
- Wireless Android Auto™ system only works for certain Android models. Use the manufacturer's USB cable when wireless feature is not available

Refer to the Car Infotainment System Quick Reference Guide for more information.

Kia Connect Activation*†1

Follow these steps to activate your Kia Connect system:

1. Enter the activation screen on your Infotainment System:
 - a. Press SETUP key
 - b. Press Kia Connect icon
 - c. Press Activate
2. Read and agree to Terms of Service and Privacy Policy and press SUBMIT
3. Enter number or email address to receive a verification code, then press SUBMIT
4. Follow these steps to receive your verification code using your phone SMS or email:
 - a. Check your phone SMS or email for verification code
 - b. Open the link in your SMS or email. A page will open requesting that you create your account

Note: If you already have a Kia Owners Portal account using the email or phone number as your login ID, you will need to provide your password prior to receiving the verification code.

Kia Connect Assistance*†1

Kia Connect **A** - Press to connect to the Kia Connect Call Center

Roadside Assist **B** - Press to connect to a Roadside Assistant where you can request vehicle towing services

REMINDER: These buttons may be located in the rearview mirror or the overhead console.


Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe bodily injury, and death. The driver's primary responsibility is in the safe and legal operation of a vehicle, and any handheld devices, other equipment, or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or which are not permissible by law should never be used during operation of the vehicle.

- c. Enter your first name, last name, email, phone number, an account password, and click CREATE ACCOUNT. A page will open displaying your verification code
- d. Enter the code in the head unit and press ACTIVATE
- e. Go back to the page with your verification code and press "I have entered my verification code." A link will be provided to download the Kia Access app from your app store. After installing the app, log in and enjoy

REMINDER: This vehicle is not equipped with over-the-air system updates.

For further Kia Connect operations, refer to the Car Infotainment System Quick Reference Guide.

Kia Connect may be unavailable for model year 2022 vehicles sold or purchased in Massachusetts.



(Buttons on overhead console*)

For further Kia Connect link operation, refer to the Car Infotainment System Quick Reference Guide. For further audio system operations, refer to pages 40-45.

QR CODES

Kia Connect Activation Video



Kia Access app Video




Kia Connect Assistance Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Kia Connect with Navigation^{+1,7} - FM/AM/SiriusXM^{®+15}/Media (USB, *Bluetooth*^{®+2} Audio)



Switchable Controller: Press the Infotainment/climate control mode switching button **A** to toggle between Infotainment System and Climate Control Modes. Press and hold the Infotainment/climate control mode switching button **A** to set the default button display mode.

Sound Settings: To adjust the sound settings, Press the **SETUP** key on the infotainment system. Select the onscreen **SOUND** button, then select the menu item. Use the onscreen buttons to adjust settings. Press the return button **↩** to save settings.

Radio Presets: To save a Preset, press and hold the desired slot or the star button **☆** next to or below the radio station display. This saves the current station in the selected slot.

SiriusXM[®] Smart Favorites: In Radio mode, choose SiriusXM[®], then select any of the first six favorites. During song or program play, tap the Skip Backward icon to start from the beginning of the song or program. Tap the Play Live icon to return to the live broadcast.

Custom Key **☆ To program,** press and hold the Custom Key. Select one of the available features you would like the Custom Key to open.

Map/software updates: To keep your map and software up to date, free of charge, visit the official Kia update webpage at <https://update.kia.com/US/EN/Main>. **Note,** visiting a dealer for software update may include an additional charge.

QR CODES

AC & Infotainment System - Switchable Controller Video



EV Kia Connect with Navigation Video



Kia Connect with Navigation Video



Infotainment System Driver Profiles Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Kia Connect with Navigation^{†1,7} (Continued) - FM/AM/SiriusXM^{®†15}/Media (USB, *Bluetooth*^{®†2} Audio)

QUICK TIPS

- Volume level between different audio modes:
 - When switching between audio modes (AM, FM, *Bluetooth*[®] Audio, etc.), the audio system saves the previous volume level you were listening to. For example, if you were listening to FM radio at volume level 20 then switched to *Bluetooth*[®] Audio and adjusted the volume level to 30, the volume level will be at 20 when you switch back to FM radio
 - When using *Bluetooth*[®] Audio, the overall volume is dependent on your device's volume. If the volume is turned down low on your device it will remain low even if the system volume is turned up
- This system supports Android Auto™ (USB & wireless connection) and Apple CarPlay® (wireless connection only) and Android Auto™ (USB & wireless connection) and Apple CarPlay® (wireless connection only)
- This system supports Android Auto™ (USB & wireless connection) and Apple CarPlay® (wireless connection only)
- At any time, you can interrupt Command Feedback by pressing the TALK button
- A warning screen may appear periodically to remind users that the audio system should be operated when the engine is running to prevent battery discharge
- Prolonged use of the audio system in ACC mode may drain the vehicle's battery

REMINDER: Driving while distracted is dangerous and should be avoided. Drivers should remain attentive to driving and always exercise caution when using the audio system controls while driving. To help minimize driver distraction, some audio system functionalities have been modified while the vehicle is in Drive, Reverse or moved out of Park.

Kia Connect is currently unavailable for model year 2022 or later vehicles sold or purchased in Massachusetts. See Kia Connect Terms of Service at owners.kia.com for more information. For further operational information, refer to the Car Infotainment System Quick Reference Guide.

QR CODES

Navigation System
Important Tips Video



Navigation System
Updates Video



Refer to the inside front cover for
more information on QR codes.
www.youtube.com/KiaFeatureVideos

Kia Access App Download

Go to an app marketplace to download the Kia Access App. Once you download the app, make sure you register your vehicle and start an account (refer to Kia Connect Activation page). Get to know your new Kia and the available convenient features on the app.



QUICK TIPS

- The smartphone and vehicle need to be connected to a cellular network with good wireless signal strength in order to use Kia Connect. If these conditions are not met, remote command may not execute or may take a long time. It will also affect voice commands
- To use Remote Start or Remote Start with Climate Control feature, all doors, hood and trunk/liftgate must be closed and locked
- When Remote Start is activated, if the driver does not enter the vehicle within 10 minutes, the Remote Start will turn the engine off
- When using Remote Start with Climate Control, turn on for at least a few minutes before getting into the vehicle, allowing the vehicle interior to reach your desired temperature
- The quickest way to obtain accurate vehicle status through the app is by pressing the refresh button on the app or refreshing the web page when using the customer web portal
- In order to preserve the vehicle battery, Kia Connect will not turn on seven days after the last ignition was on. You will need to restart the vehicle with a key fob in order to use Kia Connect again
- Do not use remote climate control or remote start if vehicle is in an enclosed area (e.g., closed garage) or a partially enclosed area without ventilation. Close all doors leading from adjacent living areas to the vehicle area before executing a remote climate control or remote start command.

Kia Access App Features Guide

The Kia Access App Features Guide helps you utilize the app to its full potential by detailing each feature and how to adjust various settings. Below are some of the topics included:

- Remote Commands
- Set Climate
- Schedule Remote Start/Climate
- Schedule Charge
- Schedule Service
- Dealer Settings
- Manage Vehicles and Profiles

Do not use remote climate control or remote start if vehicle is in an enclosed area (e.g., closed garage) or a partially enclosed area without ventilation. Close all doors leading from adjacent living areas to the vehicle area before executing a remote climate control or remote start command.

QR CODES

Download the Kia Access App
by clicking this dynamic QR code. Some phone's operating systems may need to be updated to scan dynamic QR codes.



Kia Access App Features Guide

Guide. Click this dynamic QR code to access the guide. Some phone's operating systems may need to be updated to scan dynamic QR codes.



Kia App Screen for illustrative purposes only. Actual App screen and functionality may vary. For further Kia Connect link operations, refer to the Car Infotainment System Quick Reference Guide.

Digital Clock - Infotainment System

Press **SETUP**, then select **General**, then select **Date/Time** from the menu to adjust.

QUICK TIPS


- Press the **Return** button on the audio head unit to ensure changes are saved
- When needed, **Daylight Savings** must be enabled in the **Clock Settings** screen
- To access manual date and time setting, turn **GPS time OFF** in the **Clock Settings**

USB-C Charger Ports

The USB-C Charger Ports **A** are located on the center panel and on the side of the seats. Devices can be recharged using a USB cable. The **Power** button needs to be in the **ACC/ON/RUN/START** position to operate the USB Charger Ports.



(Located in Center Console in front of gear shift)



(Located on upper side of both front seats)


Multimedia USB Ports, Charger Ports & Power Outlets

Multimedia USB Port **B**

Use the Multimedia USB port to connect USB audio devices and smartphones.

Power Outlets **C**

Use the power outlet for mobile phones and other devices designed to operate on a 12V (180W max) power outlet.



QUICK TIP

The power outlets are inactive when ignition is in the **OFF** position.

REMINDERS:

- Only use cables made by your device manufacturer. Third party cables may damage your device
- The Multimedia USB data port is located between the Power Outlet and USB Charger Port. The USB Charger Port does not support data transfer

QR CODES

Multimedia USB Port, Power Outlets & USB Charger Port Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.

For illustrative purposes only. Your actual display, buttons and/or features may vary.

Wireless Smartphone Charging System^{†21}

Charge a compatible Qi Certified smartphone wirelessly by placing it on the charging pad **A** at the front of the console, near the Multimedia USB ports and the charging indicator, while the ignition is on.

1. Enable Wireless Charging in the User Settings in the Instrument Cluster LCD or the Vehicle Settings* in the infotainment system, select Convenience, then Wireless Charging System
2. Place a compatible smartphone on the center of the charging pad **A**
3. Indicator light **B** may change to amber once the wireless charging begins
4. Once charging is complete, the amber light may change to green


QUICK TIPS

- The smartphone must be a compatible phone with Qi function available
- Wireless charging must be enabled in user settings
- If wireless charging does not work, move smartphone around the pad until the charging indicator turns amber. Avoid placing other metal items in the bin while charging so as to not to impede the charging area
- For wireless charging to occur, all doors (excluding rear hatch) must be closed & the Smart Key Fob must be detected inside the vehicle and driver's seat belt on

REMINDERS:

- The smartphone must be a compatible Qi certified phone with Qi function available. Some smartphone models are not Qi certified, which may affect the availability, speed or performance of the wireless charging
- Wireless charging technology allows for a device to be charged using inductive charging. See your Owner's Manual for more detailed information and the back page for legal disclaimers
- Inductive charging systems are less efficient than conventional charging through cable. As a result, higher device operating temperatures may be experienced during use
- Charging Performance - Device position on the wireless charging system can affect charging performance. Other factors that may affect the charging rate includes foreign objects, such as coins or pens, and phone case thickness
- If driver door is opened, charging will be disabled
- Avoid placing other metal items in the bin while charging as to not impede the charging area

Requires Qi enabled device or Qi enabled case



(Located in front of Gear Shift)

QR CODE

Wireless Smartphone Charging Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Charging system only works with select devices. Refer to the section 5 in the Owner's Manual for warnings and instructions.

Images are for illustrative purposes only and may not reflect actual feature or operation.

Rotary Dial Shifter*

Rotate dial for the following:

P: Park - Press to place in Park. To release the Parking Brake, rotate dial to R, D or N


R: Reverse

N: Neutral

D: Drive

REMINDER: The vehicle is equipped with a shift-by-wire system and a shift-lock system that prevents you from shifting gears without depressing the brake pedal.

Refer to section 6 in the Owner's Manual for more information.



(Located on center console below Power button)

QR CODE

Rotary Dial Shifter Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Heated Steering Wheel*

Press button **A** to turn ON/OFF the steering wheel heater, while the POWER button is in the ON or READY position.


The steering wheel heater will turn off automatically after 30 minutes, or when button is pressed again to deactivate.

QUICK TIP

If ignition is cycled, the Heated Steering Wheel turns OFF. Press button again to turn ON.

REMINDER: If the steering wheel becomes too warm, turn the system off. The heated steering wheel may cause burns even at low temperatures, especially if used for long periods of time.


Refer to section 5 in the Owner's Manual for more information.



(Located beside gear shift dial)

Automatic Climate Control

- A** Driver Temperature Control knob
- B** Front Windshield Defroster
- C** Rear Windshield Defroster
- D** AUTO Climate
- E** Recirculated Air button
- F** **Switchable Controller:** Toggle between Climate and Infotainment Controls; Press and hold to set the default mode displayed
- G** Driver Only Climate display
- H** Fan Speed Control knob
- I** Mode Display
- J** A/C On-Off
- K** SYNC (Dual Zone)
- L** Passenger Climate display
- M** Passenger Climate Control knob



Climate Control Auto Function

Press AUTO to select Full Auto Operation. The Auto setting automatically controls the airflow modes, fan speeds, air intake and air conditioning according to the temperature setting selected.

Turn temperature control knob **B** to the desired temperature.

Air Flow Modes **H**:

To select Air Flow Modes, press the Mode selection buttons:

- Face-Level
- Bi-Level
- Floor-Level
- Floor/Defrost-Level

QUICK TIPS

- Defrost mode activates A/C and opens Fresh Air Vent to help dehumidify the air and improve defog performance
- During Auto Operation, the A/C indicator will NOT illuminate. The fan speed, air intake, air flow and air conditioning may automatically be engaged at any time to reach desired temperature and reduce humidity
- Keep inside glass as clean as possible to reduce window fogging

Your Automatic Climate Control system may differ from those in the illustration. Refer to section 5 in the Owner's Manual for more information.

QR CODES

Automatic Climate Control - Switchable Controller Video



Automatic Climate Control - Touch-Sensitive Control Panel Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

REMINDERS:

- Continuous use of the climate control system in the recirculated air position may allow humidity to increase inside the vehicle which may fog the glass and obscure visibility
- Pressing any button during AUTO operation will deactivate the AUTO function and switch to manual mode, except for Temperature Control
- When in AUTO mode, Air Flow mode and Fan Speed do not display on the Climate Control Display
- Cold or warm ambient air may flow in through vents if Recirculated Air button is not pressed ON (LED lit)
- Continuous use of the A/C and heater may allow the Energy Consumption to increase, especially excessive use of the heater

Automatic Climate Control (Continued)

Auto Defogging System: Auto defogging is designed to reduce the fogging up of the inside of the windshield by automatically sensing the moisture of the inside of the windshield. The system will automatically change to defrost mode when needed.

Auto Defogging is set ON by default. To cancel Auto Defogging, press and hold the Front Defrost button  for three seconds, when the ignition is in on (the defrost button light will flash three times and the ADS OFF icon will illuminate). To turn Auto Defogging on again, press and hold the Front Defrost button  again for three seconds and the defrost button light will flash 6 times and ADS OFF icon will turn off.

Driver Only Ventilation: Driver Only Ventilation restricts air flow to the driver's side vents only. This can help to optimize driving range by limiting the power drawn from the battery. Press DRIVER ONLY button to enable air flow through the driver's side vents only.

Defrost Outside and/or Inside Windshield (refer to illustration on previous page):

1. Set Front Fan Speed  to the highest position
2. Set **Temperature** to **Hot** 
3. Press the **Front Defrost** button  

Seat Warmers^{*14} / Ventilated Seats^{*}

Seat Warmers

- Press the button once for high setting (3 LEDs lit)
- Press the button twice for medium setting (2 LEDs lit)
- Press a third time for low setting (1 LED lit) and again to turn OFF

Ventilated Seats

- Press the button once for high setting (3 LEDs lit)
- Press twice for medium setting (2 LEDs lit)
- Press a third time for low setting (1 LED lit) and again to turn OFF

QUICK TIPS

- With the seat warmer switch in the ON position, the heating system in the seat turns OFF or ON automatically depending on the seat temperature
- System is OFF by default

REMINDER: Use extreme caution when using the seat warmers to avoid burns.

ALWAYS CHECK THE OWNER'S MANUAL FOR COMPLETE OPERATING INFORMATION AND SAFETY WARNINGS.



QR CODES

Auto Defogging System (ADS) Video



Seat Warmers /Ventilated Seats Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.

Electronic Parking Brake (EPB)

The Electronic Parking Brake (EPB) system utilizes an electric motor to engage the parking brake.

Applying the Parking Brake

Pull up the EPB switch **A**. Ensure that the indicator light **(P) BRAKE** is illuminated on the instrument cluster.

Releasing the Parking Brake

The EPB will automatically release when the brake pedal is engaged and shifter is shifted out of P (Park) to R (Reverse) or shifted out of N (Neutral) to Reverse or D (Drive).

Manually, depress the brake pedal, then press the EPB switch **A** down, with the ignition switch in the ON position. Ensure that the indicator light **(P) BRAKE** is OFF.

QUICK TIPS

- When leaving your keys with parking lot attendants or valet, make sure to inform them how to operate the EPB
- If parked on a steep incline/decline, pull up the EPB switch for more than 3 seconds for a firmer EPB application
- Pull up and hold EPB switch again to increase brake pressure if parked on a decline or incline

REMINDERS:

- As a bulb check, the EPB malfunction indicator will illuminate for approximately 3 seconds when the ignition switch is turned ON
- If the warning light does not illuminate temporarily, or continues to remain lit, take your vehicle to an authorized Kia dealer and have the system checked
- The EPB should not be operated while the vehicle is moving
- A click or electric brake motor sound may be heard while operating or releasing the EPB, but these conditions are normal and indicate that the EPB is functioning properly

Refer to section 6 in the Owner's Manual for more information.

Auto Hold

Auto Hold temporarily maintains the vehicle at a standstill even if the brake pedal is released. Auto Hold can be turned ON/OFF using the AUTO HOLD switch **B** on the center panel. Before Auto Hold will operate, the driver's door, engine hood and trunk must be closed, and the driver's seat belt must be fastened.


The Auto Hold indicator has four states:

Standby (white): With vehicle in Park and at a standstill, and AUTO HOLD switch **B** turned ON, the indicator will illuminate white. While driving the vehicle (vehicle is not at a standstill), the Auto Hold indicator will remain white.

Engaged (green): When coming to a complete stop and depressing the brake pedal, the Auto Hold indicator changes from white to green.

OFF (not illuminated): The indicator will turn OFF when the AUTO HOLD switch **B** is turned OFF or when the EPB is manually turned ON.

Malfunction (yellow): When the indicator is illuminated yellow, there may be a system malfunction. Take your vehicle to a local Kia dealer.



(Located on Center Panel)

QR CODE

Electronic Parking Brake (EPB) / Auto Hold



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos



REMINDERS:

- To reduce the risk of an accident, do not activate Auto Hold while driving downhill, backing up or parking your vehicle
- Do not solely rely on the Auto Hold system to keep the vehicle stopped. Always pay attention to traffic and road conditions, and be prepared to depress the brakes
- Auto Hold turns off when ignition is cycled
- Auto Hold only operates when vehicle is in Drive, Neutral or Reverse

Refer to section 6 in the Owner's Manual for more information.

Power Adjustable Driver's Seat^{†12}

Move/Press controls to adjust Seat forward/backward, Seat Cushion tilt up/down, Seatback forward/backward or Lumbar forward/backward.




REMINDER: Do not attempt to adjust the seat while the vehicle is moving. This could result in loss of control of the vehicle.

Refer to section 4 in the Owner's Manual for more information.

Driver Position Memory System^{†12}

To store a seating position into memory, first place the shifter into P (Park) while the ignition switch is ON. Then:

1. Adjust the driver's seat
2. Press one of the memory buttons **D** within 5 seconds. The system will beep twice when memory has been stored
3. "Driver (1 or 2) set is memorized" will appear on the instrument cluster LCD screen



Do not attempt to operate the driver position memory system while the vehicle is moving. This could result in a loss of control of the vehicle.

QR CODE

Power Adjustable Driver's Seat with Memory Settings Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos


Front Seat Headrest Adjustment^{†12}

- **To raise headrest:** Pull headrest up.
- **To lower headrest:** Press lock **E**, then press the headrest down.

QUICK TIP

For easy adjustments, hold a headrest post with one hand while using the other hand to pull the headrest from underneath.

Do not operate the vehicle with the headrests removed. Headrests can provide critical neck and head support in an accident.



6-Way Manual Adjustable Driver's Seat^{*†12}

Pull lever **A** to slide Seat forward/backward.

Pull/press lever **B** up/down one or more times to adjust Seat height*.


Pull lever **C** to adjust Seatback recline.

QUICK TIP

When adjusting seat forward or backward, ensure seat clicks or locks into place before driving vehicle.

Do not attempt to adjust the seat while the vehicle is moving. This could result in loss of control of the vehicle.

Refer to section 4 in the Owner's Manual for more information.



QR CODE

Manual Seat Adjustment Video



*Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos*


Folding Rear Seats

To Fold:

1. Ensure the belt strap is out of way of the Seatback folding **D**. Insert the metal seat belt tab into the holder **E**.
2. Adjust the Front Seatback to the upright position and lower the rear headrest to the lowest position.
3. Pull on the Rear Seatback lock release lever **F**, then fold the seat toward the front.

To Unfold:

1. Pull the lock release lever **F** and lift the Seatback backward until it clicks firmly in place.
2. Return the rear seat belt to the proper position.



REMINDERS:

- Before unfolding Seatback, ensure the seat belt is placed into the holder.
- Always make sure the Seatback is locked in place when unfolded.

For illustration purposes only. Actual vehicle might be slightly different. Refer to section 4 in the Owner's Manual for more information.

QUICK TIPS

- It may be necessary to adjust the Front Seatbacks to fully lower rear seats.
- Ensure seat is locked by pressing down on Seatback and ensuring red line is NOT visible on bottom of Folder Lever.

Rear Occupant Alert (ROA) with Door Monitoring^{†3}

The Rear Occupant Alert (ROA) with Door Monitoring can help alert the driver when a rear passenger may be left in the vehicle. The alert will be a message on the Instrument Cluster stating to "Check rear seats" **A** and a chime will sound.

The factory default is set to OFF. To turn the system ON or OFF, go to User Settings in the Instrument cluster or Vehicle Settings* on the audio head unit, select Convenience, then Rear Occupant Alert and check/uncheck the box.

REMINDER: Always be sure to check the passenger areas before leaving the vehicle.

Rear Occupant Alert is not a substitute for one's attention and may not detect all movement within the vehicle. Always check the vehicle interior when exiting the vehicle.

See section 5 in the Owner's Manual for more information.



Image is for illustrative purposes only and may not reflect actual feature or operation.

QR CODE

Rear Occupant Alert (ROA) with Door Monitoring video




*Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos*

Hood Release Lever and Latch

Opening the Hood:

Pull the Secondary Hood Release Lever **A** to unlatch the Hood. In the front of the vehicle, lift the Hood slightly, pull the secondary Latch **B** inside of the Hood's center to the left and lift the Hood.



Closing the Hood: Lower the Hood about halfway and then press down to securely lock in place.


Refer to section 5 in the Owner's Manual for more information.

Sun Visor^{†17}

Use the Sun Visor to shield direct light through the front or side windows. Move the Sun Visor out and adjust as needed.

REMINDERS:

- Sun Visor may not shield all direct light
- Do not operate the vehicle if Sun Visor is impairing your visibility
- Be aware of your seating position when adjusting or swinging Sun Visor around from the front or side windows



Refer to section 5 in the Owner's Manual for more information.

Digital Key 2 Touch*

Digital Key 2 Touch, through your smartphone, can be used to lock and unlock your vehicle and allow you to start or power off your vehicle, without needing to have a key fob.

Digital Key 2 Touch Setup:

1. First, ensure your Smart Key is inside the vehicle and turn the vehicle on
2. Download the Kia Access App and activate Kia Connect in your vehicle's Infotainment System (see page 44)
3. Register your smartphone by going to the Vehicle Settings on the Infotainment System:
 - Press **SETUP**, **VEHICLE**, **DIGITAL KEY** **A**, **SMARTPHONE KEY** and then **MY SMARTPHONE KEY**
4. On your smartphone, press **DIGITAL KEY** **B**, **CONTINUE TO WALLET APP**, then **CONTINUE** again, which will open the Wallet app. Follow the prompts to complete the registration/pairing of your smartphone (actual steps may vary between apps/smartphones)
5. Place your smartphone in the authentication pad (wireless charging pad) to complete registration. Click **Save** on the Infotainment System screen and a message will appear showing the process is in place
6. When the Infotainment System is done pairing, remove the smartphone and continue the steps to open the **Digital Key** in your iPhone® Wallet or Samsung™ Wallet
7. When in the Wallet app, click on the **Digital Key** and select the menu icon to adjust other settings or use other features

Using your Digital Key 2 Touch:

1. To lock or unlock your vehicle with Digital Key, position smartphone to door handle until smartphone vibrates
2. To start your vehicle with Digital Key 2 Touch, place registered smartphone on the authentication pad **C** (wireless charging pad; see next page), press the brake pedal and the Start/Stop button

Sharing your Digital Key 2 Touch:

1. Open the Wallet app, click on the Kia Digital Key and select the menu icon to enter settings
2. Under **PEOPLE**, click on **Invite** and follow the prompts to share your Digital Key with one of your contacts Apple iPhone/iWatch or Samsung phone (actual steps may vary between apps/smartphones)

When sharing a Digital Key, the receiver of the share invitation must have the same smartphone operating system, e.g., Apple to Apple and Samsung to Samsung

Revoking shared Digital Key access:

You can also delete a key using the Wallet app on your smartphone. Open the Wallet app, click on the **Kia Digital Key** and select the menu icon to enter settings. Under **PEOPLE**, click on the contact to revoke. Then click on **Revoke Access** (actual steps may vary between apps/smartphones).

To delete shared keys and the owner key:


Go to the Vehicle Settings* on the Infotainment System. Press **SETUP**, **VEHICLE**, **DIGITAL KEY** and **SMARTPHONE KEY**. Then press **DELETE**.

QR CODE


Digital Key 2 Touch Video





Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos



Digital Key 2 Touch* (Continued)



(Charging pad located in center console)



Door handle authentication pad

NFC antenna (backside of smartphone). Antenna position differs depending on models

QUICK TIPS

- You can set the Access for the Shared Digital Key before inviting the contact
- If the smart phone digital key does not operate, move the smart phone around the door handle slowly until it vibrates

REMINDERS:

- Digital Key 2 Touch is currently only compatible with Apple iPhone & iWatch and Samsung smartphones
- Your iPhone Wallet or Samsung Wallet app content may vary as the apps are updated. The actual steps for Digital Key 2 Touch setup, usage and sharing may change
- During the Digital Key saving process, the process will cancel when:
 - The smart phone is removed from the in-vehicle authentication pad
 - Changing the infotainment system screen
 - The vehicle is powered off or the gear is shifted
 - There is no smart key (saving process will not begin)
- You may need to set up language for Samsung smartphones
- Currently compatible devices:
 - For **Apple iPhone** (Ensure the device has the latest version of iOS):
 - iPhone XS or later.
 - iPhone 11 Pro or later (for passive entry or remote features on compatible cars)
 - For **Apple Watch** (Ensure the device has the latest version of watchOS):
 - Apple Watch Series 5 or later
 - Apple Watch Series 6 or later (for passive entry or remote features on compatible cars)
 - For **Samsung Phones**: Ensure the device has the latest version of Android OS and latest application version of Samsung Wallet)
 - Galaxy S20 or later
 - Galaxy Note20 5G or later
 - Galaxy Z Flip 5G or later
 - Galaxy Fold 2 or later

Refer to section 5 in the Owner's Manual for more information.

Smart Key with Remote Start^{†9}

Smart Key Fob:

- A** Press to lock All Doors; Press twice within 2 seconds to sound the horn
- B** Press to unlock Driver's Door. Press twice in 4 seconds to unlock All Doors
- C** Press and hold for more than 1 second to unlock Liftgate. Then lift the liftgate handle to manually open Liftgate

REMINDER: The Liftgate unlocks when the Smart Key fob is within close proximity of the vehicle Liftgate.

- D** Press and hold more than 1 second for Panic Alarm. To turn off Alarm, press any button
- E** Press to release Mechanical Key (on reverse side of fob)

Driver's Door Lock/Unlock button **F**:

- Press button once to unlock Driver's Door
- Press again within 4 seconds to unlock All Doors
- Press again to lock All Doors

Mechanical Key **G**:


- Use to lock/unlock Driver's Door by turning once or all doors by turning twice
- Use to enable/disable Child Safety Locks
- Use to unlatch rear center seatbelt lower anchor

Remote Start* **H:** Lock the doors by pressing the door lock button

A within 32 feet distance from the vehicle. Within four (4) seconds of pressing the door lock button **A**, press and hold the Remote Start button **D** for more than two (2) seconds to start the vehicle. To stop the Remote Start operation, press the button again. If driver does not enter vehicle within three minutes of starting the vehicle, the vehicle will automatically turn off.


QUICK TIPS

- If the Smart Key battery is weak or not working properly, hold the Smart Key fob up to the POWER button (Lock button side closest) and press to start vehicle
- The Smart Key's signal can be blocked by the normal operation of a cell phone or smartphone. To help prevent this, store each device separately



Double-Turn Lock/Unlock All

- Turn counterclockwise once to unlock Driver's Door
- Turn counterclockwise again within 4 seconds to unlock All Doors
- Turn clockwise once to lock All Doors



Images are for illustrative purposes only and may not reflect actual feature or operation.

QR CODES

Remote Start - Smart Key Video



*Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos*

REMINDEES:

- Remote button configuration may vary depending on vehicle options
- One/two button turn logic can be changed in User Settings
- When reinserting the mechanical key, make sure it is pushed all the way in until there is a click sound.

Refer to section 5 in the Owner's Manual for more information.


Map/Room Lamps

Automatic turn off function*

The interior lights automatically turn off approximately 30 seconds after the POWER button is turned OFF.

Map Lamp/Room Lamp Operation

- Press lens **A** to turn the Driver's/ Passenger's Map Lamps ON/OFF. This light produces a spot beam for convenient use as a map lamp or as a personal lamp for the driver or the front passenger.
- Press button **B** to turn all the Map/Room Lamps ON/OFF
- Press button **C** to turn the Map/Room Lamp ON, for 30 seconds, when a door is opened, unlocked from Smart Key or the ignition is turned OFF. When pressed and a door is opened, or doors are unlocked from the Smart Key, the Map and Room Lamps turn ON for approximately 30 seconds.
- Press button **D** to turn the Room Lamp ON/OFF



QUICK TIPS

- When doors are unlocked by the Smart Key*, the lamp turns ON for approximately 30 seconds
- If your vehicle is equipped with the theft alarm system, the interior lights automatically turn off approximately 3 seconds after the system is in armed stage
- Using interior lights for an extended period of time may cause 12V battery discharge

Power Sunroof with Sunshade*

The Sunroof glass and Sunshade operation is controlled by a multidirectional switch **E**, and the ignition needs to be in the ON position to operate the sunroof glass and sunshade.

To slide the sunroof glass and sunshade:

- Auto Open:** Slide switch **E** backward to the farthest position and release (second detent)
- Auto Close (Sunroof only):** Slide the switch **E** forward to the farthest position and release (second detent)

Tilt the Sunroof:

- Tilt open:** Press switch **E** upward
- Tilt close:** Press switch **E** forward

QUICK TIPS

- To stop the Sunroof at any position, push or pull the Sunroof control lever in any direction
- Adjusting the sunroof past the first stop position (normal), in the fully opened position, may cause wind buffeting noise
- While driving with rear windows down or with the sunroof in an open or partially open position, a wind buffering or pulsation noise may be heard. This is a normal occurrence and can be reduced or eliminated by the following:
 - If the noise occurs with one of both of the rear windows down, partially lower both front windows approximately one inch
 - If the noise occurs with the sunroof open, slightly reduce the size of the sunroof opening

REMINDERS:

- Sunshade needs to remain OPEN while Sunroof is open and vehicle is moving
- When closing, be mindful of any objects or persons
- If the ignition is turned off with the sunroof not fully closed, the instrument cluster LCD will display a warning message and a chime will sound for a few seconds
- Do not adjust the sunroof or sunshade while driving. This could result in loss of control of the vehicle.

QR CODE

Sunroof Operation Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.

Smart Power Liftgate*†10

Opening from Inside the Vehicle: Press and hold the Smart Power Liftgate Open/Close button **A** to automatically open/close the Liftgate.

Smart Key: To open the Smart Power Liftgate, press and hold the Liftgate button **B** until the Liftgate begins to open. Press and hold again to automatically close.

Opening from Outside the Vehicle:

To open the Smart Power Liftgate automatically, press the Rear Hatch Release button **C** on the exterior of the Liftgate.

Automatically close by pressing the Power Liftgate Close button **D**.

REMINDER: Pulling the Liftgate upward by the handle or pressing the button a second time will interrupt the automatic opening of the Power Liftgate.

Power Liftgate Opening Height Adjustment

The height setting of a fully opened liftgate (tailgate) can be adjusted by the following steps:


1. Position the liftgate manually to the preferred height
2. Press the Smart Power Liftgate Close button **D** more than 3 seconds
3. A system beep will sound twice indicating the height setting has been saved

The liftgate will then open to the set height. To change setting again, repeat steps 1-3.

REMINDERS:

- When closing, be mindful of any objects or persons
- The Smart Key Liftgate button or the Smart Power Open/Close button **C** must be held to close the liftgate. Releasing these buttons mid operation will cause the liftgate to halt its motion and sound a warning chime. This is normal operation


See section 5 in the Owner's Manual for more information.



(Button located on Driver's Panel)



Remote button configuration may vary depending on vehicle options.



(Handle located outside liftgate below Kia badge. Liftgate Close button located on inside of liftgate.)

QR CODES

Smart Liftgate Operation, Opening Height/Speed Adjustment Video



Remote Start - Smart Key Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Smart Power Liftgate*†10 (continued)

The Smart Power Liftgate with Auto Open can be operated from several controls to either open, close or lock the Liftgate. The Smart Power Liftgate will close the Liftgate, lock all doors and Liftgate and then arm the vehicle.

When the Smart Key fob is on your person and you are near the back of the vehicle, within close proximity, the hazard lights will blink and a chime will sound for about 3 seconds as an alert that the Smart Power Liftgate is about to open. Then the alert system will blink and chime two additional times before opening the Smart Power Liftgate.

The Smart Power Liftgate feature is off by default. To enable the Smart Power Liftgate, go to User Settings mode in the LCD Instrument Cluster or the Vehicle Settings* in the Infotainment System.

QUICK TIPS

- During the Smart Liftgate open alert, the Smart Liftgate can be deactivated with the Smart Key by pressing any button on the key fob or moving away from the detection area
- The open height and speed can be adjusted. For information on how to set the open height and speed, see your owner's manual

REMINDERS:

- All doors are closed and locked after about 15 seconds
- The Smart Power Liftgate feature will not operate when:
 - The doors are recently closed and locked, and the Smart Key is still detected after 15 seconds near the vehicle or within 60 inches of the door handles
 - A door is not locked or closed
 - The Smart Key is in the vehicle
- Press any button on the Smart Key fob during the Detect and Alert stage, or move out of the detection area, to deactivate the Smart Power Liftgate function
- When the ignition is on, the Smart Power Liftgate will only operate with the gear shift in the Park (P) position
- The Smart Key must be outside of the vehicle for the Smart Liftgate with Auto Open to operate
- Ensure obstacles and people are out of the way of the Liftgate
- When closing, be mindful of any objects or persons


Liftgate Release Button†20

The button is located on the bottom of the Liftgate lid. With doors unlocked, press the Liftgate Release button **A** and pull the Liftgate up by the handle to open.

QUICK TIPS

- The Liftgate must be unlocked before it can be opened by the Liftgate Release Button
- The Liftgate unlocks automatically and then can be opened manually when the Smart Key* is within close proximity to the vehicle

REMINDER: Pressing the Smart Key remote liftgate button only unlocks the liftgate. To open liftgate, also press the Liftgate Release button & pull the liftgate up by the handle to open.



(Handle located outside liftgate below Kia badge. Liftgate Close button located on inside of liftgate.)

QR CODES

Smart Liftgate Operation, Opening Height/Speed Adjustment Video



Liftgate Button and Operation Video




Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 5 in the Owner's Manual for more information.

HomeLink® †2 with Auto-Dimming Rearview Mirror*

The HomeLink® / Auto-Dimming Rearview Mirror* is designed to reduce glare from a vehicle's headlights located in the rear and also connect up to three electronic transmitters into one location.

- | | |
|---|---|
| A HomeLink® Channel 1 | E HomeLink® Operation Indicator |
| B HomeLink® Channel 2 | F Garage Door Opener Status Indicator: Opening or Open |
| C HomeLink® Channel 3 | G HomeLink® User Interface Indicator |
| D Garage Door Opener Status Indicator: Closing or Closed | |



QUICK TIPS

- You can reprogram a single HomeLink® button by repeating Step 2
- Erasing the programmed buttons will delete all trained transmitters

How to Sync Transmitter with HomeLink®*

If programming for the first time, begin with Step 1 (repeating this step will delete all information).

To program non-rolling and rolling code garage door openers and other devices:

1. Press and hold the left **A** and **C** buttons simultaneously until the indicator light **G** begins to flash (to reprogram buttons, skip this step)
2. Press and hold the desired button **A**, **B** or **C** and hold the button on the transmitter while it is approximately 1 to 3 inches away from the mirror. The HomeLink® Indicator light **E** will flash rapidly once the frequency signal has been successfully programmed

To finish programming rolling code garage door openers, complete these steps:

3. Locate the "learn" or "smart" button on the garage door's motor head unit. Press and release the button and complete Step 4 within 30 seconds
4. Firmly press and release the programmed HomeLink® button up to three times

Operating HomeLink®:

Press one of the programmed HomeLink® buttons.

Erasing programmed buttons:

Press and hold the **A** and **C** buttons simultaneously for approximately 20 seconds, and then release both buttons within 30 seconds.

If your garage door opener was manufactured in 2011 or later, and you're unable to program your vehicle's HomeLink® system, you may need to purchase a HomeLink Repeater Kit. For more information, go to www.HomeLink.com or call (800) 355-3515.

QR CODE

Homelink® Support Video



*Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos*


Tire Mobility Kit

The Tire Mobility Kit is designed to temporarily seal certain types of tire damage. For operational information, please refer to the Owner's Manual.

- A** Sealant Bottle
- B** Compressor

QUICK TIPS

- The Tire Mobility Kit is a temporary fix and is to be used for one tire only; the tire should be inspected as soon as possible
- The kit should only be used for sealing/inflating passenger car tires; do not use for inflating any other type of tires
- Some damaged tires cannot be sealed completely; do not use the kit if it appears a tire is damaged beyond repair



REMINDERS:


- The above images are for illustration purposes only and may not reflect actual operation
- After tire is properly sealed, drive cautiously and never exceed 50 mph or 120 miles on a tire that has been properly sealed with the Tire Mobility Kit
- Accessory spare tire kit is available for purchase

Child-Protector Rear Door Lock*

Locate these locks on the rear edge of the rear passenger doors. Move the Child-Protector Rear Door Lock, with the mechanical ignition key, to the lock position  to disable the inner door handles from opening the rear doors.

REMINDER: Child-Protector Rear Door Lock is located on rear passenger's door jamb.

Refer to section 7 in the Owner's Manual for more information.



QR CODE

Tire Mobility Kit Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 7 in the Owner's Manual for more information.


Occupant Detection System (ODS)^{†8} / Passenger Airbag Off Indicator^{†13}

ODS is designed to detect the presence and position of the front passenger and adjusts or turns off airbag deployment accordingly.

Depending on the situation and type of accident, the system may:

- Deploy airbag (Adult)
- Not deploy the airbag (Unoccupied)

If the system determines that the airbag should not be deployed, the "PASSENGER AIR BAG OFF" light will illuminate.



REMINDERS:


- Do not allow an adult passenger to ride in the front seat when the Passenger Airbag Indicator is illuminated OFF because the airbag will not deploy in the event of a crash. The driver must instruct the passenger to reposition her/himself in the seat, or move to another seat in the vehicle
- For more information on the Occupant Detection System/ Passenger Airbag Off Indicator, please refer to the Owner's Manual

QUICK TIPS

The Seat Belt warning chime operates for driver and front passenger seats only.

REMINDER: For maximum protection, always wear your Seat Belt.

Refer to section 4 in the Owner's Manual for more information.



Seat Belts^{†13}


To properly fasten your safety belts:

1. Insert the belt tongue plate **A** into the buckle **B** until it clicks
2. Position the lap portion of the belt across your lap as **LOW ON THE HIPS** as possible **C**. Adjust the belt to a **SNUG FIT** by pulling up on the shoulder portion **D**.

Seat belt retractor locks:

Retractor locks allow lap/shoulder seat belts to remain unlocked during normal vehicle operation for freedom of movement and increased comfort.

During a **STRONG STOP, SUDDEN TURN OR CERTAIN COLLISIONS**, seat belt retractors will automatically lock the belts to reduce the risk of injury.



QR CODE

Latch Anchors for the Child Restraint System Video



Refer to the inside front cover for more information on QR codes.
www.youtube.com/KiaFeatureVideos

Refer to section 4 in the Owner's Manual for more information.

LEGAL DISCLAIMERS

Driving while distracted can result in a loss of vehicle control that may lead to an accident, severe personal injury and death. The driver's primary responsibility is in the safe and legal operation of a vehicle. Handheld devices, other equipment or vehicle systems which take the driver's eyes, attention and focus away from the safe operation of a vehicle or that are not permissible by law should never be used during operation of the vehicle.

Safety Features: No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive safely.

- Kia Connect:** Purchase/lease of certain 2022 and newer Kia vehicles with Kia Connect includes a complimentary 1-year subscription starting from new vehicle retail sale/lease date as recorded by the dealer. After your complimentary 1-year Kia Connect subscription expires, continued access to the full suite of Kia Connect services available on your Kia will require a paid subscription at the then-current subscription rate or your use of certain Kia Connect features may immediately terminate. Use of Kia Connect is subject to agreement to the Kia Connect Privacy Policy (available at owners.kia.com/us/en/privacy-policy.html) and Terms of Service (available at owners.kia.com/us/en/terms-of-service.html). Complimentary Kia Connect subscription is transferable to subsequent owner during the original Kia Connect service term. Only use Kia Connect when safe to do so. Kia Connect may currently be unavailable for Model Year 2023 and newer vehicles sold or purchased in Massachusetts; please see the Kia Owners Portal for updates on availability. Kia Access app is available from the Apple® App Store® or Google Play Store®. Kia America, Inc. reserves the right to change or discontinue Kia Connect at any time without prior notification or incurring any future obligation. Message and data rates may apply. Cellular and GPS coverage is required to use most features. Kia Connect features may vary by model, model year, and trim level. Features, specifications, and fees are subject to change. For more on details and limitations, visit www.kia.com or your authorized Kia dealer. Apple® and App Store® are registered trademarks of Apple Inc. Google™ and its logos are trademarks of Google LLC.
- Android Auto™, Apple CarPlay®, Bluetooth® Wireless Technology, Google Play™ Store, iPhone, SiriusXM®, Sportmatic®, HomeLink®:** Fair Use of Trademark - The commentary reference to trademarked material is for educational purposes only and not an endorsement by or of the holder of the mark.
- Driver Assist Features - Blind-spot Collision Warning (BCW), Blind-spot Collision-Avoidance Assist (BCA), Cruise Control (CC), Forward Collision-Avoidance Assist (FCA), Forward/Reverse Parking Distance Warning (PDW), Highway Driving Assist (HDA), Intelligent Speed Limit Assist (ISLA), Lane Following Assist (LFA), Lane Keeping Assist (LKA), Leading Vehicle Departure Alert (LVDA), Navigation-based Smart Cruise Control (NSCC), Rear Cross-traffic Collision-Avoidance Assist (RCCA), Rear Occupant Alert (ROA) with Door Monitoring, Rear Parking Collision Avoidance (PCA), Rear View Monitor (RVM), Remote Smart Parking Assist (RSPA), Safe Exit Warning (SEW) and Smart Cruise Control (SCC):** When engaged, these features are not substitutes for safe driving, and may not detect all objects surrounding vehicle. Always drive safely and use caution.
- Driver Attention Warning (DAW):** When engaged, Driver Attention Warning is not a substitute for safe driving and may not detect all instances of driver fatigue or inattentive driving practices. Failure to pay attention to travel conditions and vehicle operation could result in loss of vehicle control. Always drive safely and use caution.
- Electronic Stability Control (ESC)/ Traction Control System (TCS)/Hill-start Assist Control (HAC):** No system, no matter how advanced, can compensate for all driver error and/or driving conditions. Always drive safely.
- Front Seat Headrest Adjustment:** Never attempt to adjust headrests when vehicle is in motion.
- Navigation:** Distracted driving can result in a loss of vehicle control. When operating a vehicle, never use a vehicle system that takes your focus away from safe vehicle operation. Navigation is for information purposes only, and Kia does not make any warranties about the accuracy of the information.
- Occupant Detection System (ODS):** Kia vehicles use a number of different ODS types that vary by model. Children age 12 and under should always be seated in the REAR seats.
- Power Button / Smart Key with Remote Start:** Always come to a complete stop before turning the power on or off. However, if you have an emergency while the vehicle is in motion and must turn the power off, you can turn the power off to the ACC position by pressing the Power button for more than 3 seconds or 3 times in succession. If the vehicle is still moving, you can restart the power by pressing the Power button with the shift lever in Neutral (N). With the power off, hydraulic power assist for steering and braking will be disabled and the vehicle will be more difficult to control.
- Smart Power Liftgate:** Driving with the liftgate open may be unlawful and can draw dangerous exhaust fumes into your vehicle; if you choose to do so, keep air vents and all windows open for improved ventilation.
- Roadside Assist:** 24-hour Enhanced Roadside Assistance is a service plan provided by Kia America, Inc. Certain limitations apply. Coverage details are available in the Kia Warranty and Consumer Information Manual. On certain audio systems, for access to Enhanced Roadside Assistance®, a connected mobile phone via Bluetooth® within the cellular service coverage area is required.
- Seat Adjustments:** Reclining the passenger seats can reduce the effectiveness of the safety restraint system and may lead to additional injury in an accident.
- Seat Belts / Airbags:** For maximum protection, always wear your seatbelt.
- Seat Warmers:** Use extreme caution when using the seat warmers to avoid burns. Refer to the Owner's Manual for more information.
- SiriusXM®:** SiriusXM Satellite Radio, SiriusXM Traffic and SiriusXM Travel Link each require a subscription sold separately, or as a package, by SiriusXM Radio Inc. If you decide to continue your service at the end of your trial subscription, the plan you choose will automatically renew and bill at then-current rates until you call 1-866-635-2349 to cancel. See SiriusXM Customer Agreement for complete terms at www.siriusxm.com. Other fees and taxes will apply. All fees and programming are subject to change. Not all vehicles or devices are capable of receiving all services offered by SiriusXM. Data displays and individual product availability vary by vehicle hardware. Current information and features may not be available in all locations, or on all receivers. Weather Forecast, Current Conditions may not be available in all locations. Images above are for representative purposes only and are not real products. For actual features and images of real products, consult the vehicle manufacturer. SiriusXM is not responsible for any errors or inaccuracies in the data services or their use in the vehicle. Travel Link Stocks displays current price and daily delta of around 7,000 actively reported securities traded on the NYSE®, NASDAQ® and AMEX®. The service is delayed approximately 20 minutes. SiriusXM satellite service is available only to those at least 18 years of age in the 48 contiguous USA, DC, and Puerto Rico (with coverage limitations). SiriusXM Internet Radio service is available throughout our satellite service area and in AK and HI. ©2022 SiriusXM Radio Inc. Sirius, XM and all related marks and logos are trademarks of SiriusXM Radio Inc.
- Steering-Wheel-Mounted Controls:** Driving while distracted is dangerous and should be avoided. Remain attentive to driving and be cautious when using steering-wheel-mounted controls while driving.
- Sun Visors:** Sun Visor may not shield all direct light. Do not operate the vehicle if Sun Visor is impairing your visibility.
- Tilt/Telescoping Steering Wheel:** Never attempt to adjust steering wheel position when vehicle is in motion.
- Tire Pressure Monitoring System (TPMS):** Even with Tire Pressure Monitoring System, check tire pressure on a regular basis.
- Liftgate:** Driving with the liftgate open may be unlawful and can draw dangerous exhaust fumes into your vehicle; if you choose to do so, keep air vents and all windows open for improved ventilation.
- The **myQ logo** is a registered trademark of The Chamberlain Group, Inc.



NIRO EV NORMAL MAINTENANCE SCHEDULE

(up to 64,000 miles)^A

MAINTENANCE ITEMS	MAINTENANCE INTERVALS (MILES)							
	8,000	16,000	24,000	32,000	40,000	48,000	56,000	64,000
Check tire pressure and tread wear; Rotate tires	P	P	P	P	P	P	P	P
Climate control air filter ‡	I	R	I	R	I	R	I	R
Brake fluid	I	I	I	I	I	R	I	I
12V battery condition	I	I	I	I	I	I	I	I
Steering gear rack, linkage & boots	I	I	I	I	I	I	I	I
Air conditioner refrigerant/compressor ‡	I	I	I	I	I	I	I	I
Brake lines, hoses and connections	I	I	I	I	I	I	I	I
Brake discs and pads	I	I	I	I	I	I	I	I
Suspension ball joints	I	I	I	I	I	I	I	I
Cooling system	I	I	I	I	I	I	I	I
Drive shafts and boots		I		I		I		I
Reduction gear fluid				I			I	

P=Perform R=Replace I=Inspect^B

QUICK TIP

Check your Maintenance Schedule or schedule an appointment with a dealer using your Kia Connect account by logging into Kia Access App or your account on <https://owners.kia.com> (See page 42 for setup information)

‡ If equipped.

A. See the Owner's Manual for complete maintenance schedule.

B. And, if necessary, adjust, correct, clean or replace.

See your Owner's Manual for more details and complete maintenance information, including severe maintenance schedule. Warranty may be voided if maintenance schedule is not followed.

© 2022 Kia America, Inc.
All rights reserved.

Consumer - Roadside Assistance¹¹⁾:
1-800-333-4KIA (4542)

Part Number: SGEV230-PS-004

‡ If equipped

† LEGAL DISCLAIMERS ON BACK INSIDE COVER