



EyeSight[®]

Driver Assist Technology

Quick Guide

2020



© 2019 Subaru of America, Inc. All rights reserved.

Contents may not be reproduced in whole or in part without prior written permission of publisher. Specifications in this Guide are based on the latest product information available at the time of publication. Some images shown are for illustration purposes only. Some equipment shown in photography within this Guide is optional at extra cost. Specific options may be available only in combination with other options. Specific combinations of equipment or features may vary from time to time, and by geographic area. Subaru of America, Inc. reserves the right to change or discontinue at any time, without notice: Prices, colors, materials, equipment, accessories, specifications, models and packages, without incurring any obligation to make the same or similar changes on vehicles previously sold. Colors shown may vary due to reproduction and printing processes. Subaru of America, Inc. is not responsible for typographical errors.

Aha™ is a trademark of Harman International Industries, Inc. Alcantara® is a registered trademark of Alcantara S.p.A., and Alcantara is produced by the Toray Group. App Store® is a registered trademark of Apple, Inc. Apple® is a registered trademark of Apple, Inc. BBS® is a registered trademark of BBS Kraftfahrzeugtechnik, AG. Bluetooth® is a registered trademark of Bluetooth SIG, Inc. Brembo® is a registered trademark of Freni Brembo, S.p.A. GreenEdge® is a registered trademark of Harman International Industries, Inc. Harman Kardor® is a registered trademark of Harman International Industries, Inc. HD Radio® is a registered trademark of iBiquity Digital Corporation. HomeLink® is a registered trademark of Prince Corporation, a wholly owned subsidiary of Johnson Controls. iHeart® Radio is a registered trademark of iHeartMedia, Inc. iPod® is a registered trademark of Apple, Inc. iTunes® is a registered trademark of Apple, Inc. Metal-Matrix Diaphragm (MMD®) is a registered trademark of Harman International Industries, Inc. MirrorLink™ is a trademark of Car Connectivity Consortium, LLC. Pandora® is a registered trademark of Pandora Media, Inc. Siri® is a registered trademark of Apple, Inc. Smart Way® is a registered trademark of the U.S. Environmental Protection Agency. Stitcher™ is a trademark of Stitcher™, Inc. TORSEN LSD® is a registered trademark of JTEKT TORSEN North America, Inc. SiriusXM® All Access Radio is a registered trademark of SiriusXM Radio, Inc. SiriusXM Traffic® and SiriusXM Travel Link® are registered trademarks of SiriusXM Radio, Inc. Added Security, Crosstrek, Forester and Outback are registered trademarks of Subaru of America, Inc. Ascent, DriverFocus and StarTex are trademarks of Subaru of America, Inc. BRZ, EyeSight, Impreza, Lineartronic, Legacy, Subaru, SUBARU BOXER, Starlink, Subaru Starlink, WRX, STI and X-MODE are registered trademarks of Subaru Corporation. Confidence in Motion is a trademark of Subaru Corporation.

TABLE OF CONTENTS



PURPOSE OF THIS GUIDE

- 3 **FORWARD**
- 3 **IMPORTANT SAFETY INFORMATION**
- 3 **ADDITIONAL RESOURCES**

EYESIGHT®

- 4 **OVERVIEW**
- 4 **OPERATION**
- 5 **FUNCTIONS**
- 8 **STEERING WHEEL CONTROLS**
- 9 **EYESIGHT® ASSIST MONITOR (EAM) (if equipped)**
- 10 **LANE DEPARTURE WARNING AND PRE-COLLISION
BRAKING SYSTEM OFF SWITCHES**

DRIVER ASSIST TECHNOLOGIES

- 11 **REAR-VISION CAMERA**
- 11 **FRONT VIEW MONITOR (if equipped)**
- 11 **BLIND-SPOT DETECTION (BSD)/ REAR CROSS-
TRAFFIC ALERT (RCTA) (if equipped)**
- 12 **HIGH BEAM ASSIST (HBA) (if equipped)**
- 12 **STEERING RESPONSIVE HEADLIGHTS (SRH)
(if equipped)**
- 13 **REVERSE AUTOMATIC BRAKING (RAB) (if equipped)**

TABLE OF CONTENTS

CARE AND LIMITATIONS

14 **STEREO CAMERA PRECAUTIONS**

14 **WINDSHIELD GLASS AND DASHBOARD**

FRONT VIEW

15 **Crosstrek, Crosstrek Hybrid, WRX (Front View)**

15 **Ascent (Front View)**

16 **Impreza (Front View)**

17 **Index**

PURPOSE OF THIS GUIDE

FORWARD

Congratulations on choosing a Subaru vehicle! This Quick Guide is designed to provide information on the basic operation and key features of the EyeSight and Driver Assist Systems on your Subaru vehicle.

IMPORTANT SAFETY INFORMATION

The Quick Guide is not intended as a substitute for the EyeSight® Owner's Manual. Some of the features and functions covered in this guide may vary by model and trim level. We strongly encourage you to review the entire EyeSight® Owner's Manual to ensure complete understanding. EyeSight® is a driver assistance system that may not operate optimally under all driving conditions. The driver at all times remains responsible for safe and attentive driving. Performance of the EyeSight® system depends on many factors, including vehicle maintenance, weather and road conditions. See the EyeSight® Owner's Manual for complete details on system operation and important limitations.

ADDITIONAL RESOURCES

If you're having difficulty using any of the functions outlined in this guide, you can get more information from the following sources:

Your Subaru EyeSight® Owner's Manual:

Located in the glovebox

Online Subaru Owner's Resources:

www.subaru.com/owners

Subaru Customer Support:

www.subaru.com/customer-support

1-800-SUBARU3 (1-800-782-2783)



Scan to learn more
about **Owner's
Resources**.



Scan to learn more
about **Customer
Support**.



Scan to get the **MySubaru** App.




Scan to get the **SUBARU STARLINK®** App.

EYESIGHT®

OVERVIEW

Your Subaru features a variety of safety systems that are the culmination of everything Subaru Engineers know about safety. These systems are referred to as “Driver Assist Technologies” and add confidence to every trip you and your passengers take. Working together, these systems provide enhanced awareness, safety, and convenience in front, to the sides, and behind your Subaru. Subaru Driver Assist Technologies include:

- EyeSight® Driver Assist Technology
- Rear-Vision Camera
- Front View Monitor
- Blind-Spot Detection (BSD)
- Rear Cross-Traffic Alert (RCTA)
- Reverse Automatic Braking (RAB)
- High Beam Assist (HBA)
- Steering Responsive Headlights (SRH)



OPERATION

EyeSight® is a driver assist technology that uses dual color cameras to serve as an extra pair of eyes on the road ahead to identify vehicles in front, pedestrians, traffic lanes, or other objects. If need be, the EyeSight® system can apply the brakes and/or reduce engine power to help avoid or reduce the severity of a collision. During these events, the system will provide audible and visual alerts to assist you in making decisions.

Since the characteristics and limitations of the EyeSight® color cameras are similar to humans, it is important that the cameras, windshield, and area in front of the cameras are treated with special care. For more information, please refer to “Care and Limitations” on page 14 for more details.



FUNCTIONS

The EyeSight® system features several distinct functions designed to provide extra awareness, improve safety, reduce fatigue, and add peace of mind every time you drive your Subaru. EyeSight® functions include:

- Pre-Collision Braking (PCB)
- Pre-Collision Brake Assist
- Pre-Collision Throttle Management
- Lane Departure Warning (LDW)
- Lane Sway Warning
- Lane Keep Assist (LKA)
- Adaptive Cruise Control (ACC)
- Conventional Cruise Control
- Lead Vehicle Start Alert

Pre-Collision Braking

This function helps prevent or minimize a frontal collision with another vehicle, pedestrian, or other objects by providing visual and audible warnings. Warnings are displayed in the Combination Meter Display (CMD) and/or Multi-Function Display (MFD) with audible beeps. If you take no corrective action, the system automatically reduces engine power and applies the brakes with increasing force to help prevent or minimize the collision. This system can be turned on or off by using the Pre-Collision Braking System OFF switch (please refer to page 10).



Pre-Collision Brake Assist

This function recognizes a possible collision with another vehicle, a pedestrian, or object in front while you are applying the brakes. If the system determines you are not applying enough force, it can assist by applying additional pressure to the braking system to decrease stopping distance. This function can be turned on or off by using the Pre-Collision Braking System OFF switch (please refer to page 10).

Pre-Collision Throttle Management

This function is designed to help prevent you from unintentionally accelerating into a stopped vehicle or other obstacle by reducing engine power. Warnings are displayed in the Combination Meter Display (CMD) with audible beeps.

This function can be turned on or off by using the Pre-Collision Braking System OFF switch (please refer to page 10).


EYESIGHT[®]

Pre-Collision Throttle Management is helpful when:

- You unintentionally place the select lever in the “D” position instead of the “R” position and start to accelerate toward a parked car, wall or parking structure.
- You start to merge onto another road when the vehicle ahead accelerates, but suddenly stops.


Lane Departure Warning

This function provides audible and visual warnings if you are about to depart your lane of travel. Using the EyeSight[®] camera, the Lane Departure Warning function identifies lane markings when traveling at speeds of approximately 30 mph or greater. Warnings are displayed in the Combination Meter Display (CMD) with audible beeps. Lane Departure Warning does not provide any corrective actions. This function can be turned on or off with the Lane Departure Warning OFF switch (please refer to page 10).



Lane Sway Warning


This function detects repetitive or unusual side-to-side vehicle movement within a lane of travel that may indicate a drowsy or inattentive driver. Using the EyeSight[®] camera, the Lane Sway Warning function identifies lane markings when traveling at speeds of approximately 37 mph or greater. Warnings are displayed in the Combination Meter Display (CMD) with audible beeps. Lane Departure Warning does not provide any corrective actions. This function can be turned on or off with the Lane Departure Warning OFF switch (please refer to page 10).



Lane Keep Assist (LKA)

This function provides steering assistance to keep your Subaru in it's lane of travel when cruising on expressways, freeways, and interstate highways. Using the EyeSight[®] camera, the Lane Keep Assist function identifies lane markings when traveling at speeds of approximately 37 mph or greater.

This function is turned on or off using the Lane Keep Assist button on the right side of the steering wheel. Once the system is turned on, a white Lane Keep Assist icon will be displayed on the Combination Meter Display (CMD). As you drive the vehicle above the minimum speed, white lane marking graphics on the CMD will indicate that right and/or left lane markings have been successfully identified by the EyeSight[®] camera. If your Subaru is about to depart the driving lane, the system can assist the steering by gently guiding the vehicle back into your lane. When the system is actively providing assistance, the Lane Keep Assist icon in the CMD will change from white to green.



Adaptive Cruise Control (ACC)

This system provides Cruise Control with the ability to keep a safe distance from the car in front of you. Using the EyeSight® camera, the Adaptive Cruise Control function identifies vehicles in front when traveling at speeds of approximately 20 mph or greater and manages the acceleration/deceleration of your Subaru to maintain a set speed and distance.



Adaptive Cruise Control is turned on or off using the Adaptive Cruise Control button on the right side of the steering wheel (please refer to page 8). Once the system is turned on, a white Adaptive Cruise Control icon will be displayed on the Combination Meter Display (CMD).

To set Adaptive Cruise Control, push the “SET/-” switch on the right side of the steering wheel. The CMD will indicate a target speed. This speed can be adjusted up or down using the “RES/SET” switch (please refer to page 8).

When a vehicle in front of you is identified, a Lead Vehicle icon will be displayed on the Combination Meter Display (CMD) and/or Multi-Function Display (MFD). You can change the desired following distance from the lead vehicle by pressing the “Following Distance” button or the “Increase Distance” or “Decrease Distance” buttons depending on which steering wheel switch you have (please refer to page 8).

Conventional Cruise Control

Conventional Cruise Control maintains a constant traveling speed set by the driver, but does not adapt to other vehicles in front of your Subaru. To switch to Conventional Cruise Control, press and hold either the “Following Distance Setting” button or the “Increase Distance” or “Decrease Distance” buttons on the steering wheel for approximately two seconds. The Cruise Control indicator on the Combination Meter Display (CMD) will change from the Adaptive Cruise Control icon to the Conventional Cruise Control icon.



Lead Vehicle Start Alert

This function provides visual and audible alerts when a vehicle in front of you starts to move, but you have not. Warnings are displayed in the Combination Meter Display (CMD) with audible beeps. Lead Vehicle Start Alert is helpful in situations where you may become temporarily distracted at a traffic light and the vehicle ahead begins to move. This function can be customized using the steering wheel mounted “i/SET” switches to access the EyeSight® settings menu on the CMD.



STEERING WHEEL CONTROLS

Adaptive Cruise Control

The appearance of the steering wheel controls may vary across Subaru models.

- 1 Adaptive Cruise Control (ACC):** Press to turn Adaptive Cruise Control (ACC) on or off.
- 2 Resume/Set:** Press the switch down to set an initial target speed. Once set, press up or down to adjust the target speed.
 - Press up the “RES/+” side briefly to increase the vehicle set speed in 5 mph increments. Press up and hold to increase the set speed in 1 mph increments while being held.
 - Press down the “SET/-” side briefly to decrease the set speed in 5 mph increments. Press down and hold to decrease the set speed in 1 mph increments while being held.
 - The Cruise Control Acceleration Characteristics can be adjusted to four different levels depending on your preference. The four levels are:
 - Lv. 1 Eco
 - Lv. 2 Comfort
 - Lv. 3 Standard
 - Lv. 4 Dynamic



Type 1



Type 2

To change this setting, use the steering wheel mounted “i/SET” switches to access the “EyeSight®” settings menu on the Combination Meter Display (CMD).

- 3 Decrease Distance:** Press to decrease the following distance setting while using Adaptive Cruise Control. Press and hold to switch to Conventional Cruise Control.
- 4 Increase Distance:** Press to increase the following distance setting while using Adaptive Cruise Control. Press and hold to switch to Conventional Cruise Control.
- 5 Following Distance:** Press this button to change the following distance between Far, Medium and Close settings to your preferred distance. If pressed a third time it will return to the Far setting. Press and hold to switch to Conventional Cruise Control.
- 6 Lane Keep Assist (LKA):** Press to turn Lane Keep Assist (LKA) on or off.

Customizing EyeSight® Settings


The EyeSight® system features customization of certain preferences and warnings. Use steering wheel mounted “i/Set” switches to navigate through the Combination Meter Display (CMD) to adjust settings such as:

- Warning Volume: Min/Mid/Max
- Cruise Control Acceleration Characteristics: Eco/Comfort/Standard/Dynamic



EYESIGHT® ASSIST MONITOR (EAM) (if equipped)

The EyeSight® Assist Monitor (EAM) provides a heads-up display of EyeSight® system functions in the lower windshield area allowing you to keep your eyes on the road ahead. The EAM indicators can be changed using the steering wheel mounted “i/SET” switches to access the “EyeSight®” settings menu on the Combination Meter Display (CMD). Below are the indications provided by the EAM function:



LED COLOR	PATTERN	WARNING CONDITION
Green	Solid illumination	A lead vehicle is detected ahead while Adaptive Cruise Control is operating
Yellow	Flashing on one side	Lane Departure Warning is operating; flashes on side of departure
	Flashing alternately	Lane Sway Warning is operating
	Flashing simultaneously	Steering wheel operation could not be detected for a certain period of time
Red	Flashing simultaneously (4) indicators	Following Distance Warning, Pre-Collision Braking System, Obstacle Detected Warning, or Pre-Collision Throttle Management is operating

LANE DEPARTURE WARNING AND PRE-COLLISION BRAKING SYSTEM OFF SWITCHES

Lane Departure Warning OFF Switch

Press and hold this switch on the overhead console for two seconds to turn off Lane Departure Warning and the Lane Sway Warning functions. Press and hold the switch again for two seconds to turn the functions on. When this function is off, a yellow Lane Departure Warning indicator will be illuminated in the Combination Meter. An example of a situation where it may be helpful to turn these functions off is when lane markings on the road are inconsistent.



Pre-Collision Braking OFF Switch

Press and hold this switch on the overhead console for two seconds to turn off the Pre-Collision Braking, Pre-Collision Brake Assist, and Pre-Collision Throttle Management functions. Press and hold the switch again for two seconds to turn the functions on. When these functions are off, a yellow Pre-Collision Braking indicator will be illuminated in the Combination Meter. An example of a situation where it may be helpful to turn these functions off is when taking your Subaru through an automatic carwash.



DRIVER ASSIST TECHNOLOGIES

REAR-VISION CAMERA

This function provides a clearer view of the area behind your Subaru to help avoid obstacles. Using a wide-angle camera mounted on the rear of the vehicle, an image is automatically displayed on the multimedia screen when the select lever is placed in the “R” position. The displayed image features a centerline indicator, colored distance markers, and dynamic guide lines that move as the steering wheel is turned.




FRONT VIEW MONITOR (if equipped)

The Front View Monitor provides 180-degree visibility from the front grille of your Subaru. This improves visibility when making turns with an obstructed view or pulling into a narrow parking spot.



Press the “VIEW” button on the center console to display the Front View Monitor image on the Multi-Function Display (MFD). A guide line is also displayed to provide distance and width references. You can manually turn off the Front View Monitor off by pressing the “VIEW” button again or the function will automatically turn off. Camera settings can be adjusted through the Settings menu in the MFD.



BLIND-SPOT DETECTION (BSD)/ REAR CROSS-TRAFFIC ALERT (RCTA) (if equipped)

This system uses radar sensors mounted behind the rear bumper on the left and right sides of your Subaru to warn you if another vehicle is sensed in your blind spots. These functions provide additional awareness when changing lanes or driving in reverse.



BSD/RCTA can be turned on or off by pressing the BSD/RCTA off switch. When this function is off, a BSD/RCTA indicator will be displayed on Combination Meter Display (CMD).

DRIVER ASSIST TECHNOLOGIES

Blind-Spot Detection (BSD)

This function senses if a vehicle is in your blind spot and provides a visual warning (yellow light) in the corresponding side mirror frame. The default operation of BSD is on.



Lane Change Assist (LCA)

Lane change assist works with BSD to provide an additional level of warning when you attempt change lanes with a vehicle in your blind spot. LCA will rapidly flash the corresponding side mirror indicator if you operate your turn signal. The default operation of LCA is on.

Rear Cross-Traffic Alert (RCTA)

This function detects a vehicle approaching from either side as you are reversing and provides audible and visual warnings. Warnings will appear in the upper corners of the Rear-Vision Camera display and the side mirrors with audible beeps. The default operation of RCTA is on.



HIGH BEAM ASSIST (HBA) (if equipped)

This function uses the EyeSight® camera to automatically switch the headlights between high and low beam setting when an oncoming vehicle is detected, enhancing safety for both you and other drivers on the road.



To activate High Beam Assist, set the headlight control switch to the “AUTO” position and push the headlight stalk forward to the high beam position. The green HBA indicator will illuminate on the Combination Meter Display (CMD). When vehicle speed is above approximately 20 mph, HBA will automatically switch between high and low beams. When the high beams are activated, the blue high beam indicator will be displayed on the Combination Meter Display (CMD).

STEERING RESPONSIVE HEADLIGHTS (SRH) (if equipped)

The Steering Responsive Headlights (SRH) system aims the headlight beams in the direction you are steering. This helps to improve visibility at corners and intersections when driving at night. While the system is normally on, you can turn the system off using the steering wheel mounted “i/SET” switches to access the “SRH” settings menu on the Combination Meter Display (CMD).

DRIVER ASSIST TECHNOLOGIES

REVERSE AUTOMATIC BRAKING (RAB) (if equipped)

This system uses four rear bumper mounted sonar sensors to detect objects when your Subaru is moving between 1 and 9 mph in reverse. RAB uses the Rear-View Camera image to display colored proximity alerts when an object is detected. As an object becomes closer to the rear of your vehicle, audible beeps provide additional awareness in three progressive levels. If RAB determines that a collision with an object is possible, the system can automatically apply the brakes to help prevent or minimize the impact.



The default operation of the RAB system is on, but in some cases, such as connecting a trailer, it may be helpful to temporarily turn the system off. RAB can be turned off using the Touchscreen buttons on the lower corners when the select lever is in the "R" position.

All functions will automatically return to "ON" the next time the select lever is shifted to the "R" position.

Touch and hold the "P))) ON" button in the lower left of the Touchscreen until it changes to "P))) OFF" to disable the audible beeping of the RAB system.



Touch and hold the "RAB ON" button in the lower left of the Touchscreen until it changes to "RAB OFF" to disable the automatic braking functions of the RAB system.



CARE AND LIMITATIONS

STEREO CAMERA PRECAUTIONS

Your EyeSight® stereo cameras are precision components that must be kept free from obstruction and contamination such as fingerprints or cleaning solutions. When the system detects that the stereo camera lenses are impaired a malfunction indicator will be displayed and EyeSight® functions will not be available.

When you are in the vicinity of the EyeSight® stereo cameras, always observe the following precautions:

- Do not touch or attempt to clean the EyeSight® camera lenses inside the vehicle. Extra caution should be used when cleaning the inside of the windshield. Over-spray from cleaning solutions may impair or even damage the camera lenses. Please inform others who may attempt to clean the windshield, such as car wash staff, of this precaution.
- Electronic Toll Collection devices, such as EZPass™, must be installed in an area that does not obstruct the stereo cameras' field of vision. See "Prohibited Areas" on page 15.
- Adjust the rearview mirror so it does not obstruct the stereo cameras' field of vision.
- Do not install any interior rearview mirror accessories such as a wide-type mirror or hanging objects. Only approved Genuine SUBARU accessories may be installed.


For more detailed information, please refer to your EyeSight® Owner's Manual.

WINDSHIELD GLASS AND DASHBOARD

Since the characteristics of the EyeSight® stereo cameras are similar to human limitations, it is important that the area in front of the cameras be kept free from dirt, scratches, cracks, fogging, or accessories mounted to the windshield, hood or dashboard. Visual impairments or reflections can affect EyeSight® system performance. Extra caution should be taken when cleaning the windshield to prevent over-spray from cleaning solutions.

The images in the section below outline those areas that must be kept clean and free from obstruction. Please refer to the Owner's Manual for a complete listing of limitations.


Crosstrek, Crosstrek Hybrid, WRX (Front View)



(A) 13.2 in (355 mm)
(B) 5.5 in (139 mm)
(C) 9.6 in (243 mm)

(D) Prohibited area (in gray)
(E) 7.9 in (200 mm)

Ascent (Front View)




(A) 13.2 in (355 mm)
(B) 5.5 in (139 mm)

(C) 9.6 in (243 mm)
(D) Prohibited area (in gray)

FRONT VIEW

Impreza (Front View)



(A) 13.2 in (355 mm)

(B) 5.5 in (139 mm)

(C) 9.6 in (243 mm)

(D) Prohibited area (in gray)

A

ADDITIONAL RESOURCES	3
Ascent (Front View)	15

B

BLIND-SPOT DETECTION (BSD)/ REAR CROSS-TRAFFIC ALERT (RCTA)	
Blind-Spot Detection (BSD)	11
Lane Change Assist (LCA)	12
Rear Cross-Traffic Alert (RCTA)	12

C

Crosstrek, Crosstrek Hybrid, WRX (Front View)	15
--	----

E

EYESIGHT® ASSIST MONITOR (EAM)	9
--------------------------------	---

F

FORWARD	3
FRONT VIEW MONITOR	11
FUNCTIONS	
Adaptive Cruise Control (ACC)	5
Conventional Cruise Control	7
Lane Departure Warning	6
Lane Keep Assist (LKA)	6
Lane Sway Warning	6
Lead Vehicle Start Alert	7
Pre-Collision Brake Assist	5
Pre-Collision Braking	5
Pre-Collision Throttle Management	5

H

HIGH BEAM ASSIST (HBA)	12
------------------------	----

I

IMPORTANT SAFETY INFORMATION	3
Impreza (Front View)	16

L

LANE DEPARTURE WARNING AND PRE-COLLISION BRAKING SYSTEM OFF SWITCHES	
Lane Departure Warning OFF Switch	10
Pre-Collision Braking OFF Switch	10

O

OPERATION	4
OVERVIEW	4

R

REAR-VISION CAMERA	11
REVERSE AUTOMATIC BRAKING (RAB)	13

S

STEERING RESPONSIVE HEADLIGHTS (SRH)	12
STEERING WHEEL CONTROLS	
Adaptive Cruise Control	8
Customizing EyeSight® Settings	9
STEREO CAMERA PRECAUTIONS	14

W

WINDSHIELD GLASS AND DASHBOARD	14
-----------------------------------	----

NOTES

[illegible]

NOTES

[illegible]

NOTES

[illegible]

NOTES

[illegible]

EyeSight® is a driver assist system that may not operate optimally under all driving conditions. The driver is always responsible for safe and attentive driving. System effectiveness depends on many factors such as vehicle maintenance, tire condition, and weather and road conditions. See the EyeSight® Owner's Manual for complete details on system operation and limitations.

All information contained within this EyeSight® guide was accurate at the time of publication. Subaru of America, Inc. reserves the right to change features, operation and/or functionality of any vehicle specification at any time without incurring any obligation to make the same or similar changes to products previously sold. Your Subaru Retailer is the best source for the most current information. For detailed operating and safety information, always consult the Owner's Manual.



MSA5B2014A
Issued September 2019
Printed in USA 09/19

