




2020 DODGE CHALLENGER QUICK REFERENCE GUIDE

VEHICLE USER GUIDE — IF EQUIPPED

VEHICLE USER GUIDE — IF EQUIPPED

To access the Vehicle User Guide on your Uconnect Touchscreen: Tap the Uconnect **Apps** button, then tap the **Vehicle User Guide** icon on your touchscreen. No Uconnect registration is required.



**Uconnect 4C NAV With 8.4-inch Display Vehicle
User Guide Touchscreen Icon**

NOTE:

Vehicle User Guide features are not available while the vehicle is moving.

Features

- Your User Guide — Updated in real-time
- Available when and where you need it
- Touchscreen convenience
- Customizable interface
- Maintenance schedules and information
- Multilingual
- Comprehensive icon and symbol glossary

For further information, and applicable warnings and cautions, please refer to the Owner's Manual at www.mopar.com/en-us/care/owners-manual.html (U.S. Residents) or www.owners.mopar.ca (Canadian Residents).

PASSIVE ENTRY

KEYLESS ENTER-N-GO — PASSIVE ENTRY

The Keyless Enter-N-Go system is an enhancement to the vehicle's key fob. This feature allows you to lock and unlock the vehicle's door(s) and trunk without having to press the key fob lock or unlock buttons.

TO UNLOCK FROM THE DRIVER OR PASSENGER SIDE




Grab The Door Handle To Unlock

- With a valid Keyless Enter-N-Go key fob located outside the vehicle and within 5 ft (1.5 m) of the driver or passenger side door handle, grab either front door handle to unlock the door automatically.

TO LOCK THE VEHICLE

- Both front door handles have buttons located on the outside of the handle. With one of the vehicle's Keyless Enter-N-Go key fobs located outside the vehicle and within 5 ft (1.5 m) of the driver or passenger front door handle, push the door handle button to lock the two doors and trunk.
- Do NOT grab the door handle when pushing the door handle button. This could unlock the door(s).



Push The Button To Lock



Do NOT Grab The Handle When Locking

NOTE:

- If “Unlock All Doors 1st Press” is programmed, all doors will unlock when you grab hold of the driver's door handle. Additionally, all doors and the trunk will unlock with this option programmed when you push the trunk button.
- If a key fob is detected in the vehicle when locking the vehicle using the power door lock switch, the doors and trunk will unlock, and the horn will chirp three times. On the third attempt, your key fob can be locked inside the vehicle.
- After pushing the Keyless Enter-N-Go lock button, you must wait two seconds before you can lock or unlock the vehicle using the door handle. This is done to allow you

to check if the vehicle is locked by pulling the door handle without the vehicle reacting and unlocking.

- If a Keyless Enter-N-Go door handle has not been used for 72 hours, the Keyless Enter-N-Go feature for that handle may time out. Pulling the deactivated front door handle will reactivate the door handle's Keyless Enter-N-Go feature.

TO ENTER THE TRUNK



Trunk Release Button

- With a valid Keyless Enter-N-Go key fob located outside the vehicle and within 5 ft (1.5 m) of the deck lid, push the button located on the center of the light bar which is located on the deck lid above the license plate.

INSTRUMENT CLUSTER DISPLAY

INSTRUMENT CLUSTER DISPLAY

The instrument cluster display features an interactive driver display that is located in the instrument cluster. Pushing the controls on the left side of the steering wheel allows the driver to select Vehicle Information and Personal Settings.



Instrument Cluster Display Controls

- Push the **up** button to scroll upward through the main menus (Speedometer, mph/km/h, Vehicle Info, Performance Pages – SRT only, Driver Assist — If Equipped, Fuel Economy, Trip A, Trip B, Audio, Messages, Screen Set Up).
- Push the **down** button to scroll downward through the main menu and submenus (Speedometer, mph/km/h, Vehicle Info, Driver Assist, Fuel Economy, Trip A, Trip B, Audio, Stored Messages, Screen Set Up).
- Push the **right** button to access the information screens or submenu screens of a main menu item.
- Push the **left** button to access the information screens or submenu screens of a main menu item.
- Push the **OK** button to access/select the information screens or submenu screens of a main menu item. Push and hold the **OK** button for two seconds to reset displayed/selected features that can be reset. Pushing the **OK** button will also toggle between mph and km/h on the digital speedometer.

Compass Calibration

This compass is self-calibrating, which eliminates the need to set the compass manually. When the vehicle is new, the compass may appear erratic, and the cluster will display dashes (- -) until the compass is calibrated.

You may also calibrate the compass by completing one or more 360 degree turns (in an area free from large metal or metallic objects) until the dashes (- -) displayed in the cluster turn off. The compass will now function normally.

PHONE PAIRING

PAIRING PROCEDURE

Mobile phone pairing is the process of establishing a wireless connection between a cellular phone and the Uconnect system.

Start Pairing Procedure On The Radio

Uconnect 4C & 4C NAV With 8.4-inch Display



Uconnect 4C & 4C NAV With 8.4-inch Display

1. Place the ignition in the ACC or ON/RUN position.
2. Tap the Phone icon in the Menu Bar on the touchscreen.
 - If no phone is connected to the vehicle, a message will display asking to pair a phone. Select “Yes” to this message. After pressing “Yes”, the radio prompts will take you through the steps to connect your phone via Bluetooth®.

- Uconnect Phone will display an “In progress” screen while the system is connecting. A message will display if pairing is successful. Click “OK” to this message.

Phone pairing can also be accessed by:

1. Placing the ignition in the ACC or ON/RUN position.
2. Pressing the Apps button in the Menu Bar on the touchscreen.
3. Pressing “Settings”.
4. Pressing “Phone/Bluetooth®”.
5. Pressing “Paired Phones and Audio Devices”.
6. Pressing “Add Devices”.

Then, proceed to follow on-screen instructions to pair phone with vehicle.

NOTE:

Uconnect Phone will display an “In progress” screen while the system is connecting.

NOTE:

During the pairing procedure, you may receive a pop-up on your mobile phone for the Uconnect system to access your “messages” and “contacts”. Selecting “OK” or “Allow” will sync your contacts with the Uconnect system.

Pair Your iPhone®:

For further information on how to activate Bluetooth® on your iPhone®, refer to your phone's User Manual.

Complete The iPhone® Pairing Procedure:

After Bluetooth® is activated on your mobile phone, confirm the passkey shown on the mobile phone matches the passkey shown on the Uconnect system, then accept the Bluetooth® pairing request.

Pair Your Android™ Device:

For further information on how to activate Bluetooth® on your Android® device, refer to your phone's User Manual.

Complete The Android™ Pairing Procedure:

After Bluetooth® is activated on your mobile phone, confirm the passkey shown on the mobile phone matches the passkey shown on the Uconnect system, then accept the Bluetooth® pairing request.

For further information on Uconnect Phone, please refer to “Uconnect Phone” in the vehicle’s Owner’s Manual or the Uconnect Supplement.

LIGHTS

AUTOMATIC HIGH BEAM — IF EQUIPPED

This system automatically controls the operation of the headlamp high beams as oncoming vehicles approach.

- The Automatic High Beam Headlamp Control can be turned on or off using the Uconnect system.

- Push the turn signal lever away from you.
- With the headlight switch in the AUTO position, the high beams are controlled automatically.
- Pull the turn signal lever toward you to manually deactivate the system.
- To improve system recognition of crossing traffic, and to limit use in a residential area, the vehicle must be moving at a speed greater than 20 mph (32 km/h) before the Automatic High Beam Module (AHBM) begins requesting high beam activation.

NOTE:

If the windshield or Automatic High Beam Headlamp Control mirror is replaced, the mirror must be re-aimed to ensure proper performance. See a local authorized dealer.

SPEED CONTROL

ADAPTIVE CRUISE CONTROL (ACC) — IF EQUIPPED

If your vehicle is equipped with Adaptive Cruise Control, the controls operate exactly the same as the standard cruise control, with one difference. You can set a specified distance you would like to maintain between you and the vehicle in front of you.

- If the ACC sensor detects a vehicle ahead, ACC will apply limited braking or acceleration automatically to maintain a preset following distance while matching the speed of the vehicle ahead.

NOTE:

Your vehicle will not exceed the cruise speed you have set.

- If the sensor does not detect a vehicle directly ahead of you, it functions like a standard cruise control system, maintaining the speed you set.



Adaptive Cruise Switches

- 1 — Adaptive Cruise Control (ACC) On/Off
- 2 — Distance Setting – Decrease
- 3 — Distance Setting – Increase

SAFETY FEATURES

FORWARD COLLISION WARNING (FCW) – IF EQUIPPED

The Forward Collision Warning (FCW) system provides the driver with audible warnings and visual warnings within the instrument cluster display to warn the driver when a potential frontal collision is detected. The warnings are intended to provide the driver with enough time to react, to avoid or mitigate the potential collision.

FCW monitors the information from the forward looking sensors, as well as the Electronic Stability Control (ESC) system, to calculate the probability of a forward collision. When the system determines that a forward collision is probable, the driver will be provided with the audible and visual warnings.

NOTE:

The FCW feature can be customized and turned off through the Uconnect system touchscreen.

STARTING AND OPERATING

SRT & SCAT PACK VEHICLES

Chassis

- Wheels — due to the high performance nature of the brake system, the wheels will get coated with brake dust. It is recommended that Mopar® Wheel Cleaner be used on your wheels to avoid any possible damage to the finish. However, do not use wheel cleaner if your vehicle is equipped with Dark Vapor or Black Satin Chrome wheels, which must only be cleaned with mild soap, water, and a soft cloth.

NOTE:

Due to the high performance nature of the brakes on your SRT, vehicle dust and some noise are expected and normal.

- Tire Service Kit — your vehicle comes with a tire inflator kit; there is no spare tire included in your vehicle.
- Trailer Tow — trailer towing with your SRT vehicle is not recommended.
- Electronic Stability Control (ESC) - your vehicle is equipped with selectable ESC modes. The ESC mode selected will alter the handling characteristics of your vehicle.
- Adjustable Modes — your vehicle is equipped with selectable driving modes: Default (Street), Sport, Track, Custom, ECO, and Valet. Please refer to the Owner's Manual for further information.
- Three-Season Tires — this vehicle may be equipped with three-season tires to enhance performance. FCA US LLC does not recommend use of these tires when temperatures are below 40°F (4°C) or in snow/ice conditions.

Powertrain & Drivetrain

- Engine & Transmission (SRT Engine Break-In Recommendations) — The following tips will be helpful in obtaining optimum performance and maximum durability for your new SRT Vehicle. Despite modern technology and World Class manufacturing methods, the moving parts of the vehicle must still wear in with each other. This wearing in occurs mainly during the first 500 miles (805 km) and continues through the first oil change interval.

NOTE:

Check engine oil with every refueling and add if necessary. Oil and fuel consumption may be higher through the first oil change interval.

- Engine Oil — 0W-40 Full Synthetic Engine Oil recommended.
- Fuel — Premium Fuel with a minimum octane rating of 91 Pump Octane Number is required.

Automatic Transmission:

- Applying the brake and throttle pedals at the same time (“brake torquing”) for an extended period of time will illuminate the Electronic Throttle Control (ETC) fault light requiring the dealership to clear.
- The vehicle may be equipped with steering wheel mounted “Paddle Shifters” and an M gate console shifter. When in the M gate, the vehicle will not shift at red line and must be manually shifted with either the paddle shifters or the console shifter. In the M gate, the shift light can be programmed to assist the driver with optimal shift points.

Launch Control:

- Your car may be equipped with Launch Control to improve acceleration performance. It is activated by pressing the LAUNCH or Super Track Pack (if equipped) button, located in the instrument panel switch bank, as well as in the radio within “Race Options”, and will help control tire spin for maximum acceleration. The launch RPM is also selectable through the race options screens. Launch Control is not available for the first 500 miles of vehicle life.

Manual Transmission:

- Your vehicle is equipped with a 1-4 skip shift feature to maximize fuel economy. Under certain conditions, the vehicle will require you to shift the transmission from first to fourth gear, instead of from first gear to second gear. Skip Shift is only active while in normal or default driving mode. The detailed conditions of this feature are described in the Owner's Manual.
- Do not attempt to shift the transmission if the rear wheels are spinning due to loss of traction. Damage to the transmission may occur.
- When shifting, fully depress the clutch pedal and lift off the accelerator pedal before shifting gears. Damage to the transmission or clutch may occur if you do not fully depress the clutch pedal and lift off the accelerator pedal when shifting.
- Do not rest your hand on the gear shift knob while driving. This may cause

premature wear of the transmission synchronizers.

- Do not rest your foot on the clutch pedal while driving. This may cause premature wear of the clutch.

Body & Exterior

- Fascias and Ground Effects - This vehicle has a unique exterior appearance, which includes SRT unique fascias and ground effects. These exterior components define the style and appearance of your new vehicle. They also cause a lower approach angle in the front of the vehicle and reduced ground clearance. Due to lower ground clearance, driving your vehicle up steep driveways, approach ramps, or near parking blocks may cause damage to the front fascia and ground effects.
- If your vehicle is equipped with a SATIN FINISH Exterior Body Paint, use products made specifically for satin paint, such as Swissvax Opaque Satin Paint Wax and Dr. Beasley's Satin Paint and Sealant. Refer to the Satin Finish Tips Card.

- Caution should be taken when driving through water or snow more than 4 inches (100 mm) deep to avoid any potential for damage to your vehicle.

Electrical

- Your vehicle may be equipped with a premium "harman/kardon" sound system. Your audio mode can be configured using the radio.
- Your vehicle is equipped with SRT performance pages, Drive Modes, Performance Shift Indication, Launch Control, and Valet Mode, which are displayed in the instrument cluster and the radio.
- Valet Mode is offered on all SRT vehicles. The driver can activate and deactivate Valet Mode with a four-digit PIN they create. Custom PINs are created with each use. If you forget your PIN, disconnect the battery for five minutes to reset.

- Your vehicle may be equipped with a Red key fob, in addition to the Black key fob. The Red key is the only key that can unlock the full horsepower and torque potential of the SRT Hellcat engine, while the Black key fob limits the driver to reduced engine output and reduction of transmission shift schedules. In addition, the Red key fob will unlock all the options within Drive Modes. The Black key fob will limit your options within Drive Modes.
- If equipped with an Automatic Transmission, your vehicle offers an ECO mode. ECO mode will change the feel of the throttle response and shift patterns. Please see the Owner's Manual for further information on configuration that are automatically adjusted.

DEALER SERVICE

ENGINE OIL SELECTION — 5.7L/6.2L/6.4L

NOTE:

Hemi engines (5.7L/6.2L/6.4L) at times can tick right after startup and then quiet down after approximately 30 seconds. This is normal and will not harm the engine. This characteristic can be caused by short drive cycles. For example, if the vehicle is started then shut off after driving a short distance. Upon restarting, you may experience a ticking sound. Other causes could be if the vehicle is unused for an extended period of time, incorrect oil, extended oil changes or extended idling. If the engine continues to tick or if the Malfunction Indicator Light (MIL) comes on, see the nearest authorized dealer.

SIRIUSXM GUARDIAN™ — IF EQUIPPED

ACTIVATION

Activate your account to enjoy advanced safety, security and convenience features.

1. Press the Apps icon on the bottom of your in-vehicle touchscreen.
2. Select the “Activate Services” icon from your list of apps.
3. Select “Customer Care” to speak with a SiriusXM Guardian™ Customer Care agent who will activate services in your vehicle, or select “Enter Email” to activate on the web.

Once you have activated your services, you're only a few steps away from using remote services.



Mobile App

Download the Uconnect mobile app:

- Once downloaded, use your Owner Account login and password to access the app.
- A PIN is required to execute remote services.
- Tap the Location button on the bottom menu bar of the app to locate your vehicle or send a destination to your Uconnect Navigation (if equipped).

- Tap the “Settings” side menu in the upper left corner of the app to bring up app settings and access the Assist Call Centers.

For further information:

- US residents visit: <https://www.driveuconnect.com/sirius-xm-guardian.html>
- Canadian residents visit: <https://www.siriusxm.ca/guardian-v1/>

FEATURES

In-Vehicle

SiriusXM Guardian™ enhances your ownership and driving experience by connecting your vehicle to an operable network. When connected to an operable network, you have access to:

- SOS Call: Connect to a live agent who will contacts emergency services and stay on the line with you until help arrives.

- Customer Care Assistance: Speak with a live agent by pressing the ASSIST button on your rearview mirror to get Roadside Assistance or support.

Remote Services

- Vehicle Finder helps you find where you parked your car.
- Send & Go allows you to send destinations to your navigation system for easy access on the go.
- Remote Door Lock/Unlock lets you unlock or lock your doors from any distance.
- Remote Horn & Lights allows you to sound your horn and flash your lights to easily find your car.
- Receive monthly Vehicle Health Reports, and Alerts whenever a problem is detected under the hood.

Security Services

- Receive stolen vehicle assistance, using GPS technology to help authorities locate your vehicle if it is stolen.

SiriusXM Guardian™ remote services can be used with the Uconnect app from virtually anywhere.

For further information on SiriusXM Guardian™ or the Uconnect mobile App, refer to your Uconnect Owner's Manual Supplement.

VEHICLE FINDER AND SEND & GO

Vehicle Finder

Vehicle Finder allows you to find the location of your vehicle. To find your vehicle:

1. Press the “Location” tab on the Uconnect mobile App bottom bar.
2. Select the “Vehicle” icon to determine the location of your vehicle.
3. Select the “Find Route” button that appears, once your vehicle is located.
4. Select your preferred Navigation app to route a path to your vehicle.

Send & Go

To send an address to your Uconnect Navigation (if equipped) using the Uconnect mobile app:

1. Press the “Location” tab on the bottom bar of the Uconnect mobile app.
2. Type in the destination you would like to navigate to, or search through one of the categories provided.
3. Select the destination you want to send from the list that appears.
4. Press the Send To Vehicle button, and then confirm the destination by pressing “Yes,” to send the destination to the Uconnect Navigation in your vehicle.
5. Finally, confirm the destination inside your vehicle by pressing the “Go Now” option on the pop-up that appears on the touchscreen when the vehicle is started.

AMAZON ALEXA® — IF EQUIPPED

Amazon Alexa® Integration

Alexa® is Amazon's cloud-based voice service and it lets you voice-command your Uconnect system from just about anywhere you Alexa®.

To link your Uconnect system to Amazon Alexa®:

1. Download the Amazon Alexa® app on your iPhone® or Android™ smartphone.
2. Launch the app, then tap MENU, and go to SKILLS.
3. Search for your vehicle. Then tap “ENABLE.”

4. Select LINK ACCOUNT.
5. Log in using your vehicle's Owner Account ID and password.

Examples of commands:

- "Alexa®, ask Dodge Durango how much gas is in my vehicle."
- "Alexa®, ask Jeep Grand Cherokee to send directions to Iron Mountain to my vehicle."
- "Alexa®, ask Chrysler 300 to start my vehicle."

ANDROID AUTO™ AND APPLE CARPLAY® — IF EQUIPPED

ANDROID AUTO™ INTEGRATION



Android Auto™ And LTE Data Coverage

With easy touchscreen navigation and voice recognition, Android Auto™ brings useful information and organizes it into simple cards that appear just when they are needed.


1. Download the Android Auto™ app from the Google Play store on your Android™-powered smartphone.
2. Connect your Android™-powered smartphone to one of the media USB ports in your vehicle. If the Android Auto™ app was not downloaded, it will begin to download when you plug in your device.
3. Once the device is connected and recognized, the "Phone" icon on the personalized menu bar will automatically change to the Android Auto™ icon.

NOTE:

Uconnect screen images are for illustration purposes only and may not reflect exact software for your vehicle.

APPLE CARPLAY® INTEGRATION

Apple CarPlay® is the smarter, safer way to use your iPhone® to get directions with Apple Maps, listen to Apple Music®, make calls and send messages — all through the Uconnect touchscreen or with your voice through Siri.



Apple CarPlay® And LTE Data Coverage

To use Apple CarPlay®, make sure you are using iPhone® 5 or later, have Siri enabled in Settings, ensure your iPhone® is unlocked for the very first connection only, and then follow these steps:

1. Connect your iPhone® to one of the media USB ports in your vehicle.
2. Once the device is connected and recognized, the “Phone” icon on the personalized menu bar will automatically change to the Apple CarPlay® icon.

NOTE:

Long Press: Press and hold the Voice Recognition (VR) button to activate Siri or Google Assistant.

Short Press: Briefly tap the VR button to activate the native Uconnect voice recognition system.

When using Android Auto™ or Apple CarPlay®, be sure to use the manufacturer-provided cable that came with your phone, as aftermarket cables may not work.

NOTE:

Uconnect screen images are for illustration purposes only and may not reflect exact software for your vehicle.

DRIVE DODGE MOBILE APP

NOTE:

The Owner's Mobile App content is applicable to vehicles sold in the US market and are not available from the Canadian App Store® or Google Play Store.

KEY FEATURES

- Owner Information For Your Vehicle
- Accident Assistant
- Online Service Scheduling
- Roadside Assistance
- Maintenance History
- And More

To get this FREE application, go directly to the App Store® or Google Play Store and enter the search keyword “Dodge”.

The DRIVE DODGE Application is the essential app for owners of Dodge brand vehicles. The app puts driver and lifestyle information right in the palm of your hand, anywhere you go. Whether it's providing information about specific product features, taking a tour through your vehicle's equipment, staying up to date on your vehicle's health, knowing what steps to take following an accident, or scheduling your next appointment, we know you'll find the app an important extension of your Dodge vehicle. Simply download the FREE app, select your make and model and enjoy the ride.

FEATURES/BENEFITS

- Available for free on iOS and Android™ smartphones and tablets.
- Select Dodge brand vehicles from model year 2011 to current model year.
- You can also add other Chrysler, Jeep, Ram, FIAT or Alfa Romeo vehicles.*
- Easy access to vehicle information anywhere you go using categories, bookmarks, search and an A-Z index.
- Vehicle information such as operating instructions, maintenance, service history, vehicle controls and emergency procedures.
- Find a dealer or an FCA-certified repair facility.

- Easily document and email an accident report.
- A parking reminder that allows you to drop a pin on your location and navigate back to your vehicle.
- Contact customer care with one click.
- Access to vehicle heritage, parts, accessories, and social media networks.
- Schedule your next service appointment.
- Available in English and Spanish.

*App supports selected vehicles from model year 2011 to present.

To get this FREE application, go directly to the App Store® or Google Play Store and enter the search keyword “Dodge”.



Whether it's providing information about specific product features, taking a tour through your vehicle's heritage, knowing what steps to take following an accident or scheduling your next appointment, we know you'll find the app an important extension of your Dodge brand vehicle.

Simply download the app, select your make and model and enjoy the ride. To get this app, go directly to the App Store® or Google Play® Store and enter the search keyword "Dodge" (U.S. residents only).

U. S.



mopar.com/om

**DOWNLOAD A FREE ELECTRONIC COPY OF THE MOST UP-TO-DATE
OWNER'S MANUAL, UCONNECT AND WARRANTY BOOKLETS**

Canada



owners.mopar.ca

©2020 FCA US LLC. ALL RIGHTS RESERVED. TOUS DROITS RÉSERVÉS.

DODGE IS A REGISTERED TRADEMARK OF FCA US LLC OR FCA CANADA INC., USED UNDER LICENSE. DODGE EST UNE MARQUE DÉPOSÉE DE FCA US LLC OU FCA CANADA INC., UTILISÉE SOUS LE PERMIS.

APP STORE IS A REGISTERED TRADEMARK OF APPLE INC. GOOGLE PLAY STORE IS A REGISTERED TRADEMARK OF GOOGLE.