





Wi-Fi Chime



Power Plug

## Overview

1. Status Indicator
2. Reset Button
3. Power Plug
4. Release Tab
5. Device QR Code



## Status Indicator

|                                                                                  |                              |
|----------------------------------------------------------------------------------|------------------------------|
|  | Device ready                 |
|  | Ready for network connection |
|  | Device malfunction*          |
|  | Network connection failed*   |
|  | Firmware update in progress  |

\*Try resetting the device by holding down the reset button.



### IMPORTANT!

- Ensure you are on a 2.4 GHz Wi-Fi connection.
- Ensure your Video Doorbell and Wi-Fi Chime have the latest firmware version in the device settings.

# Setup


1. Download the **Lorex** app.



2. Attach the plug, and then plug your Chime into an outlet.

**Note:** To remove the power plug, lift up on the release tab.

3. Tap **+** in the app, and then follow the in-app instructions to add the Chime.



## Need help?

For additional support material, scan the QR code or visit [help.lorex.com/ACCHM2](https://help.lorex.com/ACCHM2).

Please see our full Terms of Service and Limited Hardware Warranty Policy at [lorex.com/warranty](https://lorex.com/warranty).



**Copyright © 2023 Lorex Technology Inc.**

As our products are subject to continuous improvement, Lorex reserves the right to modify product design, specifications and prices, without notice and without incurring any obligation. E&OE. All rights reserved.