


USER MANUAL

— MERACH MR-T12 TREADMILL —



Questions or Concerns?

IMPORTANT!

Please read all details before use, and keep this user manual for future reference.
PLEASE CONTACT US BEFORE THE RETURN: Mon-Fri, 9:00 am-5:00 pm PST/PDT
Phone: 1- (877) 3563730 Mon-Fri 8am-5pm(PST)
support@merach.com




**WHO
WE ARE**



Our customers aren't just important; their health, fitness, and pure enjoyment for live is at the core of everything we do at MERACH. From innovative fitness research and cutting-edge product development, to our exceptional purchasing & after-sales service. we are our customers' life-long partner in crafting a better fitness future.

Through quality fat-burning & muscle-building fitness equipment such as our quality rowing machines and exercise bikes, plus our innovative MERACH APP, and diqital courses, we give the opportunity and support to all to pursue their health and fitness goals and discover a new way of healthy living

Welcome to MERACH



Thank You for Your Purchase!

(We hope you love your new treadmill as much as we do.)



JOIN

the MERACH Fitness Community on Facebook
facebook.com/groups/merachfitness



EXPLORE

fitness courses
merachfit.com/blogs/courses



ENJOY

weekly, featured courses
made exclusively by our in-house
fitness instructor



Hey!

**Please register your warranty to
keep yourself protected!**



Email your item model to
register@merach.com



Register your warranty via
merachfit.com/pages/warranty

If purchased outside US/Canada: To register your product warranty, contact your local distributor.

For details regarding product warranty or if you have questions or problems with your product, please contact your local distributor.

Self-Service Customer Support FAQ

1. The outer package was broken, which makes me worried that the product may be damaged.

Please contact us via the after-sales email to ask for FREE return /replacement in time.

2. This was the first time I bought your product, is there a user manual or tutorial video available?

A detailed user manual is included in the package and you can also watch the installation video by scanning the QR code on the packaging.

3. I just received the parcel today, but it doesn't come with accessories.

You'll get twice the price refund of the accessories if the missing accessories don't affect your user experience. Or you can contact us for a refund or free accessories via the after-sales email service.

4. Purchased it six months ago, I want to return it but can't find the return window. What should I do?

Great after-sales service including 12-month exchange or return, support@merach.com, or Amazon live chat.

5. Where can I get your latest product information and related promotions?

Search our products on Amazon or visit our Facebook, Twitter, TikTok, Instagram @merachfit, and also you can send us the product list you're interested in and ask if there is any discount.

FAQ

Contact us by [*support@merach.com*](mailto:support@merach.com)

Contents

Safety Instructions.....	01
Technical Details	03
Packing List	04
Assembly Instructions	05
Instructions on Product Usage	10
Instructions for [MERACH] App Connection and Use	17
Instructions for [KINOMAP] App Connection and Use	18
Warm-up	19
Troubleshooting	20
Maintenance	21
Warranty Information	23
FCC Statement.....	25

This device contains a radio transmitter module with type approval code
FCC ID: 2A6QWMR-BLE001 IC: 29678- MRBLE001 HVIN: MRBLE001



Please read the entire manual carefully
before installing and using the machine,
and save for further use.

Safety Instructions

To ensure your safety and avoid accidents, please read the manual carefully before use and pay attention to the following safety matters.

- The treadmill must be placed on flat ground, the treadmill is suitable for placing indoors, avoiding moisture and not splashing water onto the treadmill. Do not place any foreign objects on the treadmill, both sides of the treadmill and the front end should be 1 meter and the back end should have 6.6*3.3ft of safe use space, so as to facilitate the emergency jump away.
- The power plug must be reliably grounded, and the socket should have a special circuit to avoid sharing with other electrical equipment. If the power cord is damaged, in order to avoid danger, it must be replaced by the manufacturer, its maintenance department, or a similar department's professional staff.
- When not using the treadmill, put the safety lock out of reach of children, if not used for a long time, please disconnect the power cord.
- Accessories package please put in a place where children can not get, to avoid unnecessary accidents.
- This product is not suitable for people with disabilities, or children, such as physical discomfort or mental deficiencies, and lack of common sense is prohibited, except under the supervision or guidance of a person responsible for their safety. If you do not comply, there may be a risk of injury.
- Do not use the treadmill in a dusty space, and keep a certain humidity in the room to avoid strong static electricity, so as not to interfere with the normal work of the electronic meter and controller.
- Please use the original accessories, private replacement is strictly prohibited.
- Avoid all moving parts with both hands, forbid putting hands and feet in the gap under the running belt.
- Do not put the power cord close to hot or moving objects; do not use the product outdoors, under high humidity and sunlight.
- Unplug the treadmill before moving it. Non-professional personnel must not disassemble the machine without permission, otherwise, serious consequences may occur.
- Please clip the safety lock cable puller on your clothes when you exercise to prevent safety stops when you encounter an emergency.
- Before using the treadmill, please check whether the clothing is buttoned or zipped up, or the clothes are too loose.
- This product should not be used for a long time, long time use is easy to cause the treadmill electrical overheating and lead to electrical failure.

Safety Instructions

- Use qualified sockets to avoid bringing danger. If the plug and socket are not compatible, please do not move the plug, ask a professional to handle it.
- The product is suitable for home use, not suitable for professional training and testing, and can not be used for medical purposes.
- Do not use in the shell cracked, broken off state (internal structure exposed) or welding parts cracked state.
- Do not jump up or down on the machine during exercise, which may lead to injury due to a fall.
- Do not use after eating and drinking, fatigue, or poor physical condition, which may lead to damage to health.
- The product's maximum load is 300lbs.


Care & Maintenance

- Do not store the machine in a place exposed to direct sunlight, wind and rain, or with high humidity. If needed, please pack the machine to keep children away from touching or playing with it.
- Please check if there's rust or cracks after long-term storage.
- Please understand that for the consumable parts, the wear and tear may also occur even with proper maintenance.
- For long-term use of this machine, please wipe the dust regularly. Do not water it directly, or wipe it with gasoline, abrasive powder, etc. Otherwise, it might cause cracks on the parts or main body, electric shock or fire. Please use dilute neutral detergent for maintenance.



Before starting any training, please consult your physician, especially for those who are over 35 years old or with pre-existing health conditions. Please read all instructions before using the machine.












Technical Details



Product Name:	Merach Treadmill
Model:	MR-T12
Voltage:	120V~ 60Hz
Maximum horsepower:	2.5HP
Running area:	42.5*16.5inch
Speed range:	0.5-7.5mph
Max load weight:	300lbs
Net weight:	105.8lbs
Product size:	53.5*27.6*49.2inch

Packing List

Check if all parts and accessories are in the package.

 #1 Main Frame*1	 #68 Flat Washer $\Phi 8 \times 2$ #69 Spring Washer $\Phi 8 \times 6$ #55 Hexagon Flat Round Head Screws $M8 \times 45 \times 2$	
 #78 Arc Washer $\Phi 8 \times 4$ #69 Spring Washer $\Phi 8 \times 6$ #53 Hexagon Flat Round Head Screws $M8 \times 16 \times 4$	 #23 Right Bottom Cover *1	
 #24 Left Bottom Cover *1	 #45 Safety Lock *1	
 #60 Cross Slot Head Self-tapping Screws $ST4.2 \times 19 \times 2$	 #48 Lubricating Oil *1	 #74 5mm Internal Hexagon Wrench*1 #75 6mm Internal Hexagon Wrench*1
 #76 Cross Wrench *1	 Power Cord *1	 User Manual *1

Assembly Instructions

Put all the parts in the empty area and remove the packaging materials, do not discard the packaging materials before finishing the assembly.




Tips

Scan QR code to watch installation video

Step 1:

Open the packaging box, remove the components listed above, and place the Main Frame(1) flat on the ground.




Assembly Instructions


Step 2:

A. As show in the figure, Push up the Monitor and Column Tube (3&4).

B. Put the Hexagon Flat Round Head Screws(55) on the Spring Washer (69) and the Flat Washer (68) through the base hole and the left column hole, and use the Hexagon Socket Head Screws(74) to lock it.



C. Put the Hexagon Flat Round Head Screws(53) on the Spring Washer (69) and the Arc Washer (78) through the base hole and the left column hole, and lock it with the Internal Hexagon Wrench (74).




D. Installation on the right side is the same as on the left side. After the screws on both sides of the left and right columns are completely locked, tighten the left and right screws uniformly.

Assembly Instructions

Step 3:

1. Using the Hexagon Flat Round Head Screws (53) to put on the Spring Washer (69) and the Arc Washer (78), use the Internal Hexagon Wrench(74) to lock the electronic watch on the column.
2. The assembly method on the left is the same as on the right.
3. After all the left and right bolts are locked, tighten the left and right screws uniformly.




Assembly Instructions

Step 4:

A. Connect the Cross Slot Head Self-tapping Screws (60) through the Right Bottom Cover (23), the column tube screw hole and the base screw hole in sequence, and fix it with the Cross Wrench (76).


B The assembly method of the Left Bottom Cover (24) is the same as the right one.



Assembly Instructions

Step 5:



- A. Rotate the display about 65° clockwise.
- B. Insert the Safety Lock (45) into the safety lock hole.
- C. Connect the Power Cord (46) to the power source.



Note:

- Ensure that all the installation steps mentioned above are completed as specified before uniformly tightening all the bolts. Only after confirming that nothing has been overlooked should you proceed to connect the power.
- For instructions on using the treadmill, please carefully review the relevant information provided in the following sections.

Instructions on Product Usage



A. Window and Button Descriptions

1. Display Window Descriptions:

-  Displays the speed value.
-  Displays the incline value.
-  Displays the distance value.
-  Displays the calorie value.
-  Displays the heart rate value.

These values alternate every 5 seconds, accompanied by the corresponding LED indicator light.

2. Function Buttons:

PROG, START, STOP, MODE, INCLINE increase and decrease buttons, INCLINE shortcuts (3, 6, 9), SPEED increase and decrease buttons, SPEED shortcuts (1, 3, 5).

Instructions on Product Usage

3. Function Button Descriptions:

"PROG." Button:

Program selection buttons. The order of selection is: Manual Mode, P01-P15 automatic program, FAT.

"START" Button:

Start button. Pressing this button initiates a 3-second countdown, after which the treadmill starts running at the lowest speed or the default program speed.

"STOP" Button:

Start button. When exercising, pressing this button gradually reduces the treadmill's speed to a stop while maintaining all counts.

While paused, pressing the stop button again returns the treadmill to standby mode.

"MODE" Button:

Mode selection button. The order of selection is: Manual Mode, Time Countdown, Distance Countdown, Calorie Countdown.

1. When the electronic watch is in standby mode, press this button to enter the countdown mode setting; the selection sequence is: manual mode, time countdown, distance countdown, and calorie countdown cycle.

2. In the body fat test setting state, select the keys for the fat measurement parameters: the selection order is: "Gender", "Age", "Height", "Weight".

"SPEED +/-" Button:

Speed value adjustment button.

1. When the electronic watch is running, the running speed value can be adjusted.

2. In the parameter setting state, the size of the set parameter value can be adjusted. (1,3,5) —Speed shortcut button.

"INCLINE +/-" Button:

Incline value adjustment button.

Instructions:

1. When the electronic watch is running, the Incline value can be adjusted.

2. In the parameter setting state, the size of the set parameter value can be adjusted. (3,6,9) —Incline shortcut button.

Right Handrail Button:

Speed + or - shortcut button.

Left Handrail Button:

Incline + or - shortcut button.

Note: When any button is pressed and is valid, there will be a prompt sound. When the parameter adjustment exceeds the limit, there will be a long beep prompt. There will be no beep when the button is pressed ineffectively.

Instructions on Product Usage

B. Startup Instructions:

1. Place the safety lock in the safety lock switch position on the panel.
2. Plug the power cord into the front socket of the treadmill, turn on the power, and switch on the power switch at the front of the machine. The treadmill enters standby.
3. Control the treadmill using the control panel.

C. Mode Settings:

1. Manual Mode:

- Attach the safety lock, press the START button, and after a 3-second countdown, the treadmill will start running from the lowest speed.
- Adjust the speed using the SPEED +/- buttons.
- Adjust the incline using the INCLINE +/- buttons.
- To stop, press the STOP button or simply disconnect the safety lock.

Note: The initial running speed is 0.5 mph.

2. Countdown Mode:

In standby mode, press the MODE button to select the time countdown, distance countdown, and calorie countdown in order. Use the SPEED +/- buttons and INCLINE +/- buttons to reach the desired value. Press the START button to enter countdown mode.

Note: When the set time reaches zero, the machine will gradually stop running.

Instructions on Product Usage

D. Program Mode:

1. Automatic Program: In the initial standby state or mode setting state, press the program button to enter the automatic program. P01-P15 programs are available. At this point, the time window will display 30:00 minutes and blink (you can set the desired exercise time using the SPEED +/- buttons and INCLINE +/- buttons within the range of 5:00 to 99:00 minutes). Press the START button to enter the automatic program mode.

Divide the designated time by 20 time intervals to obtain the runtime for the upper and lower time intervals																					
program	time	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
P01	SPEED(mph)	2	3	3	4	5	3	4	5	5	3	4	5	4	4	4	2	3	3	5	3
	INCLINE(%)	1	1	2	2	2	3	3	3	2	2	1	2	2	1	1	3	3	2	2	2
P02	SPEED(mph)	2	4	4	5	6	4	6	6	6	4	5	6	4	4	4	2	2	5	4	2
	INCLINE(%)	1	2	2	2	2	3	3	2	2	2	2	2	3	3	3	4	4	3	2	2
P03	SPEED(mph)	2	4	4	6	6	4	5	6	5	4	3	3	4	4	4	2	4	5	3	2
	INCLINE(%)	2	3	3	2	2	3	3	3	2	2	2	2	4	4	4	6	6	3	2	2
P04	SPEED(mph)	3	5	5	6	5	4	5	3	3	2	4	5	6	5	5	6	6	4	4	3
	INCLINE(%)	2	3	3	2	2	3	3	3	2	2	2	2	4	4	4	6	6	3	2	2
P05	SPEED(mph)	2	4	4	5	6	5	6	5	6	4	3	2	5	4	3	3	6	5	4	2
	INCLINE(%)	3	3	3	4	4	5	5	5	4	4	4	4	5	5	3	3	3	2	2	2
P06	SPEED(mph)	2	4	4	4	5	6	3	4	6	3	2	3	6	4	4	2	5	4	3	2
	INCLINE(%)	3	5	5	5	4	4	4	3	3	3	3	4	4	4	3	3	3	4	3	2
P07	SPEED(mph)	2	3	3	3	4	5	3	4	5	3	4	5	3	3	3	6	6	5	3	3
	INCLINE(%)	4	4	4	4	3	3	6	6	6	7	7	8	8	9	9	6	6	5	4	4
P08	SPEED(mph)	2	3	3	6	5	4	4	6	2	4	6	5	4	4	4	2	3	4	4	2
	INCLINE(%)	4	5	5	5	6	6	6	7	8	9	9	9	10	10	10	12	12	8	6	3
P09	SPEED(mph)	2	4	4	3	5	4	3	2	4	5	6	6	4	4	4	5	6	3	3	2
	INCLINE(%)	5	5	5	6	6	6	4	4	6	6	5	5	8	8	9	9	9	7	4	2
P10	SPEED(mph)	2	4	5	6	3	5	4	6	3	3	6	6	5	4	4	2	4	4	3	3
	INCLINE(%)	5	6	6	6	7	5	8	8	4	4	4	5	5	8	8	10	10	8	6	3
P11	SPEED(mph)	2	5	4	3	4	5	6	6	4	5	6	6	5	5	6	3	5	5	4	3
	INCLINE(%)	4	5	3	2	6	6	2	2	2	2	2	4	5	6	3	2	5	5	2	0
P12	SPEED(mph)	3	4	5	6	5	4	5	2	5	6	4	5	5	3	6	5	5	2	6	3
	INCLINE(%)	1	2	3	2	3	5	5	0	0	2	3	5	7	3	3	5	6	5	3	3
P13	SPEED(mph)	3	6	2	5	5	6	6	5	5	3	3	5	2	5	6	5	6	5	4	3
	INCLINE(%)	3	3	5	6	5	3	3	7	5	3	2	0	0	5	5	3	2	3	2	1
P14	SPEED(mph)	2	2	4	5	6	5	4	3	2	1	2	3	4	5	6	5	4	3	2	1
	INCLINE(%)	4	4	4	4	3	3	6	6	6	7	7	8	8	9	9	6	6	5	4	4
P15	SPEED(mph)	2	4	6	3	6	6	4	4	2	2	2	4	6	5	6	6	4	4	2	2
	INCLINE(%)	3	3	3	4	4	5	5	5	4	4	4	4	5	5	3	3	3	2	2	2

Instructions on Product Usage

E. Body Fat Test Mode:

Body Mass Index (FAT) measures the relationship between a person's height and weight, not body proportions. FAT is suitable for both men and women and, along with other health indicators, provides a basis for adjusting one's weight.

Entering Body Fat Test Mode:

1. In the treadmill's standby or mode setting state, press the program button. When the window displays 'FAT,' it indicates entry into the body fat test mode.
2. Press the "MODE" Button to select a parameter category ("Name", "Age", "Height", "Weight"). "F-1", "F-2-", "F-3-", "F-4" are displayed in the corresponding window.
3. Use the SPEED +/- button or INCLINE +/- button to adjust the set value.

Parameter Settings and Ranges:

Gender (F-1) Setting	Initial value 1 (Range 1-2, 1 represents male; 2 represents female).
Age (F-2) Setting	Initial value 25 (Range 10-99 years).
Height (F-3) Setting	Initial value 67 (Range 40~95inch).
Weight (F-4) Setting	Initial value 154 (Range 44-352lbs).

4. Press the "MODE" button again to start the measurement.
5. After completing the settings, enter the body fat test. Initially, it will display '—.' At this point, hold both hands on the heart rate test plate for about 5 seconds, and the body fat test index will be displayed. The range for the body fat index is as shown in the chart below.

Body fat index (BMI)	Obesity level
FAT<19	Thin
19<FAT≤26	Normal
26<FAT≤30	Overweight
>30	Obese

Special Note: This data is for reference in your fitness routine and is not intended as medical data.

Instructions on Product Usage

F. Safety Lock Function:

1. At any time when the safety lock is pulled off, the electronic display LED window will show '---', accompanied by a buzzer alert. If the safety lock is removed while the treadmill is in operation, the treadmill will quickly stop running, and all data will reset to zero.
2. Each time the safety lock is properly placed, the screen will fully illuminate and then enter the system's default working state. All counters will reset, set values will return to default, and the treadmill will be in manual program mode with positive timing.

G. Heart Rate Function:

With the treadmill powered on, place the palms of both hands on the steel plates located on the left and right handrails. After about 5 seconds, the LED heart rate display window will show the initial heart rate value. Please keep your hands still, and the heart rate display window will gradually update with data, approaching the current actual heart rate value after approximately 60 seconds.

Note: Heart rate test data is provided for exercise reference and should not be considered medical data.

H. Display and Setting Range of Exercise Parameters (as shown in the chart below):

When setting a specific parameter, use the speed increase and decrease buttons to make adjustments, and you can cycle through the settings.

Setting parameters	Display range	Set range	Initial values
Speed(mph)	0.5-7.5	0.5-7.5	/
Incline(%)	0-15	0-15	0
Time(min:sec)	0:00-99:59	5:00-99:00	30:00
Distance(ml)	0:00-99:9	0.5-99.9	1.0
Calories(kcal)	0-999.9	10-990	50
Heart rate(bpm)	60-200	/	/

I. Sleep Function Explanation:

When the treadmill is not in operation for more than 10 minutes, it enters sleep mode, and the electronic display automatically turns off. Press any key to wake up the electronic display, and it will fully illuminate before returning to the initial standby state.

J. Shutdown:


Turn off the treadmill by using the power switch.

Instructions on Product Usage

K. Treadmill Folding and Storage:


As shown in the diagram, grasp the handrails with your left hand and support position A with your right hand to lift the treadmill upwards. Apply force to lift it until you hear the safety tread at point B make a sound.

Note: While lifting the treadmill, ensure a firm grip on the handrails to prevent the frame from moving forward.



L. Treadmill Movement:


If you need to move the treadmill, as illustrated in the diagram, grip point A with both hands and push it downward. Move it forward or backward following the arrow direction.



M. Unfolding the Treadmill:

Once the treadmill is securely in place, grasp the handrails with your left hand and support position A with your right hand to slightly lift the treadmill upwards. Use your foot to kick the safety tread at point B while simultaneously pulling down the main frame with your right hand, allowing the frame to descend slowly.

Note: During the descent of the treadmill, ensure that people and pets are away from the machine to prevent any potential injuries.



Instructions for [MERACH] App Connection and Use

Download and use of MERACH

- * Our customer can get a 180-day MERACH membership. Please contact us through support@merach.com after receiving the product to get an exclusive redemption code. Please include your order ID and MERACH app Username.

1. Please scan the QR code down below to download the MERACH APP and get the APP connection guide.



MERACH APP Download



APP Connection Guide



2. Log in/create an account (click to log in if you already have an account); If you do not have an account, please click ""Sign Up"" below.
3. Select the corresponding fitness equipment.
4. Update the app to the latest version.

In the near future, we will upgrade the app function, adding free exercises mode, courses and various training modes to the app. If you receive an upgrade notification when connecting, please upgrade the app to the latest version.

Instructions for [KINOMAP] App Connection and Use

Download and use of KINOMAP



1. To download the Kinomap app, scan the QR code or search "Kinomap" in the Apple App Store® or Google Play Store.
2. Open the Kinomap app. Log In or Sign Up.
3. Select the corresponding fitness equipment.
4. Turn on Bluetooth, and choose MERACH.
5. Select "Treadmill", and find your "MRK-T12S-XXXX".
6. Start training and explore different workout methods.

Warm-up

Do stretches before exercising. Warm muscles are easier to stretch, so start with a 5-10 minute warm-up, then do some stretches shown below - 5 times, 10 seconds or more per leg. Do it again after the workout.

1. Stretch down

Bend your knees slightly, slowly bend your body forward, relax your back and shoulders, and try to touch your toes with your hands. Hold for 10-15 seconds, then relax. Repeat 3 times (see Figure 1).




2. Seated hamstring stretch

Sit with one leg straight. Bring the other leg in so that it is snug on the inside of the straightened leg. Try to touch your feet with your hand's toe. Hold for 10-15 seconds, then relax. Repeat 3 times for each leg (see Figure 2).




3. Calf and Achilles tendon stretch

Stand with both hands against the wall or a tree, put one foot behind another. Keep the back leg straight and your heel on the ground, lean toward a wall or a tree. Hold for 10-15 seconds, then relax. Repeat 3 times for each leg (see Figure 3).




4. Quadriceps stretch

Reach back with your right hand, grab your right foot and slowly pull it toward your hips until you feel the muscles in the front of your thigh tense. Hold for 10-15 seconds, then relax. Repeat 3 times for each leg (see Figure 4).



5. Sartorius (inner thigh muscle) stretch

Sit with your feet facing each other and your knees facing out. Grab your feet with both hands and pull toward your groin. Hold for 10-15 seconds, then relax. Repeat 3 times (see Figure 5).



Troubleshooting

Fault Code	Troubleshooting
E01--Electronic Panel Communication Failure	1.Check the communication line between the electronic panel and the motor controller for integrity and reliability 2.If the error persists, check if the motor connections are normal. Please contact customer support or a professional technician for assistance.
E02--Voltage Abnormality	1.Check if the voltage is within the operating range. 2.Power off and restart. 3.If the error persists, check if the motor connections are normal. Please contact customer support or a professional technician for assistance.
E03--Sensor Signal Abnormality	1.Check if the sensor is inserted correctly or if the magnetic sensor is damaged. 2.If the error persists, check if the motor connections are normal. Please contact customer support or a professional technician for assistance.
E05--Over Current Protection	1.Check if the current is within the operating range. 2.Power off and restart. 3.If the error persists, consider replacing the controller. Please contact customer support or a professional technician for assistance.
E06--Controller Internal Self-Test Error	1.Check whether the power wiring connects normally. 2.If the error persists, consider replacing the controller. Please contact customer support or a professional technician for assistance.
E07--Data Abnormality	The controller is operating abnormally. If the error persists, consider replacing the controller. Please contact customer support or a professional technician for assistance.
E08--EEPROM Damage	The controller is operating abnormally. If the error persists, consider replacing the controller. Please contact customer support or a professional technician for assistance.

Maintenance

Maintenance Guide

WARNING: Always unplug the motorized treadmill before cleaning or maintaining the product.

CLEANING: A thorough cleaning will extend the life of your motorized treadmill.

Remove dust regularly to keep parts clean. Be sure to sweep the exposed portions of both sides of the treadmill belt, as this will minimize the buildup of impurities under the belt.

Make sure your sneakers are clean to avoid carrying foreign objects under the running belt that could wear down the running board and running belt. The surface of the running belt should be cleaned with a soapy damp cloth, please be careful not to splash water on the electrical components and under the running belt.

Special lubricant for running belt and motorized treadmill

This motorized treadmill is pre-lubricated between the running board and the running belt. The friction between the running belt and the running board has a significant impact on the life and performance of the motorized treadmill, so regular lubrication is required. We recommend regular inspection of the plate. If there is any damage to the treadmill surface, please contact our customer service center.

We recommend applying lubricant between the running belt and the running board of the motorized treadmill according to the following schedule: (Usage is shown below)


Light-weight users (less than 3 hours per week) Once a year;

Medium-weight users (3-5 hours per week) Once every 6 months;

Heavy duty users (more than 5 hours per week) every 3 months.

When the lubricant has been used up, we recommend that you purchase the lubricant from your local dealer or contact us directly.

Note: Any other maintenance needs to be done by a specialist.




Running belt adjustment

1. To better maintain your motorized treadmill and prolong the life of the machine, it is recommended that you turn off the power after 1.5 hours of continuous use and let the machine rest for 10 minutes before using it again.
2. If the running belt is too loose, there will be slipping phenomenon when running; if it is too tight, over-tightening may reduce the performance of the motor and increase the wear and tear of the roller and running belt. When the running belt is suitable for loosening or tightening, you can lift both sides of the running belt away from the running board by hand about 50 - 75mm.


Treadmill belt centering

1. Place the motorized treadmill on a level surface. Run the motorized treadmill at about 6-7MPH and observe the running belt deviation.


2. If the running belt is to the right, unplug the safety lock and power switch, turn the right adjusting bolt 1/4 turn in clockwise direction, insert the power switch and safety lock, run the treadmill and observe the running belt deviation. Repeat the above steps until the running belt is centered. Figure A.



3. If the running belt is off to the left, unplug the safety lock and power switch, turn the left adjusting bolt 1/4 turn clockwise, insert the power switch and safety lock, run the treadmill, and observe the running belt deviation. Repeat the above steps until the running belt is centered. Figure B.



4. The treadmill belt will loosen after the above adjustments or after a period of use, and needs to be adjusted. Unplug the safety lock and power switch, turn the left and right adjusting bolts 1/4 turn clockwise, plug in the power switch and safety lock, run the treadmill, and then stand on the running belt to check the tightness. Repeat the above steps until the running belt is at the right level of tightness. Figure C.



Warranty Information

Product Name	MERACH Treadmill
Model	MR-T12
Default Warranty Period	12 Months
For your own reference, we strongly recommend that you record your order number and date of purchase.	
Date of Purchase	
Serial Number	

Terms & Policy

The MERACH products are premium in material, craftsmanship, and service. MERACH 1-year limited warranty is effective from the date of purchase.

MERACH will replace defective products based on eligibility. Refunds are available to the original purchasers of our products within the first 30 days of purchase. This warranty extends only to personal use, doesn't apply to the commercial, rental, or any other uses for which the product is not intended for. There are no warranties other than the warranties expressly set forth with each product.

This warranty is non-transferable. MERACH is not responsible for any damages, losses or inconveniences caused by equipment's failure, user's negligence, user's abuse, or improper operation that does not follow the included user manual.

This warranty does not apply to the following situations:

- Damage due to abuse, accident, alteration or vandalism.
- Improper or inadequate maintenance.
- Damage in return transit.
- Unsupervised use by children under 18 years old.

MERACH and its subsidiaries are only responsible for damages caused by the intended use or as instructed in the user manual. Some states do not allow this exclusion or limitation of incidental or consequential losses, so the above disclaimer may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which may vary from state to state.

All expressed and implied warranties, including the warranty of merchantability, are limited to the period of the limited warranty.

Warranty Information

Additional 12-month Warranty:

You can enjoy an additional 12-month warranty. Just activate your warranty by sending the product's model name via **register@merach.com**, or log onto **merachfit.com/pages/warranty** and enter your order number (i.e. Amazon) within the first 14 days of purchase to register your new product for the extended warranty. If you are unable to provide the order number for your product, please type a short note in the order number field along with the date you received your product.

Defective Products & Returns:

Should your product prove defective within the specified warranty period, please contact the Customer Support via **support@merach.com** with your invoice and order number. **DO NOT** dispose of your product before contacting us. Once our Customer Support team has approved your request, please return the product with a copy of your invoice and order number.

Customer Support

Your satisfaction is our goal! Should you encounter any issues or have any questions about your new product, feel free to contact our Customer Support Team via **support@merach.com** or **Phone Support**:

 **1- (877) 3563730 Mon-Fri 8am-5pm(PST)**

TikTok Shop Exclusive after-sales: **service@merach.com**

*** Please have your Order ID and serial number ready before contacting Customer Support.**

FCC Statement

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

MERACH



@merachfit



@Merachfit



@Merachfit



@Merachfit



merachfit.com



@merach.us

Phone Support: 1- (877) 3563730 Mon-Fri 8am-5pm(PST)
Customer Service: support@merach.com
Official Website: merachfit.com