

OUTLAND LIVING®


AUROS STRING LIGHT WITH SPEAKERS

OUTDOOR LIVING PERFECTED®

Length (Approx.):

STRING LIGHT: 5 m / 16.4 ft

POWER CORD: 3 m / 9.8 ft



**Thank you for choosing our
Auros String Light!**

*Please read this manual carefully to
ensure optimal use, safety, and
maintenance of your string light.*

® is a registered trademark of FMI Brands Inc. The OUTLAND flame is a registered trademark of FMI Brands Inc.



FMI BRANDS INC.


101 - 3570 194 Street, Surrey, BC, Canada V3Z 1A5

Toll Free: 1-888-514-1663 | Email: info@outlandliving.com

Hours of Operation 8:30AM - 4:00PM (Pacific Time)

D:180.000.V0

PRODUCT FEATURES



PRODUCT SPECIFICATIONS

Total Rated Power: 8.8W

Light Bulb: LED E26 DC12V 0.35W (X8)

Power Supply: 24W | 12V DC

Color Temperature: 2700K

Luminous Flux: 38lm / bulb

Working Temperature: 0°C -45°C

Storage Temperature: -20°C-60°C

Working Humidity: ≤95%

IP Rating: IPX4

String Light Length: 5 m


Power Cord Length: 3 m

USER INSTRUCTIONS

USING THE STRING LIGHT

STEP 1

Align the male connector (with 2 pins) on the string light and the female connector on the power cable.




USER INSTRUCTIONS (continued)

WARNING:


Always inspect cables and lights for damage before use and do not use them if any damage is found.

Fasten the connectors by inserting them together, securing the connection with the screw cap on the male connector side. Make sure the screw cap is fully tightened.




STEP 2

Plug the power adapter into a 120V AC wall outlet.



STEP 3

Locate the ON/OFF switch along the power cable and turn it to the ON position.



STEP 4

Enjoy your AUROS String Light!

TIPS: When power is no longer required, the switch can be shut off without needing to unplug the power adapter from the wall.

USER INSTRUCTIONS (continued)

CAUTION:

Do not use with an electrical dimming switch as this can cause unwanted behavior in the lights and/or speaker.

CAUTION:

Only use the provided power adapter, do not attempt to use any other adapter, charging device, or connector.

CAUTION:

Make sure the screw-on cap of the female connector located at the end of the string light is fully tightened.

USING THE SPEAKERS

STEP 1

When the power is on, the speakers will automatically show up in pairing mode as **"OUTLAND LIVING AUROS SYNC"**.

STEP 2

To connect, open a Bluetooth capable audio device and follow the device instructions to connect to the speakers.

STEP 3

Once connected, you will hear the connection sound and are now ready to play audio.

STEP 4

Control music volume and playback functions using your Bluetooth capable audio device.

STEP 5

If additional AUROS String Light (sold separately) is connected, the second set of speakers will connect and synchronize automatically.


NOTE:

The Auros speakers can get very loud, especially in an indoor environment. Enjoy responsibly!

USER INSTRUCTIONS (continued)


CONNECTING ADDITIONAL AUROS STRING LIGHT (SOLD SEPARATELY)

You can connect up to two sets of AUROS String Lights together for even greater sound and light coverage.




STEP 1

Turn off the string light using the ON/OFF switch then unplug the power adapter.



STEP 2

Remove the screw-on cap of the female connector at the end of the first string light.




USER INSTRUCTIONS (continued)

CONNECTING ADDITIONAL AUROS STRING LIGHT (continued)


STEP 3

Align the male connector (with 2 pins) on the second string light and the female connector on first string light.




Connect the connectors by inserting them together, secure the connection with the screw cap on the male connector side.

Make sure the screw cap is fully tightened.




STEP 4

Plug the power adapter into a 120V AC wall outlet.



STEP 5

Turn on the string light using the ON/OFF switch.



STEP 6

Enjoy your AUROS String Light!



USER INSTRUCTIONS (continued)

WARNING:

- Do not attempt to connect more than two AUROS String Lights. This may overload the power adapter and cause overheating, permanent damage to the appliance, or even fire.
- Only use the provided power adapter, do not attempt to use any other adapter, charging device, or connector.

WARNING:

- Do not let wires sit in pooling water. The lights are designed for protection from splashing water and light rain only.
- Do not operate above working temperature.
- Do not submerge lights under water.
- Adult supervision required under the age of 12.

CAUTION:

Do not stare directly into the lights as it could cause damage to the eyes.

STORAGE AND MAINTENANCE

- Store indoors when not in use to maximize lifespan.
- Always store away from pooling water or wet conditions.
- To clean, wipe down with a clean microfiber cloth. The bulbs and speakers can be removed by screwing in a counterclockwise direction. Do not clean by submerging underwater or using harsh chemicals as this could damage the lights.

- Regularly inspect the bulbs, sockets, and wiring for damage.

WARNING:

Immediately stop using the appliance if any damage is found.

TROUBLESHOOTING

LIGHT(S) NOT ILLUMINATING

- **Inspect for damage** – With the appliance unplugged, check the entire length of the wiring for any cuts, frays, or damage.



WARNING:

Immediately stop using the appliance if ANY damage to the wiring is found.

- **Check the bulbs** – Ensure all bulbs are undamaged and fully screwed into the sockets. If a bulb is damaged, see Bulb Replacement.
- **Check the power** – Ensure power adapter is plugged into a working outlet that has power. Test the outlet with another appliance to ensure the outlet has power.
- **Reset the GFCI outlet (if applicable)** – If using in an outdoor GFCI outlet, ensure it has not been previously triggered. To reset, unplug all devices from the outlet and press the reset button on the electrical outlet.
- **Check connections** – Ensure that the connection from the power adapter to the lights is secure and tight.

LIGHTS FLICKERING

- **Notice:** This appliance is not designed for use with an electrical dimmer switch. Doing so may affect the lighting quality, including flickering.
- **Check the bulbs** – Ensure all bulbs are fully screwed into the sockets.
- **Check the power** – Ensure that the power adapter is securely plugged into a wall outlet. If the outlet appears loose or unable to secure the power adapter in place, use a different power outlet.
- **Check connections** – Ensure that the connection from the power adapter to the lights is secure and tight.

SPEAKER NOT CONNECTING TO DEVICE

- **Turn Bluetooth On & Off** – Restart Bluetooth on your device and try again.
- **Restart Both Devices** – Power off and restart both the speaker and your phone/tablet.
- **Forget & Re-pair** – In Bluetooth settings, forget the speaker and reconnect it.
- **Check for Interference** – Move away from Wi-Fi routers, other Bluetooth devices, or metal objects that may cause signal issues.

TROUBLESHOOTING (continued)

SPEAKER CONNECTED WITH NO SOUND

- **Check Volume** – Make sure your device is not muted and the volume is turned up.
- **Select Correct Output** – In Bluetooth settings on your device, ensure the speaker is selected as the audio output.
- **Restart Media App** – Close and reopen the app playing audio on your device. Try another app to see if the issue persists.
- **Check for Multiple Connections** – Ensure other users previously connected to the speakers have fully disconnected their devices.

SPEAKER KEEPS DISCONNECTING


- **Stay in Range** – Keep your device within 30 feet of the speaker for a stable connection.
- **Reduce Interference** – Move away from devices that may disrupt Bluetooth signals, such as Wi-Fi routers, other Bluetooth devices, or large metal/stone/concrete objects.

SPARE PARTS


Spare bulbs and power cables can be sourced directly from FMI Brands Inc., please contact us for more information.

BULB REPLACEMENT

- Before replacing the bulbs, ensure that the power adapter is unplugged from the wall.
- Locate the damaged bulb and carefully unscrew it from the socket in a counterclockwise direction, taking care and wearing gloves if necessary.



- Install the new bulb into the socket by screwing in a clockwise direction. Do not overtighten as it may damage the light bulb or the socket.



- Plug the power adapter in, connect the power cable, and turn the switch on to test the new bulb. If it is not working, disconnect the power and ensure it has been seated fully and is tightly screwed in.

CAUTION:

Only use 12V 0.35W E26 light bulbs with the AUROS String Light. Using light bulbs with the wrong socket, voltage, and power rating may cause permanent damage to the appliance and risk fire or injury.

TROUBLESHOOTING (continued)

WARNING:

Do not install the light bulbs or speaker units of the AUROS String Light into regular 120V AC household light sockets or any other light sockets. This can cause permanent damage to the unit and poses a risk of fire and/or electric shock.

SAFETY WARNING NOTES

- Do not let wires sit in pooling water or submerge any part of the appliance.
- Do not operate above working temperature.
- This is not a toy, adult supervision required at all times when using this appliance.
- Do not use the appliance if any damage to the wiring, bulbs, or sockets is found.
- Do not stare directly into the lights as it could cause damage to the eyes.

COMPLIANCE NOTES

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



COMPLIANCE NOTES (continued)

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

ISED Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

FCC ID: 2BGBC-S14-YXDC-01
IC: 33605-S14YXDC06



OUTLAND LIVING®

1 YEAR LIMITED WARRANTY **Customers in Canada and USA**

All components are warranted by the manufacturer for a period of 1 year after date of purchase by the original owner against defects in materials and workmanship under normal use. This warranty does NOT cover normal wear and weathering, assembly and/or maintenance OR use in a commercial application. At FMI Brands' sole discretion, products under warranty will be repaired and/or replaced at no charge to the customer. Any returns sent back to FMI Brands must be sent via prepaid freight and in the original retail packaging.

Please register your OUTLAND Living product for proof of purchase and warranty at
<https://outlandliving.com/register-products>

For more warranty information and details please contact FMI Brands Inc. at
info@outlandliving.com

FOR REPLACEMENT PARTS AND ACCESSORIES PLEASE VISIT **WWW.OUTLANDLIVING.COM**

The owner's manual is available as a free download from www.outlandliving.com.
Should you have any questions or comments regarding this appliance,
please do not hesitate to contact FMI Brands Inc. at (888) 514-1663 or
E-Mail to info@outlandliving.com

www.outlandliving.com