

MODEL
Food Check

ORDER CODE
221-048

SPECIFICATIONS

Range	-58 to 572°F (-50 to 300°C)
Resolution	0.1°F or °C
Accuracy	±0.7°F (±0.4°C) from -58 to 390°F (-50 to 199°C) ±1.8°F (±1.0°C), from 392 to 572 °F (200 to 300°C)
Battery	3 x 1.5V AAA, minimum 5 years (10,000 hours)
Auto-Off	After 10 min. to save battery life
Sensor	Type K thermocouple, fixed
Probe	5 L x 0.125 dia. inches (127 L x 3.2 dia. mm), 39 L inches (1 L m) cable
Display	1 H x 1.5 W inches (24 H x 38 W mm) LCD
Dimensions	5 H x 2.2 W x 1 D inches (128 H x 56 W x 25 D mm)
Weight	4.6 oz. (130 g)
Calibration	Includes NIST-traceable certificate

ACCESSORIES/RELATED ITEMS



**Standard
Protective Boot**
(THS-830-227)



**SST Wall Bracket
w/Probe Holder**
(THS-832-050)



**Duracell Procell AAA
Battery, 4-pack**
(PC2400)



**Rubber Boot w/
Probe Holder**
(THS-830-255)



ThermoWorks

Food Check Thermocouple Thermometer



Copyright by ThermoWorks, Inc. Content may not be used in whole or in part without written consent.

ThermoWorks and the ThermoWorks logo are registered trademarks of ThermoWorks, Inc. Food Check is a registered trademark of ETI, Ltd. ThermoWorks is the exclusive distribution partner of ETI, Ltd. in North America. All rights reserved.



ThermoWorks

741 E. Utah Valley Dr., American Fork, UT 84003
Ph: 801-756-7705 Fax: 801-756-8948
thermoworks.com



Made in the UK



Operating Instructions

INSTRUMENT OPERATION - Switch the instrument on and apply the tip of the probe to the substance or medium to be measured. The instrument reading may take a few seconds to stabilize, depending on the nature of the measurement and sensitivity of the probe.

OPEN CIRCUIT/FAULTY PROBE - If the probe has developed an 'Open Circuit' fault the instrument will display 'Err'.

CHANGE FROM FAHRENHEIT TO CELSIUS - Press and hold the "ON/OFF" button for 5 seconds at startup and the displayed temperature will change from °F and °C.

BATTERY REPLACEMENT - The instrument will display 'LO BAT' to warn that the batteries will need changing soon. The instrument continues to measure accurately but after further usage the instrument will display 'flat bat' and shutdown. Replace the batteries with three AAA batteries located under the rear cover that is held in place by a single screw.

INSTRUMENT CLEANING - Clean the instrument regularly with an anti-bacterial probe wipe to avoid potential food-borne bacteria growth.

WARNING - IPA and other solvents may cause damage to the case and screen of this instrument.

GUARANTEE - This instrument carries a two-year warranty against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ThermoWorks, be either repaired or replaced without charge. This warranty does not apply to probes, where a six-month period is offered. Full details of liability are available within ThermoWorks' Terms & Conditions of Sale at www.thermoworks.com/product-warranty.

For warranty, service, and technical assistance, please contact ThermoWorks' Technical Support at (385) 330-0591 or email at techsupport@thermoworks.com.