

Brio®

Manual Water Pump

Assembly

1. Prior to assembly, wash all tubes with soapy water and rinse thoroughly. Rinse all other parts thoroughly with warm water as well.
2. Depending on your bottle, connect a mid-length (G) or long-length (H) tube to the lower tube (I). NOTE: Additional tubing has been included to accommodate different bottle sizes. Whatever the configuration, ensure assembled tubing reaches the bottom of the bottle.
3. Insert the upper tube (G or H) into the bottom of the pump (A) and twist clockwise, applying pressure until secure. (If experiencing difficulty you may place the head of the tube in boiling water for 10-20 seconds to soften the tip.)
4. Attach the spout (B) to the front of the pump with a slight twist to secure, and ensure the spout opening is pointed downward.
5. After removing the bottle cap, insert assembled pump tubing into the water bottle. Push down on base of pump to connect to top of bottle. Turn fixing nut at the base of the pump counter clockwise until pump is securely attached to bottle. NOTE: If you have a 53mm screw-top bottle, attach the bottle adapter (E) first, then attach pump.

Use

1. Place cup, glass or pitcher under spout.
2. Press firmly down on top pump button to dispense water. Repeat if necessary to initiate flow.

Cleaning and Care

1. Clean pump with a cloth, mild dishwashing soap and water.
2. Clean tubes and spout in dishwasher.
3. Store in a clean, dry location.
4. For your convenience, a handy brush (D) is included.

