


Owner's Manual

Smart Switch

At a Glance



1 LED Indicator:

- Indicates the on/off status of Smart Switch.
- Indicates the network connection status.

2 RESTART Button:

- Press to restart Smart Switch.

3 RESET Button:

- Press and hold for 5 seconds to reset Smart Switch to factory settings.

4 Wires:

- Live wire (Black)
- Load wire (Red)
- Neutral wire (White)
- Ground wire (Green)

5 Screws (x 2)

6 AWG Wire Nuts (x 4)

LED	Status	Indicates
	Slowly flashing amber and blue	Smart Switch is ready to connect to a Wi-Fi network.
	Rapidly flashing amber and blue	Smart Switch is connecting to a Wi-Fi network.
	Solid blue (turns off after one minute)	Smart Switch is connected to a Wi-Fi network.
	Solid white	The device (i.e. light bulb) controlled by Smart Switch is turned off.

What You Need Before Installing


- Smart Switch
- A neutral wire at the wall switch
- A voltage detector
- A Phillips screwdriver
- Wire cutters
- A smartphone or tablet running iOS 8.0 (or above) or Android 4.3 (or above)
- A wireless router

Important Tips Before Installing

Before installing, read and follow the safety instructions below:

- Risk of electric shock or fire:** turn off the electricity at the circuit breaker or fuse. Use a voltage detector to ensure there is no power at the circuit breaker.
- If you are unfamiliar with electrical work, consult a professional electrician to install Smart Switch.
- Do not install Smart Switch with wet hands or when standing on wet or damp surfaces.

- Do not use a metal faceplate as it may interfere with the Wi-Fi signal.
- Smart Switch is an indoor single-pole switch that requires a neutral connection (lights controlled by more than one switch is not supported).



Downloading the EufyHome App

What you need:

- A Wi-Fi router supporting the 2.4 GHz and 802.11 b/g/n bands; the 5 GHz band is not supported;
- A smartphone or tablet connected to a Wi-Fi network;
- A smartphone or tablet running iOS 8.0 (or above) or Android 4.3 (or above).




Download the EufyHome app from the App Store (iOS devices) or Google Play (Android devices).


Installing Smart Switch

- In the EufyHome app, tap the "+" icon in the top right corner to add "Smart Switch" to your EufyHome account.
- Remove the faceplate from Smart Switch and identify the wires on Smart Switch.
- Follow the wiring steps provided in the app to install Smart Switch.
- After installation, press the On/Off button to turn on your device, such as the light bulb.

- When the light bulb turns on, the LED indicator on Smart Switch will turn off.
- When the light bulb turns off, the LED indicator on Smart Switch will light up in white.



Setting Up Smart Switch with the EufyHome App



After successfully connecting to a Wi-Fi network, you can control Smart Switch with the EufyHome app.

	Turn Smart Plug on or off.
	Control your devices remotely.
	Set schedules for Smart Switch: Create an event to determine when your devices will automatically turn on or off.
	Set a countdown timer: Your devices will automatically turn on or off after a preset amount of time.
	Enable Away Mode: Your devices will randomly turn on and off during the set period of time, giving the impression that someone is home.



Controlling Smart Switch with Amazon Alexa / the Google Assistant (Optional)

Before you start, make sure that:

- Smart Switch is connected with the EufyHome app.
- You have an Alexa-enabled device (i.e. Eufy Genie, Amazon Echo, Echo Dot and Amazon Tap), or a Google Assistant enabled device (i.e. Google Home). These devices are sold separately.
- The Amazon Alexa app or the Google Home app is already installed on your smart device, and you have created an account.

To control Smart Switch with Amazon Alexa:

- Open the Alexa app and select "Skills" from the menu in the top-left corner of the homepage.
- On the Skills screen, search for "EufyHome".
- Once you have found the "EufyHome" skill, tap **Enable**.




For FAQs and more information, please visit
www.eufylife.com

T1211
51005000816 V01

- 4 Login with your EufyHome account to authorize Alexa to access your account.
- 5 Discover new smart devices via the "Smart Home" menu in the Alexa app or Alexa voice control.
 - Once the device is connected, you can control the device with your voice.
- 6 Say simple commands to Alexa.

Note: You can modify the name of a device in the EufyHome app.



►9

To control Smart Switch with the Google Assistant:

Smart Switch now works with the Google Assistant on devices like the Google Home.

- 1 Open the Google Home app.
- 2 From the menu of the Google Home app, tap **Home Control**. If you cannot find **Home Control**, upgrade your app to the latest version.
- 3 Tap the "+" icon in the Device List and then select "EufyHome".
- 4 Follow the instructions in the Google Home app to authorize the Google Assistant with your EufyHome account.
- 5 After successful configuration, say simple commands to the Google Assistant to control Smart Switch with your voice.

Note: You can modify your device name in the EufyHome app.

►10

"Ok Google, turn on My Smart Switch."



Restarting Smart Switch

Press the RESTART button to restart Smart Switch and reconnect to the Wi-Fi network.

Resetting

Press and hold the RESET button for 5 seconds until the LED indicator flashes amber and blue.

- Smart Switch is reset to factory settings. All your custom settings are erased.

►11

Troubleshooting

1. No response when pressing the physical switch.

- Check if there is power at the circuit breaker.
- Check if Smart Switch is wired correctly. Consult with a qualified electrician for electrical wiring work.

2. Cannot connect to your Wi-Fi network.

- Check if you have entered the correct Wi-Fi password.
- Check if there are any Internet connection problems. If the Wi-Fi signal is too weak, reset your wireless router and try again.
- If the LED Indicator is solid blue, indicating Smart Switch is connected to a Wi-Fi network, press the RESTART button to restart the Wi-Fi connection.
- If you still have trouble, reset Smart Switch to factory settings.

3. Cannot control Smart Switch with the EufyHome app.

- Check if there are any Internet problems. If necessary, reset your wireless router and try again.

►12

- Do not use a metal faceplate with Smart Switch to prevent Wi-Fi signal interference.
- If your smart device uses a 3G or 4G mobile network, check whether the network signal is abnormal. Try again when the signal becomes stable.
- If you still have trouble, reset Smart Switch to factory settings.

4. Cannot control Smart Switch with Amazon Alexa voice control.

- Check if there are any Internet connection problems.
- Check if you have installed the Alexa app onto your smart device and enabled the "EufyHome" Skill in the Alexa app. For details, refer to the **Controlling Smart Switch with Amazon Alexa / the Google Assistant (Optional)** section of this manual.
- Check if you are using the proper commands when talking to Alexa. When making your request, first say the wake word "Alexa".
- Repeat your question. Speak clearly to Alexa.
- Check if you have modified the name of Smart Switch in the EufyHome app. If yes, you need to rediscover the device through the Alexa app or via Alexa voice control.

►13

5. Cannot control Smart Switch with the Google Assistant voice control.

- Check if there are any Internet connection problems.
- Check if you have installed the Google Home app onto your smart device and enabled the "EufyHome" Skill in the Google Home app. For details, refer to the **Controlling Smart Switch with Amazon Alexa / the Google Assistant (Optional)** section of this manual.
- Check if you are using the proper commands when talking to the Google Assistant. When making your request, first say the wake words "Ok Google".
- Repeat your question. Speak clearly to the Google Assistant.
- Check if you have modified the name of Smart Switch in the EufyHome app. If yes, unlink your EufyHome account from the Google Home app and then relink.

►14

Customer Service

- 18-month limited warranty
- Lifetime technical support
- support@eufylife.com
- +1 (800) 988 7973 (US) Mon-Fri 9:00 - 17:00 (PT)
+44 (0) 1604 936200 (UK) Mon-Fri 6:00 - 11:00 (GMT)
+49 (0) 69 9579 7960 (DE) Mon-Fri 6:00 - 11:00
+81 03 4455 7823 (日本) 月 - 金 9:00 - 17:00
+86 400 0550 036 (中国) 周一至周五 9:00 - 17:30

- @EufyOfficial @EufyOfficial
- @EufyOfficial @EufyOfficial

►15