

Meet your new phone

xfinity mobile

SAMSUNG
Galaxy A70

Printed in Korea
GH68-51222A

Getting started

This guide provides you with the information you need to get started.

- Before turning on your phone, visit **xfinitymobile.com/activate**. Log in to start the activation process.

Access account information

- The **Xfinity Mobile** app is preloaded on your phone. Consider it your control center to track your usage, manage your account and more.
- From the Home screen swipe up to access apps, tap Search phone, and enter "Xfinity Mobile" to find the **Xfinity Mobile** app.

Access voicemail

- Tap **Voicemail** and follow the on-screen instructions to setup your voice mailbox.


A map of the hardware



If you use a screen protector, make sure it allows for use of all touch-screen features.

Set up your phone

Your SIM card may be pre-installed.



Remove SIM/microSD tray

Use the tool to open the SIM/microSD™ card tray.

Insert SIM/microSD

Place the SIM card and optional microSD card (sold separately) into the tray with the gold contacts facing down.

Charge your device

Before turning on your phone, charge it fully.


Note: Use only Samsung-approved charging devices and accessories. Samsung accessories are designed for your device to maximize battery life. Using other accessories may void your warranty and may cause damage.

Backup and restore

Get help transferring contacts, photos and other content from your old phone at **samsung.com/smarts witch**

Search

From the Home screen swipe up and search for apps, settings, contacts, and more.



Customize your phone

From the Home screen, swipe up, and then tap **Settings** to customize, connect and personalize your phone:

Connections

Connect to a Wi-Fi™ network, Bluetooth device and other connection options.

Sounds and vibration

Set device volume and sounds.

Display

Customize the Home screen, navigation gestures, and display brightness.

Wallpapers and themes

Make the device your own with fun and unique wallpapers and themes.

Digital wellbeing

Configure usage limits on your device.

Lock screen

Select a screen lock type and set security options.


Biometrics and security

Set facial or fingerprint security options.

Night mode

Use a darker theme to keep your eyes comfortable at night.

From **Settings**, tap **Display** > **Night mode**.



Camera



Bixby Vision

Identify objects and locations.

Tool panel

Swipe left or right to select effects.

Camera modes

Swipe left or right to select a mode.

Gallery

View photos.

Capture

Take photos.

Toggle cameras

Switch between the back and front cameras.




Recent apps

Enjoy the new full-screen view of recent apps.

Tap **Recents** to view a list of recently opened apps.


- Tap an app icon to view options.
- Swipe up to close.
- Swipe down to open.



Gestures

Customize the Home, Back and Recents keys or remove them and use gestures instead to increase screen space.

1. From **Settings** , tap **Display** > **Navigation bar**.
2. Tap one of the following Navigation types:
 - Navigation buttons (default)
 - Full screen gestures
 - Button order
 - Gesture hints (Displays only when full screen gestures is selected)



Learn more

The Help feature gives access to the user manual and useful information on how to use your device.

To open, from **Settings** tap **Help** .

- Make a call
- Send and receive texts
- Manage contacts
- Explore health & fitness
- Utilize accessibility settings

Samsung Care



Samsung Premium Care

Get more than just protection for your device. Pick the time and place, and a team member will meet you to set up, troubleshoot, repair or replace your product.

Enroll at samsung.com/us/support/premium-care

Get to know your product:

- Access user manuals, troubleshooting, and more at samsung.com/us/support

Ask the community:

- Ask questions and share solutions with other Samsung customers at us.community.samsung.com

Contact us for support:

- Get hardware or software support, at samsung.com/us/support/contact or call us at 1.800.SAMSUNG
- Find a service location near you at samsung.com/us/support/service/locations

Need Help? We're here.
Call Xfinity Support at **1 (888) 936-4968**

©2019 Samsung Electronics America, Inc. Samsung and Galaxy A70 are both trademarks of Samsung Electronics Co., Ltd. Android, Google, Google Play, and other marks are trademarks of Google LLC. Other company and product names mentioned herein may be trademarks of their respective owners. Screen images simulated. Appearance of phone may vary.

©2019 Comcast. All rights reserved. The Xfinity Mobile logo and ("O") logo are trademarks of Comcast Corporation or its subsidiaries.