



User Manual

Model: H3500

Govee Outdoor Pathway Lights 2 Lite

IMPORTANT SAFETY INSTRUCTIONS

When using products, basic precautions should always be practiced including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- All safety messages will alert you of what the potential hazard is, tell you how to reduce the chance of injury, and let you know what can happen if the instructions are not followed.
- This light is rated as IP67. It can be used outdoors but cannot be immersed in water.
- Tighten up the waterproof cap before using the light.
- Do not allow children to assemble and install this product.
- Avoid installing this product near major heat sources or other dangerous sources.
- Avoid using other non-standard adapters for this product.
- External dimmers cannot be used with this product.
- Use this product with the provided power adapter only.
- This device uses a non-replaceable light source. When the light source reaches the end of its life cycle, this device should be replaced.
- CAUTION-The product is not a toy. Children and the disabled should use it under adult supervision.
- To reduce the risk of strangulation, the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.
- Risk of Electric Shock. The adapter install only to a covered Class A GFCI receptacle that has an enclosure that is weatherproof with the attachment plug cap inserted or removed.
- Any open ends must be sealed-off before use.
- This product includes a built-in mic that can recognize sound information to synchronize lights and music.
- FOR USE WITH LANDSCAPE LIGHTING SYSTEMS ONLY.
- LANDSCAPE LIGHTING SYSTEMS ARE FOR OUTDOOR USE ONLY.
- POWER SUPPLIES ARE FOR OUTDOOR USE ONLY.


- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of the appliance or any other appliance. The fumes can create a fire hazard or an explosion.
- Never clean appliance parts with flammable fluids or harsh chemicals. The fumes can create a fire hazard or an explosion.
- Never touch uninsulated cables, especially AC cables, with bare hands.
- Avoid using other non-standard power adapters for this product.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- If the LED light source does not illuminate when the light is turned on, please disconnect the power supply, perform troubleshooting checks first, and if it still does not illuminate, please consult after-sales services.
- Please do not operate the product with wet hands or pull on the power cord, as this may damage the power cord and cause a fire or electric shock.
- When the product is not in use for a long period of time, please unplug the power cord from the outlet to prevent fire accidents.
- When cleaning the light fixture, please turn off the power supply, use a soft cloth dipped in neutral detergent, wring it out, wipe the fixture, and then wipe it dry with a dry cloth.
- Interconnection shall be made only by the use of the supplied connectors. Any open ends must be sealed-off before use.
- For ambience lighting only. Not for illumination.

SAVE THESE INSTRUCTIONS

What You Get

Item	Quantity
Pathway Lights	4
Control Box	1
Power Adapter	1
Ground Stake	4

At a Glance



Pairing Your Light with Govee Home App

What You Need

- A Wi-Fi router supporting the 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS 8.0 and above or Android 4.3 and above.




Google Play is a trademark of Google LLC.

1. Download Govee Home App from the App Store (iOS devices) or Google Play (Android devices).
2. Turn on your smartphone's Bluetooth.
3. Open the app, tap the "+" icon in the top right corner and search for "H3500".
4. Tap the device icon and follow the on-screen instructions to complete pairing.

Installing Your Device

Please connect the device and power it up to check if it is working properly.


If you want to display the following lighting effects.



Connect and install the two string lights together. And please ensure you connect the lights to the longer output cable.




If you want to install it on both sides of the path, the lighting effect will resemble the picture below.




Recommended path
width: <1.5m/4.9ft

If you wish for adjacent U-shaped light spots to be displayed side by side, it is not recommended to use two rows of installations on paths wider than 1.5m/4.9ft.


1. Please connect each light string to the output terminals of the long control box and of the short control box, respectively.



2. Turn on the lights and install the first light using the ground stake. The projected light spot will help you assemble the lighting effects.



3. Do not install the ground stakes for the remaining lights yet. Align the light spots to confirm the installation positions (mark the locations using the ground stakes).



4. Install ground stakes at the base of the path lights and insert the fixtures into the designated installation locations.



Specifications

Power Input (Adapter)	100-240VAC 50/60Hz
Power Input (Light)	24VDC 1A
Waterproof	Light: IP67 Control Box: IP67
Light Color	RGBWIC
Working Temperature	-20 to 40 °C (-4 to 104 °F)

Matter Guide Card

Cautions:

1. You need to complete the network connection of apps that support Matter (e.g. Google Home/Apple HomeKit etc.) within 15 minutes after the product is powered on when using Matter for the first time.
2. An IPv6 network is required.
3. Changing the network may cause Matter to malfunction.
4. If unable to connect successfully, please reset the network settings on the Wi-Fi setup page and try again.

Step 1

Find the QR code or device number of Matter on the product or on Device Settings page in Govee Home App.

Step 2

Turn on the Bluetooth on your smartphone.

Step 3

Download and open the app that supports Matter like Google Home/Apple HomeKit, etc.

Step 4

Use the device number or QR code on the product in the app to complete the network connection of Matter for the product.

Troubleshooting

Cannot connect to Govee Home App.

- Make sure the device is powered on.
- Make sure your smartphone's Bluetooth has been enabled.
- Make sure your smartphone is connected to a 2.4GHz WiFi network.
- Position your smartphone close to the control box, then try connecting again. One or more LED Spotlights fail to light up.
- Remove the light and then reattach it to the power cable. Also unplug the power adapter and then plug back into power.
- If the problem persists, please contact Govee Customer Service.

Customer Service

 Warranty: 12-Month Limited Warranty

 Support: Lifetime Technical Support

 Email: support@govee.com

 Official Website: www.govee.com

 @GOVEE  @goveeofficial  @govee.official

 @GoveeOfficial  @GOVEE



Govee Home App

For FAQs and more information,
please visit: www.govee.com