



## Other Operations

### Searching content




- 1 Tap the **Search** charm (see cover).
- 2 Tap **Apps**, **Settings**, or **Files**.
- 3 Enter a keyword (e.g. **Control Panel**) in the **Search** box.

### Entering sleep or shutting down



- 1 Tap the **Settings** charm (see cover).
- 2 Tap **Power**, then tap **Sleep**, **Shut down**, or **Restart**.

### Switching apps



Swipe in from the left edge.

### More about how to use Windows 8

Refer to **Windows Help and Support**.

- 1 Tap the **Search** charm (see cover).
- 2 Enter "Help and Support" in the **Search** box, tap **Apps**, and then tap the icon.

Screenshots on this guide are examples in English.  
Content in this guide is subject to change without notice.

Microsoft, Windows, the Windows logo are trademarks of the Microsoft group of companies. In the manual, the TM or (R) marks are not specified.



# SONY

# Windows 8 Getting Started

## New Start Screen and Menu

### Start screen

You can add shortcuts to apps, the desktop, and websites that you use the most.


- **Touch operation**  
Open the charms, then tap the **Start** charm.
- **With a keyboard**  
Press the **Windows** key.




### Charms

Search for apps and files, share content, play content on other devices or print, and set up your PC.

- **Touch operation**  
Swipe in from the right edge.



- **With a mouse/touch pad**  
Point to the upper-right corner, then move downward.



- **With a keyboard**

Press the **Windows** key and the **C** key at the same time.




### Tiles

Tap a tile to start an app and personalize the **Start** screen by adding and rearranging tiles.


## Using Apps

### Starting apps



- 1 Tap the **Search** charm (see cover).
- 2 Enter a keyword in the **Search** box, tap **Apps**, and then tap the app icon.

### Opening the apps menu



- **Touch operation**  
Swipe up from the bottom edge.
- **With a mouse/touch pad**  
Right-click within an app.


### Viewing running apps



- **Touch operation**  
Swipe in from the left edge until a small app icon appears. Then, drag the icon back towards the left edge.
- **With a mouse/touch pad**  
Point to the upper-left corner, then move downward.




### Closing apps



- 1 When an app is open, point to the top-center of the screen.
- 2 Drag the app to the bottom of the screen until the app disappears from the screen.


## Using the Internet

### Connecting to a Wireless LAN



- 1 Tap the **Settings** charm (see cover).
- 2 Tap the network icon.
- 3 Select your wireless network from the list, then tap **Connect**.

### Opening websites




Enter a URL or keyword in this box.

- 1 On the **Start** screen, tap the **Internet Explorer** tile.
- 2 Enter a URL or keyword to search websites.
- 3 To open a new tab, open the apps menu (see left page) and tap the **+** icon.

You can also find the traditional style **Internet Explorer** on the desktop.

## Installing apps from Windows Store



You can add apps from **Windows Store**.

- 1 Connect to the Internet.
- 2 Tap the **Store** icon on the **Start** screen, and then find an app to install.

### Microsoft Account

You will need a Microsoft account to use some of the apps or services, including **Windows Store**. On how to create and what you can do with a Microsoft account, refer to **Windows Help and Support** (see back page).